

[Manuals.plus](#) /

› [Squishmallows](#) /

› Squishmallows Original 8-Inch Bimbi The Clown Plush Toy Instruction Manual

Squishmallows SQCR05572

Squishmallows Original 8-Inch Bimbi The Clown Plush Toy Instruction Manual

1. INTRODUCTION

Welcome to the world of Squishmallows! This manual provides essential information for the care and enjoyment of your new Squishmallows Original 8-Inch Bimbi The Clown plush toy. Bimbi is a soft, collectible stuffed animal designed for cuddling and imaginative play.



Image 1.1: The Squishmallows Original 8-Inch Bimbi The Clown plush toy, featuring its distinctive colorful clown outfit and soft texture.

2. INITIAL SETUP

Your Squishmallows Bimbi The Clown arrives ready for immediate use. No assembly is required. Please follow these steps upon receiving your product:

1. **Unboxing:** Carefully remove Bimbi from its packaging.
2. **Tag Removal:** Locate and remove any attached product tags. Retain the official tag for authenticity verification and product information, if desired.



Image 2.1: Close-up of the official Squishmallows product tag, which confirms authenticity.

3. USAGE GUIDELINES

Bimbi The Clown is designed for comfort and companionship. It is suitable for individuals aged 24 months to 8 years, and beyond. Use your Squishmallows for:

- **Cuddling:** Its soft, squishy texture makes it an ideal cuddle companion.
- **Imaginative Play:** Encourage creative storytelling and role-playing.
- **Travel:** Its portable 8-inch size makes it suitable for car rides, airplanes, or sleepovers.



SUPER SQUISHY

Image 3.1: A person holding Bimbi The Clown, illustrating its soft and squishy characteristic.

4. CARE AND CLEANING

To maintain the quality and softness of your Squishmallows Bimbi The Clown, follow these care instructions:

- **Spot Cleaning:** For minor stains, use a damp cloth with mild soap. Gently rub the affected area.
- **Hand Washing:** For a more thorough clean, hand wash with cold water and a gentle detergent. Rinse thoroughly.
- **Drying:** Air dry only. Do not machine wash or tumble dry, as this can damage the plush material and filling. Avoid direct sunlight.
- **Fluffing:** After drying, gently fluff the Squishmallows to restore its original shape and squishiness.

Do not bleach, iron, or dry clean.



Image 4.1: A close-up view of the Squishmallows' super soft fabric, emphasizing the material that requires gentle care.

5. TROUBLESHOOTING

This section addresses common inquiries regarding your Squishmallows.

- **Loss of Squishiness:** If your Squishmallows feels less squishy over time, gentle fluffing and kneading can help redistribute the filling and restore its original texture.
- **Minor Stains:** Refer to the 'Care and Cleaning' section for spot cleaning instructions. Prompt cleaning is recommended for best results.
- **Loose Threads:** If you notice any loose threads, carefully trim them with scissors. Do not pull on loose threads to avoid damaging the stitching.

6. PRODUCT SPECIFICATIONS

Detailed specifications for the Squishmallows Original 8-Inch Bimbi The Clown:

Feature	Detail
Product Dimensions	6 x 6 x 8 inches (Length x Width x Height)
Item Weight	6.4 ounces
Item Model Number	SQCR05572
Manufacturer	Jazwares
Recommended Age	24 months - 8 years
Material	Polyester



Image 6.1: Bimbi The Clown with visual indicators of its 8-inch height and approximate width and depth.

7. WARRANTY AND SUPPORT

Squishmallows products are manufactured by Jazwares. For any questions regarding product quality, defects, or general inquiries, please contact Jazwares directly. While specific warranty details are not provided in this manual, Jazwares is committed to product satisfaction.

For further assistance, please visit the official Jazwares website or contact their customer support. You can often find contact information on the product's official packaging or by searching online for "Jazwares customer support".

Please retain your purchase receipt as proof of purchase for any support inquiries.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question