

PRESS Shaver23

PRESS 5-in-1 Electric Rotary Shaver Grooming Kit (Model: Shaver23) User Manual

Model: Shaver23 | Brand: PRESS

1. IMPORTANT SAFETY INFORMATION

For safe and proper use, keep this device out of reach of children. Use only as intended. The manufacturer is not responsible for misuse of the product.

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

2. PRODUCT OVERVIEW

The PRESS 5-in-1 Electric Rotary Shaver Grooming Kit (Model: Shaver23) is a versatile grooming tool designed for men. It features a multi-head rotary shaver for smooth, bump-free shaving on the head and body, and includes several interchangeable attachments for comprehensive grooming needs. This device supports both wet and dry shaving and is waterproof for easy cleaning.



Image 2.1: The PRESS 5-in-1 Electric Rotary Shaver with its various grooming attachments.

Key features include:

- **Smooth, Bump-Free Shave:** Equipped with soft alloy blades and Advanced Anti-Bump technology for comfortable shaving.
- **Wet/Dry Shaving:** Suitable for use with or without shaving cream, in wet or dry conditions.
- **5-in-1 Grooming Kit:** Includes a five-blade rotary shaver, precision clipper/trimmer with safety guards, nose & ear hair trimmer, micro & plush skin exfoliation brush, and a deep cleansing massage pad.
- **Ergonomic Design:** Easy to hold and maneuver for effective shaving on various body parts.
- **Long Battery Life:** Cordless and portable with a rapid USB charging feature, offering up to 90 minutes of use per charge.

3. PACKAGE CONTENTS

Upon opening your package, please ensure all the following items are present:

- PRESS Electric Rotary Shaver Unit
- Five-Blade Rotary Shaver Head
- Precision Clipper/Trimmer Head
- 3mm Safety Guard for Trimmer
- 5mm Safety Guard for Trimmer
- 7mm Safety Guard for Trimmer
- Nose & Ear Hair Trimmer Head

- Micro & Plush Skin Exfoliation Brush Head
- Deep Cleansing Massage Pad Head
- USB Charging Cable
- Cleaning Brush



Image 3.1: Visual representation of the 5-in-1 grooming kit and its various functions.

4. SETUP AND CHARGING

4.1 Initial Charge

Before the first use, fully charge your shaver. This process typically takes approximately 90 minutes. During charging, the unit's indicator light will display RED. Once fully charged and ready for use, the light will turn solid GREEN.



Image 4.1: The shaver connected to its USB charging cable.

4.2 Attaching and Detaching Accessories

To change an attachment, gently pull the current head upwards to detach it from the shaver body. Align the desired attachment with the shaver body and press down firmly until it clicks into place. Ensure the attachment is securely fastened before use.



Image 4.2: Demonstrating the attachment and detachment of shaver heads.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

Press the power button located on the front of the shaver to turn the device on or off.

5.2 Using the Rotary Shaver Head

For best results, hold the shaver at a right angle to your skin and move it in small, circular motions. The flexible heads will contour to the curves of your head, face, or body. Can be used for both wet and dry shaving.

5.3 Using the Precision Clipper/Trimmer Head

Attach the precision clipper/trimmer head for shaping beards, sideburns, or for general hair trimming. Select one of the three safety guards (3mm, 5mm, or 7mm) and slide it onto the trimmer head to achieve your desired hair length. Move the trimmer against the direction of hair growth for an even cut.



Image 5.1: The precision trimmer head with its adjustable limit combs.

5.4 Using the Nose & Ear Hair Trimmer Head

Carefully insert the nose & ear hair trimmer head into your nostril or ear canal. Move it gently to trim unwanted hair. Do not insert too deeply.

5.5 Using the Facial Cleansing Brush Heads

Attach either the micro & plush skin exfoliation brush or the deep cleansing massage pad. Dampen your face and apply your preferred facial cleanser. Gently move the brush in circular motions across your face to cleanse and exfoliate. Rinse your face thoroughly after use.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene of your shaver.

6.1 Cleaning the Rotary Shaver Head

1. Turn off the shaver.
2. Gently open the shaver head by pressing the release button or lifting the top cover.
3. Carefully remove each individual blade assembly.
4. Rinse the blades and the shaver head under running water. Use the provided cleaning brush to

remove any trapped hair or debris.

5. Allow all parts to air dry completely before reassembling.



5 Cutter Head Shaver



Pull Out Trimmer Head



Comfortable Handle



Charging Jack

Image 6.1: Disassembly of the rotary shaver head for thorough cleaning.

SIZE:



Image 6.2: The shaver head being rinsed under water, highlighting its waterproof feature.

6.2 Cleaning Other Attachments

Rinse the trimmer, nose/ear trimmer, and facial brush heads under running water. Use the cleaning brush for any stubborn debris. Ensure they are dry before storing.

7. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---------------------------|---|---|
| Shaver does not turn on. | Low battery. | Charge the shaver for at least 90 minutes until the indicator light turns green. |
| Poor shaving performance. | Blades are dull or clogged with hair. | Clean the shaver head thoroughly. Consider replacing the shaver head if blades are dull. |
| Shaver stops during use. | Battery is depleted. | Recharge the shaver. |
| Irritation after shaving. | Improper shaving technique or sensitive skin. | Ensure proper technique (small circular motions). Try wet shaving with shaving cream. Use the exfoliation brush before shaving. |

8. SPECIFICATIONS

Model Name: Shaver23

Brand: PRESS

Power Source: Battery Powered

Special Features: Ergonomic Design, Portable, Rechargeable, Waterproof

Recommended Uses: Scalp, Beard, Nose, Ear, Body

Product Dimensions: 3.94 x 3.15 x 1.25 inches

Item Weight: 12.7 ounces

Batteries: 1 Lithium Polymer battery required (included)

Charging Time: Approximately 90 minutes

Operating Time: Up to 90 minutes per charge



Image 8.1: Product dimensions for the shaver and its components.

9. PRODUCT DEMONSTRATION VIDEO

Watch this official product video for a visual guide on the features and usage of the PRESS 5-in-1 Electric Rotary Shaver Grooming Kit.

Your browser does not support the video tag.

Video 9.1: A demonstration of the PRESS 5-in-1 Electric Razor for Men, showcasing its features and ease of use.

10. WARRANTY AND SUPPORT

For warranty information, technical support, or any inquiries regarding your PRESS 5-in-1 Electric Rotary Shaver Grooming Kit, please contact the manufacturer directly through their official channels. Refer to the product packaging or the manufacturer's website for contact details.