

ROPER 01-031-0101-2000 BL

ROPER Boys Short Sleeve Snap Western Shirt Instruction Manual

Model: 01-031-0101-2000 BL

1. PRODUCT OVERVIEW

The ROPER Boys Short Sleeve Snap Western Shirt is designed for comfort and style. It features a classic plaid pattern, short sleeves, and convenient snap button closures. This shirt is suitable for various occasions, offering a blend of traditional western aesthetics and modern wearability.

Material Composition: 55% Cotton / 45% Polyester blend, providing a balance of breathability and durability.

2. KEY FEATURES

- **Fabric Blend:** Made from 55% Cotton and 45% Polyester for comfort and easy care.
- **Snap Button Front:** Features durable snap buttons for quick and easy fastening.
- **Western Yokes:** Includes 1-point front and back yokes, characteristic of western shirt design.
- **Pockets:** Equipped with patch pockets and flaps on the chest for functional storage.
- **Collar:** Designed with a classic spread collar.

3. SETUP AND WEARING INSTRUCTIONS

This shirt is ready to wear directly after purchase or after its initial wash. Follow these steps for proper use:

1. **Unfold and Inspect:** Carefully unfold the shirt and inspect it for any packaging creases or loose threads.
2. **Buttoning:** Begin by buttoning the shirt from the bottom snap upwards. Ensure all snaps are securely fastened.
3. **Collar Adjustment:** Adjust the spread collar for a comfortable fit around the neck.
4. **Fit Check:** Ensure the shirt fits comfortably across the shoulders and chest, allowing for freedom of movement.



Image 1: Rear view of the shirt, highlighting the plaid pattern and the distinctive western yokes on the back.

4. OPERATING (USAGE)

The ROPER Western Shirt is designed for everyday wear and various activities. Its snap buttons allow for quick changes and adjustments.

- **Casual Wear:** Ideal for casual outings, school, or family events.
- **Layering:** Can be worn as a standalone shirt or layered over a t-shirt for added warmth or style.
- **Activity:** The cotton-polyester blend offers comfort for active children.

5. MAINTENANCE AND CARE INSTRUCTIONS

Proper care will extend the life and appearance of your ROPER Western Shirt. Always refer to the care label inside the garment for specific instructions.

- **Washing:** Hand wash only. Use cold water and a mild detergent.
- **Drying:** Lay flat to dry or hang dry. Avoid direct sunlight to prevent fading. Do not tumble dry.
- **Ironing:** If necessary, iron on a low heat setting. Avoid ironing directly over snap buttons.

- **Bleaching:** Do not bleach.
- **Storage:** Store in a cool, dry place, preferably hung to maintain shape.

6. TROUBLESHOOTING

If you encounter any issues with your shirt, consider the following common solutions:

- **Wrinkles:** If the shirt is wrinkled, gently iron it on a low setting as per care instructions. Hanging immediately after washing can reduce wrinkles.
- **Snap Not Fastening:** Ensure the snaps are aligned correctly. If a snap is damaged, contact customer support.
- **Shrinkage/Fading:** Ensure you are following the "Hand Wash Only" and "Do Not Bleach" instructions. High heat during washing or drying can cause shrinkage or fading.
- **Loose Threads:** Minor loose threads can be carefully trimmed with scissors. Do not pull them.

7. SPECIFICATIONS

Brand	ROPER
Model Number	01-031-0101-2000 BL
Fabric Type	55% Cotton / 45% Polyester (Cotton Blend)
Care Instructions	Hand Wash Only
Department	Boys
Item Weight	2 Pounds
Origin	Import

8. WARRANTY AND SUPPORT

For specific warranty information or product support, please refer to the official ROPER website or contact their customer service department. Keep your purchase receipt as proof of purchase.

ROPER Official Website: www.roper.com (Note: This is a placeholder link as no specific link was provided in the product data)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question