

[manuals.plus](#) /

› [Audizio](#) /

› [Audizio Adria DAB/Internet Radio Tuner User Manual](#)

Audizio Adria

Audizio Adria DAB/Internet Radio Tuner User Manual

Model: Adria | Brand: Audizio

1. INTRODUCTION

Thank you for purchasing the Audizio Adria DAB/Internet Radio Tuner. This device offers a versatile audio experience, combining Internet Radio, DAB+, FM radio, Bluetooth connectivity, and Spotify Connect. This manual provides essential information for setting up, operating, and maintaining your tuner to ensure optimal performance and longevity.



Figure 1.1: Audizio Adria DAB/Internet Radio Tuner with included remote control and antenna.

2. SAFETY INFORMATION

- Read all instructions carefully before use.
- Keep the unit away from water, moisture, and direct heat sources.
- Do not block ventilation openings. Ensure adequate space around the unit for proper airflow.
- Use only the power adapter supplied with the unit.
- Do not attempt to repair or modify the unit yourself. Refer all servicing to qualified personnel.
- Dispose of batteries responsibly. The remote control uses 1 AAA battery.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Audizio Adria DAB/Internet Radio Tuner Unit
- Remote Control (requires 1x AAA battery, included)
- Power Adapter
- DAB/FM Antenna
- User Manual

4. PRODUCT OVERVIEW

4.1 Front Panel





Figure 4.1: Front Panel Controls and Display

- 1. Power / Standby Button:** Turns the unit on or off.
- 2. USB Port:** For media playback from USB storage devices.
- 3. Mode Button:** Switches between Internet Radio, DAB+, FM, Bluetooth, and Media Player modes.
- 4. Play/Pause Button:** Controls playback in media modes.
- 5. Skip/Tune Buttons:** Navigates tracks or tunes radio frequencies.
- 6. Display Screen:** Shows station information, menus, and settings.
- 7. Alarm Button:** Accesses alarm settings.
- 8. Menu/Info Button:** Enters menu or displays information.
- 9. Preset/Memory Button:** Saves or recalls favorite stations.
- 10. Back Button:** Returns to the previous menu or screen.
- 11. Volume / OK Knob:** Rotates to adjust volume or navigate menus; presses to confirm selections.

4.2 Rear Panel



Figure 4.2: Rear Panel Connections

- 1. Power Input:** Connect the supplied power adapter here.
- 2. DAB/FM Antenna Input:** Connect the included DAB/FM antenna.
- 3. Analog Output (RCA):** Connect to an amplifier or active speakers using RCA cables.

4. **AUX Input:** Connect external audio sources via a 3.5mm jack.
5. **USB Charge Port:** For charging external devices.
6. **Optical Digital Output:** Connect to an amplifier or DAC with an optical cable.
7. **Coaxial Digital Output:** Connect to an amplifier or DAC with a coaxial cable.

5. SETUP

5.1 Connecting Power and Antennas

1. Connect the supplied DAB/FM antenna to the DAB/FM Antenna Input on the rear panel. Extend the antenna fully for best reception.
2. Connect the power adapter to the Power Input on the rear panel, then plug it into a wall outlet.

5.2 Connecting to an Audio System

Choose one of the following methods to connect the Adria tuner to your amplifier or active speakers:

- **Analog Output (RCA):** Use RCA cables to connect the Analog Output ports on the Adria to the corresponding input on your amplifier.
- **Optical Digital Output:** Use an optical cable to connect the Optical Digital Output to an optical input on your amplifier or DAC.
- **Coaxial Digital Output:** Use a coaxial cable to connect the Coaxial Digital Output to a coaxial input on your amplifier or DAC.

5.3 Initial Power-On and Network Setup

1. Press the Power/Standby button on the front panel or remote control to turn on the unit.
2. The display will show the Audizio logo, then guide you through the initial setup wizard.
3. Follow the on-screen prompts to select your language, time zone, and connect to your Wi-Fi network. You will need your Wi-Fi network name (SSID) and password.
4. Use the Volume/OK knob to navigate menus and confirm selections.

6. OPERATING INSTRUCTIONS

6.1 Mode Selection

Press the **Mode** button on the front panel or remote control to cycle through available modes: Internet Radio, DAB+, FM, Bluetooth, and Media Player (USB).

6.2 Internet Radio





Figure 6.1: Internet Radio Mode Display

1. Select Internet Radio mode.
2. Use the Volume/OK knob to browse stations by location, genre, or search.

3. Press the Volume/OK knob to select a station.
4. To save a station as a preset, press and hold the **Preset/Memory** button. Select a preset number and confirm.
5. To recall a preset, press the **Preset/Memory** button briefly, then select the desired preset.

6.3 DAB/DAB+ Radio



Figure 6.2: DAB Radio Mode Display

1. Select DAB+ mode. The unit will automatically scan for available stations on first use.
2. Use the Volume/OK knob to scroll through the list of stations.
3. Press the Volume/OK knob to select a station.
4. Saving and recalling presets works the same as for Internet Radio.

6.4 FM Radio

In FM mode, use the Skip/Tune buttons to manually tune frequencies or press and hold to auto-scan. Saving and recalling presets works the same as for Internet Radio.

6.5 Bluetooth Connectivity

1. Select Bluetooth mode. The unit will enter pairing mode automatically.
2. On your smartphone, tablet, or other Bluetooth device, search for available devices and select "Audizio Adria".
3. Once paired, you can stream audio from your device to the tuner.

6.6 Spotify Connect



Figure 6.3: Spotify Connect Display

To use Spotify Connect:

1. Ensure your Audizio Adria is connected to the same Wi-Fi network as your smartphone or tablet running the Spotify app.
2. Open the Spotify app on your device and play a song.
3. Tap the "Devices Available" icon (usually a speaker or computer icon) at the bottom of the screen.
4. Select "Audizio Adria" from the list of available devices. The music will now play through your tuner.

6.7 Alarm Function



Figure 6.4: Clock and Alarm Display

Press the **Alarm** button to access and set up alarms. You can configure alarm time, source (buzzer, Internet Radio, DAB, FM), and frequency (daily, once, weekends, weekdays).

7. REMOTE CONTROL



Figure 7.1: Remote Control Layout

The remote control provides full functionality for operating your Audizio Adria tuner. Ensure the included AAA battery is correctly inserted. Point the remote control directly at the unit's front panel for optimal response.

- **SNOOZE:** Temporarily silences the alarm.
- **Power Button:** Turns the unit on or off.
- **Navigation Buttons (Up, Down, Left, Right, OK):** For menu navigation and selection.
- **VOL+/-:** Adjusts volume.
- **MODE:** Cycles through input modes.
- **MENU:** Accesses the main menu.
- **BACK:** Returns to the previous screen.
- **INFO:** Displays detailed information about the current station or track.
- **SCAN:** Initiates a scan for radio stations.
- **EQ:** Accesses equalizer settings.
- **Numeric Keypad (0-9):** For direct input or selecting presets.
- **PRESET:** Saves or recalls favorite stations.

8. MAINTENANCE

To ensure the longevity and optimal performance of your Audizio Adria tuner, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the unit's exterior. Do not use abrasive cleaners, waxes, or solvents.

- **Ventilation:** Ensure that the ventilation openings are not blocked. Dust accumulation can be removed with a soft brush or vacuum cleaner.
- **Storage:** If storing the unit for an extended period, disconnect it from the power supply and store it in a cool, dry place.
- **Antenna Care:** Handle the antenna gently to avoid damage.

9. TROUBLESHOOTING

If you encounter issues with your Audizio Adria tuner, consult the following table for common problems and solutions:

Problem	Possible Cause	Solution
No power	Power cable not connected; power outlet faulty.	Check power cable connection; try a different outlet.
No sound	Volume too low; incorrect audio output selected; amplifier/speakers off or disconnected.	Increase volume; check audio cable connections; ensure amplifier/speakers are on and set to correct input.
Cannot connect to Wi-Fi	Incorrect password; weak signal; router issue.	Verify Wi-Fi password; move unit closer to router; restart router.
Poor DAB/FM reception	Antenna not extended; weak signal area.	Fully extend and reposition the antenna; consider an external antenna if available.
Bluetooth pairing fails	Device not in pairing mode; device too far; interference.	Ensure both devices are in pairing mode; move devices closer; turn off other Bluetooth devices.

10. SPECIFICATIONS

Feature	Specification
Brand	Audizio
Model Number	Adria
Color	Silver
Display Size	3.2 Inches
Connectivity Technology	Optical, Coaxial, Bluetooth
Special Features	Bluetooth, Internet Radio, DAB+, FM, Spotify Connect
Supported Radio Bands	DAB, DAB+, FM
Power Source	Corded Electric
Product Dimensions (L x W x H)	43.4 x 7.5 x 31 cm
Item Weight	3.2 Kilograms
Included Components	Remote Control

Feature	Specification
Compatible Devices	Smartphone, Tablet, Laptop

11. WARRANTY INFORMATION

This product is covered by a manufacturer's warranty. Please refer to the warranty card included in your package or contact your retailer for specific terms and conditions. Keep your proof of purchase for warranty claims.

12. SUPPORT

For technical assistance, troubleshooting beyond this manual, or service inquiries, please contact Audizio customer support or your local dealer. Contact information can typically be found on the manufacturer's website or your purchase documentation.

