

[manuals.plus](#) /

› [BANGE](#) /

› [BANGE Business Laptop Smart Backpack Instruction Manual \(Model 7267G\)](#)

BANGE 7267G

BANGE Business Laptop Smart Backpack Instruction Manual

Model: 7267G

1. INTRODUCTION

Thank you for choosing the BANGE Business Laptop Smart Backpack. This manual provides essential information for the proper setup, operation, and maintenance of your backpack. Please read these instructions carefully to ensure optimal use and longevity of your product.



Image 1.1: Front view of the BANGE Business Laptop Smart Backpack.

2. KEY FEATURES

- **Waterproof Material:** Constructed from high-density coated oxford fabric, offering water and scratch resistance to protect contents.
- **Multi-function Pockets:** Designed for organized storage of various items.
- **Laptop Compartment:** Padded sleeve securely holds up to a 15.6-inch laptop and a 9.7-inch iPad.
- **USB Charging Port:** External port for convenient charging of electronic devices (requires user-provided power bank).
- **Ergonomic Design:** Multi-function shoulder straps with a card pocket and glasses hook for comfort and accessibility.

- **Luggage Strap:** Allows for secure attachment to rolling luggage handles, simplifying travel.
- **Compact Size:** Suitable for business, daily commute, outdoor activities, and overnight trips, meeting flight approved item size requirements.



Image 2.1: Overview of external features.

3. SETUP

3.1. USB Charging Port Setup

1. Locate the internal USB cable inside the backpack's dedicated power bank pocket.
2. Connect your personal power bank (not included) to the internal USB cable.
3. Close the power bank pocket securely.
4. To charge an external device, connect your device's charging cable to the external USB port on the side of the backpack.

External USB Port

Charging your phone wherever you go



Inside-connect your own power bank



Outside-connect your own USB cable



Then connect your phone



Image 3.1: USB Charging Port connection guide.



Image 3.2: Internal power bank connection.

4. OPERATION

4.1. Organizing Your Backpack

The BANGE Business Laptop Smart Backpack is designed with multiple compartments for efficient organization:

- **Main Compartment:** Ideal for carrying 5-6 pieces of clothing, suitable for overnight stays or short business trips.
- **Laptop & iPad Compartment:** A dedicated, padded section to protect your 15.6-inch laptop and 9.7-inch iPad.
- **Front Pocket:** Convenient for quick access items such as keys, cell phone, or wallet.
- **Side Pockets:** Two side pockets are available for items like a power bank, umbrella, or water bottle.
- **Card Pocket:** Located on the shoulder strap for easy access to credit cards or transit passes.
- **Anti-theft Pocket:** A discreet pocket on the back panel for valuables.





Image 4.2: Shoulder strap card pocket.



Image 4.3: Glasses hook feature.




Image 4.4: Anti-theft pocket.

4.2. Using the Luggage Strap

For convenient travel, utilize the integrated luggage strap. Slide the strap located on the back panel of the backpack over the handle of your rolling luggage. This secures the backpack to your suitcase, allowing for easier transport through airports or busy areas.

TRAVEL BACKPACK FOR FIGHT APPROVED



1 luggage strap



2 Anti sweat and breathable



3 Anti theft pocke

Image 4.5: Backpack attached to rolling luggage.

4.3. Shoulder Strap Adjustment

Adjust the padded shoulder straps to achieve a comfortable and secure fit. Pull the strap ends to tighten or loosen as needed. The breathable back padding enhances comfort during extended wear.

5. MAINTENANCE

5.1. Cleaning Instructions

Due to its waterproof and scratch-resistant oxford fabric, the backpack is easy to clean. Wipe the exterior with a damp cloth and mild soap. Do not machine wash or tumble dry. Allow to air dry completely before storage.

5.2. Storage

Store the backpack in a cool, dry place away from direct sunlight when not in use. Ensure all compartments

are empty and dry to prevent mold or mildew.

6. TROUBLESHOOTING

- USB Charging Port Not Working:** Ensure your power bank is fully charged and correctly connected to the internal USB cable. Verify that your external device's cable is properly inserted into the external port.
- Limited Capacity:** While designed for efficiency, the backpack has specific dimensions. Avoid overpacking to prevent strain on zippers and seams. Refer to the specifications for exact dimensions.
- Discomfort During Wear:** Adjust shoulder straps to distribute weight evenly. The padded back panel is designed for comfort; ensure the backpack sits correctly on your back.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	10 x 15 x 6 inches
Item Weight	2.29 pounds (1.04 Kilograms)
Department	Unisex-adult
Item Model Number	7267G
Capacity Total	30 Liters
Material	High-density coated oxford fabric
Laptop Compatibility	Up to 15.6-inch laptop

8. WARRANTY AND SUPPORT

BANGE products undergo rigorous quality inspection. If you encounter any issues or have questions regarding your BANGE Business Laptop Smart Backpack, please contact our customer support. We are committed to resolving your concerns within 24 hours.

This item is not intended for use by children 12 and under.

For further assistance, please visit the official BANGE Store on Amazon:[BANGE Store](#)