

[manuals.plus](#) /

› [INSPIRE](#) /

› [INSPIRE LED Panel ANVIK Ceiling Light User Manual](#)

INSPIRE ANVIK

INSPIRE LED Panel ANVIK Ceiling Light User Manual

Model: ANVIK | Brand: INSPIRE

1. INTRODUCTION

This manual provides detailed instructions for the safe and efficient installation, operation, and maintenance of your INSPIRE LED Panel ANVIK Ceiling Light. Please read this manual thoroughly before installation and keep it for future reference.



Figure 1: The INSPIRE LED Panel ANVIK Ceiling Light seamlessly integrated into a modern kitchen ceiling, providing bright, uniform illumination.

2. SAFETY INFORMATION

WARNING: To reduce the risk of electric shock, fire, or injury to persons, read and follow all warnings and instructions carefully.

- Always disconnect power at the fuse or circuit breaker before installation or servicing.
- Installation must be performed by a qualified electrician in accordance with all local electrical codes.
- Do not install this fixture in wet locations. It is designed for indoor use only (IP20 rating).
- Ensure the mounting surface can support the weight of the fixture.
- Do not attempt to modify the fixture. Any modifications may void the warranty and pose safety risks.
- Avoid direct eye exposure to the light source when the fixture is on.

3. PACKAGE CONTENTS

Carefully unpack the product and ensure all components are present and undamaged. If any parts are missing or damaged, do not attempt to assemble or install the product. Contact customer support immediately.

- INSPIRE LED Panel ANVIK Ceiling Light
- Mounting accessories (screws, anchors, etc.)
- User Manual (this document)

4. SETUP AND INSTALLATION

The INSPIRE LED Panel ANVIK can be installed either by surface mounting directly to the ceiling or by recessed installation into a false ceiling. Refer to the diagrams below for guidance.

4.1 Dimensions




Figure 2: Product dimensions. The panel measures 59.5 cm x 59.5 cm with a slim profile of 1.35 cm.

Before installation, ensure the chosen location has sufficient space for the fixture's dimensions (59.5 cm x 59.5 cm x 1.35 cm).

4.2 Installation Methods



Figure 3: Installation options for the LED panel. Method A shows surface mounting, while Method B illustrates recessed installation into a false ceiling.

1. Surface Mounting (Method A):

- Mark the drilling points on the ceiling according to the fixture's mounting holes.
- Drill holes and insert appropriate wall anchors if necessary.
- Secure the mounting bracket (if applicable) or the fixture directly to the ceiling using the provided screws.
- Connect the electrical wiring (Live, Neutral, Earth) to the fixture's terminal block, ensuring correct polarity.
- Attach the LED panel to the secured mounting points.

2. Recessed Installation (Method B):

- Prepare an opening in the false ceiling that matches the fixture's dimensions (59.5 cm x 59.5 cm).
- Connect the electrical wiring (Live, Neutral, Earth) to the fixture's terminal block.
- Carefully insert the LED panel into the prepared opening, ensuring the retaining clips (if present) secure it firmly.

After installation, restore power and test the light fixture.

5. OPERATING INSTRUCTIONS

The INSPIRE LED Panel ANVIK is designed for simple operation. Once correctly installed and connected to the main power supply, it can be controlled via a standard wall switch.

- **Turning On/Off:** Use the wall switch connected to the fixture to turn the light on or off.
- **Light Output:** The panel provides a bright 3900 lumens of light, suitable for illuminating areas up to 10 m².
- **Color Temperature:** The light emits a cool white light at 6000K, ideal for functional lighting in offices, kitchens, or hallways.




Figure 4: The 6000K cool white light from the INSPIRE LED Panel ANVIK provides clear and functional illumination, as shown in a kitchen setting.

6. MAINTENANCE

Regular maintenance will help ensure the longevity and optimal performance of your LED panel.

- **Cleaning:** Before cleaning, ensure the power supply to the fixture is disconnected. Use a soft, dry, or slightly damp cloth to wipe the surface of the panel. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish or electrical components.
- **Reparability:** This LED panel features an integrated LED that is designed to be repairable. In the event of a malfunction or technical issue, individual components may be replaced, extending the product's lifespan and reducing waste. For repairs, it is recommended to contact a qualified technician or the manufacturer's support.

7. TROUBLESHOOTING

If you encounter issues with your INSPIRE LED Panel ANVIK, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power supply; loose wiring; faulty switch; damaged LED driver.	Check circuit breaker/fuse. Ensure all wiring connections are secure. Test the wall switch. If the issue persists, contact a qualified electrician or customer support.
Light flickers or dims.	Unstable power supply; loose connection; incompatible dimmer (if applicable); faulty LED driver.	Verify stable power. Check wiring. Ensure no dimmer is used unless specified as compatible. Contact support if flickering continues.
Light is not as bright as expected.	Dust accumulation on the panel; incorrect installation.	Clean the panel surface. Review installation steps to ensure proper setup.

For problems not listed above, or if solutions do not resolve the issue, please contact customer support.

8. SPECIFICATIONS

Detailed technical specifications for the INSPIRE LED Panel ANVIK Ceiling Light:

Attribute	Value
Brand	Inspire
Model Name	ANVIK LED Panel
Manufacturer	ADEO
Product Dimensions	59.5 x 59.5 x 1.35 cm
Weight	2.15 kg
Power Consumption	27.2 W

Attribute	Value
Light Output (Lumen)	3900 lm
Color Temperature	6000K (Cool White)
Material	Aluminum
Ingress Protection (IP) Rating	IP20 (Indoor use only)
Installation Type	Ceiling Mount, Recessed
Power Source	Corded Electric
Special Features	Energy-efficient, Durable, Repairable LED panel



x1=

10m²



59,5x59,5
cm



x2

LED

27.2 W

3900
LUMEN

360°



Figure 5: Visual summary of key product specifications, including coverage area, dimensions, power, and light output.



9. WARRANTY AND SUPPORT




The INSPIRE LED Panel ANVIK is designed for durability and reparability, indicating a commitment to product longevity. For specific warranty terms and conditions, please refer to the product packaging or contact your retailer. For technical assistance, troubleshooting beyond this manual, or to inquire about replacement parts for reparable components, please contact INSPIRE customer support. Keep your purchase receipt and product model information (ANVIK, Model Number: 3276007230307) ready when contacting support. You can find more information about INSPIRE products and support on the official INSPIRE store page[INSPIRE Store](#).



© 2024 INSPIRE. All rights reserved.
This manual is subject to change without notice.

Related Documents - ANVIK

	<p>SITIO Ceiling Light - Installation and Assembly Guide</p> <p>Comprehensive guide for installing and using the SITIO ceiling light by Inspire. Features step-by-step assembly instructions, technical specifications, wiring details, and recycling information.</p>
	<p>Inspire MODICA LED Ceiling Light - CCT Dimmable, 40cm White</p> <p>SEO optimized description for Inspire MODICA LED Ceiling Light. This document provides assembly instructions and usage details for the CCT dimmable, 40cm diameter white ceiling light by Inspire.</p>
	<p>Inspire Sleep App Guide for Model 2580 Remote</p> <p>A comprehensive guide to using the Inspire Sleep App and Model 2580 Sleep Remote for managing sleep apnea therapy, connecting with healthcare providers, and tracking sleep progress. Includes setup, features, and troubleshooting.</p>

	<p>Inspire Sleep App User Guide</p> <p>This guide provides detailed instructions for using the Inspire Sleep App with the Inspire Sleep Remote Model 2580. Learn how to set up the app, connect your remote, track sleep therapy, manage your care team, and access resources.</p>
	<p>Inspire Remote FAQs: Troubleshooting and Usage Guide</p> <p>Find answers to common questions about the Inspire remote, including connection issues, therapy status, battery replacement, and troubleshooting for the Inspire implantable sleep apnea system. Learn how to use your Inspire remote effectively.</p>
	<p>INSPIRE Gdansk LED Panel Light: Installation, Safety, and Specifications Guide</p> <p>This comprehensive guide provides essential information for the INSPIRE Gdansk LED Panel Light, covering detailed installation steps, crucial safety precautions, technical specifications, and warranty details. Learn how to safely and effectively install and use your INSPIRE lighting solution.</p>