



[Manuals.plus](#) /

› [HAPPYGRILL](#) /

› HAPPYGRILL 96 Gallon PE Wicker Outdoor Rattan Deck Box Instruction Manual

HAPPYGRILL B0C46G2PW7

HAPPYGRILL 96 Gallon PE Wicker Outdoor Rattan Deck Box Instruction Manual

Model: B0C46G2PW7

1. INTRODUCTION

Thank you for choosing the HAPPYGRILL 96 Gallon PE Wicker Outdoor Rattan Deck Box. This versatile storage solution is designed to enhance your outdoor living space, providing ample storage and serving as a functional surface. This manual contains important information regarding the assembly, operation, and maintenance of your new deck box. Please read it thoroughly before use and retain it for future reference.



Image 1.1: The HAPPYGRILL deck box functioning as a coffee table on a patio.

2. SAFETY INFORMATION

- Ensure all parts are securely fastened before using the deck box.
- Do not allow children to climb on or play inside the deck box to prevent entrapment or injury.
- Do not exceed the maximum weight recommendation of 125 pounds on the lid.
- Keep hands clear of the lid when closing to avoid pinching, even with the gas struts.
- Place the deck box on a flat, stable surface to prevent tipping.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Deck Box Panels (PE Rattan and Metal Frame)
- Lid Assembly with Gas Struts
- Waterproof Liner

- PP Board (for base support)
- 4 Wheels (2 lockable)
- Assembly Hardware (screws, bolts, Allen wrench)
- Instruction Manual

4. SETUP AND ASSEMBLY

Assembly is required for this product. Follow these general steps. Refer to the included detailed instruction sheet for specific diagrams and part identification.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Frame:** Connect the side and front/back panels using the provided hardware. *Important: Do not fully tighten screws until all holes are aligned. This prevents misalignment and ensures proper fit.*
3. **Install Base:** Place the PP board at the bottom of the assembled frame to create a stable base.
4. **Attach Wheels:** Secure the four wheels to the designated points on the bottom of the deck box. Ensure the two lockable wheels are positioned as desired for accessibility.
5. **Insert Liner:** Place the waterproof liner inside the deck box, ensuring it fits snugly along the interior walls and base.
6. **Attach Lid:** Secure the lid to the main body using the hinge mechanism. Install the gas struts according to the instructions to allow for smooth opening and closing.
7. **Final Tightening:** Once all parts are correctly aligned, fully tighten all screws and bolts.

High-quality Gas Strut

- ✓ Smooth opening and closing
- ✓ Prevent hands from pinching



Stable



Child-friendly




Image 4.1: Dimensions and a crucial assembly note: Do not tighten screws until all holes are aligned.

5. OPERATING INSTRUCTIONS

5.1 Storage Function

The deck box offers a generous 96-gallon capacity, ideal for storing various outdoor items.

- **Capacity:** The internal dimensions are 51" L x 20.5" W x 21" H, capable of holding items such as patio cushions, blankets, garden tools, pool accessories, and sports equipment.
- **Waterproof Liner:** The included liner helps keep stored items dry and protected from moisture. Ensure the liner is properly seated within the box.



Image 5.1: The deck box provides ample space for garden tools and other outdoor essentials.



Image 5.2: The deck box can comfortably store multiple patio cushions and blankets.

5.2 2-in-1 Multifunctional Design

This deck box is designed for dual functionality:

- **Storage Box:** Use it to store your outdoor items as described above.
- **Coffee Table/Side Table:** When the lid is closed, the flat top surface can be used to hold drinks, snacks, books, or other small items, serving as a convenient outdoor table.

Multifunctional Design




Image 5.3: Demonstrating the deck box's dual function as both a storage unit and a side table.

5.3 Gas Strut Operation

The lid is equipped with gas struts for smooth and controlled opening and closing. This feature prevents the lid from slamming shut and reduces the risk of pinching fingers.

- To open, gently lift the lid. The gas struts will assist in raising and holding it open.
- To close, gently pull the lid down. The struts will provide resistance for a soft closure.



- Please do not tighten all the screws until all the holes are aligned
- Please refer to the size instructions before purchasing to avoid unnecessary trouble
- Please do not let the product get wet to prolong the service time

Image 5.4: Detail of the high-quality gas strut ensuring stable and child-friendly lid operation.

5.4 Mobility and Stability

The deck box features four smooth-rolling casters for easy repositioning. Two of these wheels are lockable to ensure stability when the box is in its desired location.

- To move the box, unlock the two lockable wheels.
- To secure the box in place, engage the locks on the two lockable wheels.


6. MAINTENANCE

Proper care will extend the life and appearance of your HAPPYGRILL deck box.


- **Cleaning:** The PE rattan surface is smooth and breathable, making it easy to clean. Wipe down the exterior with a soft cloth dampened with mild soap and water. Rinse thoroughly and dry completely.
- **Liner Care:** Periodically check the waterproof liner for any tears or damage. Clean the liner as needed.
- **Weather Protection:** The PE rattan is weather-resistant and sun-protective. However, to prolong the service life of the product, it is recommended to cover the deck box during prolonged periods of harsh weather conditions (e.g., heavy rain, snow, extreme sun) or store it in a sheltered area.

- **Hardware Check:** Periodically inspect all screws and bolts to ensure they remain tight. Tighten if necessary.


More Details



Hand-woven Mix
Brown PE Wicker



Sturdy Construction



Removable
Waterproof Liner

Image 6.1: Details of the hand-woven PE wicker, sturdy construction, and removable waterproof liner, highlighting key features for maintenance.

7. TROUBLESHOOTING

- **Parts Not Aligning During Assembly:** If you encounter difficulty aligning holes, loosen all previously tightened screws slightly. Once all parts are in place, then proceed to fully tighten them.
- **Lid Not Opening/Closing Smoothly:** Check that the gas struts are correctly installed and not obstructed. Ensure hinges are free of debris.
- **Water Inside the Box:** Verify that the waterproof liner is correctly installed and free of damage. Ensure the lid is fully closed and sealed. Avoid placing the box in areas where water can pool excessively around the base.
- **Box Not Stable:** Ensure the two lockable wheels are engaged. Check that the box is placed on a level surface.

8. SPECIFICATIONS

Brand	HAPPYGRILL
Model Number	B0C46G2PW7
Color	Mix Brown
Material	PE Rattan, Metal, Polypropylene (PP Board), Polyester (Liner)
Overall Dimensions (L x W x H)	52" x 22" x 25"
Inner Dimensions (L x W x H)	51" x 20.5" x 21"
Capacity	96 Gallons
Item Weight	35 Pounds
Maximum Lid Weight Recommendation	125 Pounds
Special Features	Lockable Wheels, Gas Struts, Waterproof Liner, 2-in-1 Design
Recommended Use	Outdoor

9. WARRANTY AND SUPPORT

For any questions, concerns, or assistance with your HAPPYGRILL product, please contact our customer support team. While specific warranty details are not provided in this manual, please refer to your purchase documentation or the retailer's website for warranty information.

Customer Support: Please visit the HAPPYGRILL store page on Amazon or contact the seller directly for support.

We are committed to providing high-quality products and excellent customer service.