

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Remax](#) /
- › [REMAX RP3 Digital Voice Recorder 16GB Built-in Memory and Playback User Manual](#)

Remax RP3

REMAX RP3 Digital Voice Recorder User Manual

Model: RP3 | Brand: Remax

1. INTRODUCTION

Thank you for choosing the REMAX RP3 Digital Voice Recorder. This device is designed for high-quality audio recording and playback, featuring 16GB of built-in memory. It serves as both a professional voice recorder and a portable MP3 player, making it ideal for lectures, meetings, interviews, and personal notes. Please read this manual carefully to understand the device's functions and ensure proper operation.

2. PRODUCT OVERVIEW

The REMAX RP3 boasts a sleek, portable design with intuitive controls. It features a clear display, a sensitive built-in microphone, and high-fidelity speakers for on-site playback. Its robust internal components ensure clear, noise-reduced recordings.





Front view of the REMAX RP3 Digital Voice Recorder, showing its display, recording indicator, and control buttons.

3. SETUP

3.1. Charging the Device

Before first use, fully charge the device. Connect the REMAX RP3 to a computer's USB port or a standard USB wall adapter using the provided USB cable. The charging indicator will show the charging status. A full charge typically takes approximately 2.5 hours and provides up to 30 hours of battery life.

3.2. Initial Power On/Off

To power on the device, press and hold the Power button until the screen illuminates. To power off, press and hold the Power button again until the screen turns off.

4. OPERATING INSTRUCTIONS

4.1. Basic Controls

- **Record Button:** Press to start/stop recording.
- **Play/Pause Button:** Press to play or pause recordings/music.
- **Volume Buttons (+/-):** Adjust playback volume.
- **Menu Button:** Access settings and options.
- **Navigation Buttons:** Move through menus and files.

4.2. Recording Audio

The REMAX RP3 supports one-key recording and voice-activated recording (VOR). Ensure the device is powered on.

1. To start recording, simply press the **Record** button. The recording indicator will illuminate.
2. To stop recording, press the **Record** button again. The recording will be saved automatically.
3. For Voice Activated Recording (VOR), enable the feature in the device's settings. Recording will automatically start when sound is detected and pause during silence.

EASY TO USE


One-key Recording and Voice Activated Recording
A-B Repeat Play
Easy File Management




A hand demonstrating the ease of use of the REMAX RP3, highlighting one-key recording and voice-activated recording features.

GOOD-QUALITY RECORDING

New Digital Signal
Large Memory Voice Recorder
New updated slimmer design




1536KBPS

Internal view of the REMAX RP3's digital signal processing chip, illustrating its good-quality recording capabilities at 1536KBPS.

4.3. Playback

The REMAX RP3 features built-in HD speakers for clear on-site playback. You can also connect 3.5mm headphones for private listening.

1. Navigate to the file you wish to play using the navigation buttons.
2. Press the **Play/Pause** button to start playback.
3. Use the **Volume** buttons to adjust the sound level.
4. The device supports A-B repeat play, allowing you to loop a specific section of an audio file.

BUILT-IN HD SPEAKERS

High-fidelity loudspeakers have shocking sound quality, restore sound quality on site



HD Loudspeaker



Volume Adjustment



On-Site Playback




Diagram showing the REMAX RP3's built-in HD loudspeakers, emphasizing high-fidelity sound quality and on-site playback.

4.4. File Management

To manage your recorded files, connect the REMAX RP3 to your computer using the USB cable. The device will appear as a removable disk. You can then transfer, copy, or delete files as needed. The device supports easy file management.

4.5. Using as MP3 Player

The REMAX RP3 can also function as an MP3 player. Transfer your MP3 or WAV audio files to the device's memory via USB connection. You can then navigate and play these files using the device's controls.

ONE MACHINE AND TWO USES

Recording at MP3/WAV

Recording Clear and Long time, Up to 90000S



Two REMAX RP3 devices, illustrating its dual functionality as both a voice recorder and an MP3 player, capable of recording in MP3/WAV formats.

5. MAINTENANCE

- Keep the device dry. Avoid exposure to water or excessive humidity.
- Clean the device with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- Avoid dropping the device or subjecting it to strong impacts.
- Store the device in a cool, dry place away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Device does not turn on.	Low battery; device frozen.	Charge the device; perform a reset (refer to manual for specific reset instructions if available, otherwise hold power button for extended period).
Cannot record.	Memory full; incorrect settings.	Delete old files to free up space; check recording settings.
Poor sound quality.	Microphone obstructed; recording environment too noisy.	Ensure microphone is clear; record in a quieter environment.
Device not recognized by computer.	Faulty USB cable/port; driver issue.	Try a different USB cable or port; restart computer and device.

7. SPECIFICATIONS

Feature	Detail
Model Number	RP3
Brand Name	Remax
Memory Storage Capacity	16 GB
Battery Life	30 Hours
Charging Time	Approx. 2.5 Hours
Screen Size	2 inches
Item Weight	0.12 Kilograms
Microphone Form Factor	Built-In
Headphones Jack	3.5 millimeters
Hardware Interface	USB
Compatible Devices	MP3 Player
Format	Digital (MP3/WAV)
Language	English
Date First Available	11 December 2024

8. WARRANTY AND SUPPORT

Specific warranty details for the REMAX RP3 Digital Voice Recorder are not provided in this manual. For information

regarding warranty coverage, technical support, or service, please contact Remax customer support directly or refer to the warranty card included with your purchase. You may also visit the official Remax website for further assistance.



© 2024 Remax. All rights reserved.