Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Sharp /
- Sharp SPC5026AMZ Digital Alarm Clock User Manual

Sharp SPC5026AMZ

Sharp SPC5026AMZ Digital Alarm Clock User Manual

Model: SPC5026AMZ

Introduction

Package Contents

Setup

Operating Instructions

Features Overview

Maintenance

Troubleshooting

Specifications

Warranty & Support

1. Introduction

This manual provides instructions for the setup, operation, and maintenance of your Sharp SPC5026AMZ Digital Alarm Clock. Please read this manual thoroughly before using the device to ensure proper function and longevity.



Figure 1: Front view of the Sharp SPC5026AMZ Digital Alarm Clock, displaying time, alarm, date, and indoor temperature.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- Sharp SPC5026AMZ Digital Alarm Clock
- User Manual (this document)

Note: 3 x AAA batteries are required for operation and are not included in the package.

3. SETUP

3.1 Battery Installation

- 1. Locate the battery compartment cover on the back of the clock.
- 2. Remove the cover by sliding it downwards or lifting it.
- 3. Insert three (3) new AAA batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
- 4. Replace the battery compartment cover.

The clock will power on automatically after battery installation.




Figure 2: Rear panel of the clock, showing the battery compartment and control buttons.

4. OPERATING INSTRUCTIONS

Refer to Figure 2 for button locations on the back of the clock.

4.1 Setting Time and Date

- 1. Slide the ALARM / DATE / TIME SETTING SWITCH to the TIME position.
- 2. Press the HOUR / MONTH SELECTION BUTTON to adjust the hour.
- 3. Press the MIN / DATE / °C/°F SELECTION BUTTON to adjust the minute.
- Press the 12/24 HR TIME YEAR SELECTION BUTTON to toggle between 12-hour and 24-hour format.
- 5. Slide the ALARM / DATE / TIME SETTING SWITCH to the DATE position.
- 6. Press the HOUR / MONTH SELECTION BUTTON to adjust the month.
- 7. Press the MIN / DATE / °C/°F SELECTION BUTTON to adjust the date.
- 8. Press the 12/24 HR TIME YEAR SELECTION BUTTON to adjust the year.
- Once time and date are set, slide the ALARM / DATE / TIME SETTING SWITCHback to the RUN position.

4.2 Setting the Alarm

- 1. Slide the ALARM / DATE / TIME SETTING SWITCH to the ALARM position.
- 2. Press the HOUR / MONTH SELECTION BUTTON to adjust the alarm hour.
- 3. Press the MIN / DATE / °C/°F SELECTION BUTTON to adjust the alarm minute.
- Slide the ALARM ON/OFF SWITCH to ON to activate the alarm. An alarm icon will appear on the display.
- 5. To deactivate the alarm, slide the **ALARM ON/OFF SWITCH** to **OFF**. The alarm icon will disappear.
- 6. Once the alarm is set, slide the ALARM / DATE / TIME SETTING SWITCHback to the RUN position.

4.3 Snooze Function

When the alarm sounds, press the large **SNOOZE** / **LIGHT** button on the top of the clock. The alarm will pause for approximately 9 minutes before sounding again.

4.4 Nightlight and Backlight

The clock features two illumination options:

- Built-in Display Nightlight: Slide the LOW LIGHT NIGHTTIME VIEWING BACKLIGHT ON/OFF SWITCH on the back of the clock toON for a continuous, low-level illumination of the display. Slide to OFF to disable.
- On-Demand White Backlight: Press the large SNOOZE / LIGHT button on the top of the clock for 5 seconds of bright white backlight. This is useful for quick viewing in dark conditions.



Figure 3: Visual representation of the display nightlight function in different lighting conditions.

4.5 Temperature Display

The clock displays the indoor temperature in either Celsius (°C) or Fahrenheit (°F). To switch between units, press the MIN / DATE / °C/°F SELECTION BUTTON while the ALARM / DATE / TIME SETTING SWITCH is in the RUN position.

5. FEATURES OVERVIEW

The Sharp SPC5026AMZ Digital Alarm Clock offers several convenient features:

- Large 2.8" LCD Display for easy readability.
- Selectable 12/24 Hour Time Format.
- Integrated Calendar Display (Month/Date/Year).
- Indoor Temperature Display (°C/°F).
- · Ascending Alarm Volume.
- 9-Minute Snooze Function.
- Built-in Display Nightlight (continuous low light).
- On-Demand Bright White Backlight.

• Battery Operated for portability (3 x AAA batteries).



Figure 4: Pictorial representation of key features.

6. MAINTENANCE

6.1 Cleaning

Wipe the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the surface.

6.2 Battery Replacement

Replace batteries when the display becomes dim or the clock functions erratically. Always replace all three batteries simultaneously with new AAA batteries. Remove batteries if the clock will not be used for an extended period to prevent leakage.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock display is blank or dim.	Batteries are low or incorrectly installed.	Replace with new AAA batteries, ensuring correct polarity.
Alarm does not sound.	Alarm is not activated or set incorrectly.	Ensure the ALARM ON/OFF SWITCH is set to ON and the alarm time is correctly set.
Nightlight is not working.	LOW LIGHT NIGHTTIME VIEWING BACKLIGHT ON/OFF SWITCH is OFF.	Slide the LOW LIGHT NIGHTTIME VIEWING BACKLIGHT ON/OFF SWITCH to ON.
Incorrect time or date displayed.	Time/date was not set correctly or batteries were removed.	Re-set the time and date following the instructions in Section 4.1.

8. SPECIFICATIONS

• Model: SPC5026AMZ

• Display Type: Digital LCD

• Display Size: 2.8 inches (Jumbo)

• Power Source: 3 x AAA Batteries (not included)

• **Dimensions (L x W x H):** 6.3" x 1.5" x 3.6" (approximate)

• Weight: 8.47 ounces

• Features: Alarm, Snooze, Calendar, Indoor Temperature, Nightlight, On-Demand Backlight

Material: PlasticColor: Black

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official Sharp website or contact their customer service department. Keep your purchase receipt as proof of purchase.

Online Support: www.sharpusa.com/support

Contact: Refer to the Sharp website for regional contact information.

© 2024 Sharp. All rights reserved. Sharp is a registered trademark.

Related Documents - SPC5026AMZ



SHARP SPC483/SPC222 LCD Digital Alarm Clock User Manual

User manual providing instructions for setting up and operating the SHARP SPC483 and SPC222 LCD Digital Alarm Clocks, including features, power, care, and FCC compliance.



SHARP SPC500 LCD Digital Alarm Clock User Manual and Instructions

Official user manual and instructions for the SHARP SPC500 LCD Digital Alarm Clock. Learn how to set the time, set the alarm, use the snooze and backlight features, and understand power supply and battery warnings. Includes FCC information.



SHARP Atomic Wall Clock User Manual and Warranty

Comprehensive user manual for the SHARP Atomic Wall Clock, model SPC1107, detailing setup, features, atomic time synchronization via WWVB, troubleshooting, battery replacement, and warranty information. Learn how to set time zones, use the remote sensor, and optimize signal reception for accurate time and temperature display.



SHARP SPC276 Digital Alarm Clock with Bluetooth & Sleep Sounds User Manual

Comprehensive user manual for the SHARP SPC276 Digital Alarm Clock, detailing features like Bluetooth connectivity, sleep sounds, alarm functions, dimmer, and sleep timer. Includes setup, operation, safety instructions, and warranty information.



Sharp C8318A Wireless Thermo Clock User Instructions

Comprehensive user manual for the Sharp C8318A Wireless Thermo Clock (SPC900). Provides detailed instructions on setup, features, operation, specifications, alarm functions, time synchronization, and warranty information for this radio-controlled weather station.



SPC268 Sunrise Alarm Clock with USB Port: Instruction Manual & Warranty

Official instruction manual and warranty information for the SHARP SPC268 Sunrise Alarm Clock with USB Port. Learn how to set the clock, alarms, use the sunrise and color-changing lights, and understand safety precautions.