Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tefal FV 5737

Tefal Iron FV5737 Easygliss Plus (FV5737E0)

USER MANUAL

1. Introduction

Welcome to the user manual for your new Tefal Iron FV5737 Easygliss Plus. This manual provides essential information for the safe and efficient use of your appliance. Please read these instructions carefully before using the iron and keep them for future reference.

2. Safety Instructions

Always observe the following safety precautions when using your iron:

- Ensure the voltage indicated on the iron's rating plate corresponds to your mains voltage.
- Never leave the iron unattended when it is switched on or connected to the mains.
- Keep the iron and its cord out of reach of children and pets when it is switched on or cooling down.
- Do not immerse the iron, its cord, or plug in water or any other liquid.
- Always unplug the iron from the mains socket before filling with water, emptying, or cleaning, and after each use.
- Do not operate the iron if it has been dropped, if there are visible signs of damage, or if it is leaking.
- Use the iron only for its intended purpose, which is ironing clothes.
- The iron must be used and rested on a stable, heat-resistant surface.
- Do not allow the power cord to come into contact with the hot soleplate.

3. Product Overview

Familiarize yourself with the components of your Tefal Easygliss Plus iron:



Figure 3.1: Front view of the Tefal Iron FV5737 Easygliss Plus, showing the handle, water tank, and soleplate.

This image displays the overall design of the iron, highlighting its ergonomic handle and the transparent water tank, which allows for easy monitoring of water levels. The soleplate is visible at the front.



Figure 3.2: Side view of the Tefal Iron FV5737 Easygliss Plus, showcasing the Durilium Airglide soleplate.

This side view emphasizes the unique shape of the Durilium Airglide soleplate, designed for smooth gliding over fabrics. The steam vents are clearly visible on the soleplate.






Figure 3.3: Close-up view of the Durilium Airglide soleplate with steam vents.

A detailed view of the soleplate, illustrating the distribution of steam holes for efficient steam delivery and the advanced Durilium Airglide technology for effortless ironing.



Figure 3.4: The iron in operation, demonstrating powerful steam output.

This image shows the iron actively producing steam, highlighting its capability for effective wrinkle removal. The steam is visibly emanating from the soleplate.



Figure 3.5: Visual representation of the iron's smooth gliding motion.

An artistic representation of the iron's smooth movement, emphasizing the ease of use provided by the Durilium Airglide soleplate technology.



Figure 3.6: The iron positioned on an ironing board, ready for use.

This image shows the iron set up on an ironing board alongside various garments, demonstrating a typical ironing scenario.

---

4. Setup

1. **First Use:** Before first use, remove any stickers or protective film from the soleplate. It is normal for a small amount of smoke or odor to be produced during the first few minutes of use. This will quickly disappear.
2. **Filling the Water Tank:**
    - Ensure the iron is unplugged from the mains.
    - Open the water filling inlet.
    - Fill the water tank with clean tap water up to the 'MAX' level indicator. Do not overfill.
    - Close the water filling inlet securely.
3. **Connecting to Power:** Plug the iron's power cord into a suitable grounded electrical outlet.

---

5. Operating Instructions

Follow these steps for effective ironing:

1. **Temperature Setting:** Turn the temperature dial to select the appropriate temperature for your fabric type. Refer to the fabric care labels on your garments. The iron will heat up, and the indicator light will turn off when the desired temperature is reached.
2. **Steam Ironing:** For steam ironing, ensure the water tank is filled and the temperature is set to the steam zone

(usually indicated on the dial).
    - **Continuous Steam:** Adjust the steam control slider to the desired steam level.
    - **Steam Boost:** Press the steam boost button for an extra burst of steam to tackle stubborn creases. Wait a few seconds between each burst.
3. **Dry Ironing:** For dry ironing, ensure the water tank is empty or the steam control slider is set to the 'no steam' position. Select the appropriate temperature.
4. **Vertical Steaming:** The iron can be used for vertical steaming of hanging garments or curtains. Hold the iron vertically a few centimeters away from the fabric and press the steam boost button.
5. **After Use:** Unplug the iron from the mains. Allow the iron to cool down completely before storing.

---

6. Maintenance and Cleaning

Regular maintenance ensures optimal performance and extends the life of your iron:

- **Emptying the Water Tank:** After each use, unplug the iron and empty any remaining water from the tank once the iron has cooled down.
- **Cleaning the Soleplate:**
    - Allow the soleplate to cool completely.
    - Wipe the soleplate with a damp cloth and a non-abrasive cleaner if necessary.
    - Do not use abrasive pads, scouring powders, or harsh chemicals as these can damage the soleplate.
- **Anti-Calc System (Self-Clean):** Your iron is equipped with an anti-calc system. Refer to the specific instructions for activating the self-clean function in the full product manual if available, or perform a self-clean cycle periodically to remove mineral deposits.
- **Storage:** Store the iron upright on its heel rest in a dry place, with the cord neatly wrapped.

---

7. Troubleshooting

If you encounter issues with your iron, consult the table below:

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outlet faulty; temperature dial set to minimum.	Check plug connection; test outlet with another appliance; turn temperature dial to desired setting.
No steam or insufficient steam.	Water tank empty; temperature too low for steam; steam control set to 'no steam'.	Fill water tank; set temperature to steam zone; adjust steam control slider.
Water leaks from soleplate.	Temperature too low for steam; water tank overfilled; iron not hot enough for steam.	Increase temperature and wait for indicator light to go out; do not overfill; allow iron to fully heat before using steam.
White flakes coming from soleplate.	Mineral deposits (limescale) in the water tank.	Perform the self-clean/anti-calc function as per manufacturer's instructions.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications

Feature	Detail
Brand	Tefal
Model Name	FV 5737
Special Feature	Easygliss Plus
Color	Turquoise
Base Material	Stainless Steel (Durilium Airglide Soleplate)
Voltage	220 Volts
Frequency	50 Hz
Product Dimensions	25.2 x 9.45 x 7.87 inches
Item Weight	3.5 pounds
Manufacturer	Tefal

9. Warranty and Support

Your Tefal Iron FV5737 Easygliss Plus is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.

For technical assistance, spare parts, or any questions not covered in this manual, please contact Tefal customer support. Contact information can typically be found on the official Tefal website or on your product packaging.

You can visit the official Tefal store for more information:T-Fal Store on Amazon.

© 2024 Tefal. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C48LQXL5

More documents and user manuals: **https://manuals.plus/**