T4TREAM ASC6DRSC-ROWAW

T4TREAM 6-Drawer Dresser Instruction Manual

Model: ASC6DRSC-ROWAW

Introduction

Thank you for choosing the T4TREAM 6-Drawer Dresser. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new furniture. Designed with a vintage aesthetic and robust construction, this dresser offers ample storage and complements various home decor styles.

Safety Information

WARNING: Furniture Tip-Over Hazard
Serious or fatal crushing injuries can occur from furniture tip-overs. To help prevent tip-over:

- Always install the tip-over restraint provided with the dresser.
- Never allow children to climb or hang on drawers, doors, or shelves.
- Never open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

For additional safety, ensure the dresser is placed on a flat, stable surface.



Figure 1: Anti-Tipping Design for enhanced safety. Always secure the dresser to the wall using the provided anti-tipping device to prevent accidents, especially in households with children.

Package Contents

Before beginning assembly, verify that all parts and hardware are present. If any items are missing or damaged, please contact T4TREAM customer support.

- Dresser components (panels, drawer fronts, etc.)
- Hardware pack (screws, cams, dowels, drawer slides, handles)
- Anti-tipping device kit
- Assembly instructions manual

Setup and Assembly

Assembly is required for this product. It is recommended to have two adults for assembly. Please follow the detailed

instructions provided in the included assembly guide. All parts and accessories are coded for precise and faster installation.

Tools Required (Not Included):

- Phillips head screwdriver
- Hammer (optional, for dowels)

Assembly Tips:

- Clear a spacious area for assembly.
- Lay out all components and hardware, organizing them by their labels.
- Do not overtighten screws to avoid damaging the wood.
- Refer to the visual diagrams in the separate assembly manual for step-by-step guidance.



Figure 2: Overall dimensions and individual drawer measurements for planning your space and storage.

Operating Instructions

The T4TREAM 6-Drawer Dresser is designed for convenient storage in bedrooms, living rooms, or hallways.

Drawer Usage:

- The 6 drawers slide easily on ball bearings, allowing for smooth opening and closing.
- The double-coated metal handles provide a comfortable grip for pulling and pushing drawers.
- The dresser features four larger drawers (26.5"W x 12"D x 6.3"H) and two smaller top drawers (11.5"W x 12"D x 4"H).

Weight Capacity:

- **Tabletop Weight Capacity:** 100 LBS
- **Drawers Weight Capacity:** 50 LBS per drawer

Distribute weight evenly within drawers and on the tabletop to maintain stability and prevent damage.




Figure 3: Examples of drawer capacity, illustrating how various clothing items can be neatly stored.

Maintenance

To keep your T4TREAM dresser in excellent condition, follow these simple care guidelines:

- **Cleaning:** Wipe with a dry cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Immediately wipe up any spills with a soft, dry cloth to prevent staining or water damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the wood finish.
- **Humidity:** Maintain a stable room temperature and humidity level to prevent wood warping or cracking.
- **Hardware:** Periodically check and tighten all hardware connections to ensure stability.



Figure 4: Details of the dresser's construction, including the durable tabletop and stable base, which benefit from proper care.

Troubleshooting

Problem	Possible Cause	Solution
Drawers stick or do not slide smoothly.	Misaligned drawer slides or debris in tracks.	Check that drawer slides are properly aligned and free of obstructions. Ensure all screws on the slides are tightened.
Dresser feels wobbly.	Loose hardware or uneven floor.	Tighten all assembly screws. If the floor is uneven, place shims under the dresser legs to stabilize it. Ensure the anti-tipping device is securely installed.
Missing parts during assembly.	Packaging error or overlooked parts.	Double-check all packaging materials. If parts are genuinely missing, contact T4TREAM customer support immediately.

Specifications

Feature	Detail
Brand	T4TREAM
Model Name	ASC6DRSC-ROWAW
Product Dimensions	16"D x 32"W x 48"H
Color	Antique White
Item Weight	105.8 Pounds
Mounting Type	Freestanding
Room Type	Bedroom, Living Room
Special Feature	Storage
Assembly Required	Yes
Material	FSC-Certified Wood
Tabletop Weight Capacity	100 LBS
Drawer Weight Capacity	50 LBS (each)

Warranty and Support

T4TREAM offers a limited warranty on this product. For specific details regarding warranty coverage, please refer to the documentation included with your purchase or contact customer support.
If you have any questions, require assistance with assembly, or encounter any issues with your T4TREAM dresser, please do not hesitate to contact our customer support team. We are committed to providing a satisfactory answer within 24 hours.
Contact Information: (Please refer to your purchase documentation or the T4TREAM official website for the most current contact details.)
You can also visit the official T4TREAM store for more products and information:T4TREAM Store

© 2025 T4TREAM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question