

[Manuals.plus](#) /

› [Yizosh](#) /

› Yizosh 72-inch Metal Storage Cabinet User Manual

## Yizosh 72HLC-1850

# Yizosh 72-inch Metal Storage Cabinet User Manual

Model: 72HLC-1850

## INTRODUCTION

---

Thank you for choosing the Yizosh 72-inch Metal Storage Cabinet. This cabinet is designed to provide secure and organized storage for various items in your garage, office, laundry room, or home. Constructed from durable alloy steel, it features two locking doors and four adjustable shelves to meet your specific storage needs. Please read this manual thoroughly before assembly and use to ensure proper installation and safe operation.



Figure 1: Yizosh 72-inch Metal Storage Cabinet (Model 72HLC-1850)

## SAFETY INFORMATION

---

Please observe the following safety precautions during assembly and use:

- Always assemble the cabinet on a flat, stable surface to prevent tipping.
  - Ensure all screws and fasteners are securely tightened before use.
  - Do not exceed the maximum weight limit of 140 pounds (63.5 kg) per shelf.
  - Distribute weight evenly on shelves to maintain stability.
  - Keep children and pets away from the assembly area.
  - For added stability, consider anchoring the cabinet to a wall, especially in areas prone to earthquakes or if heavy items are stored on upper shelves.
  - Use caution when moving the assembled cabinet; it is heavy and may require multiple people.
-

## PACKAGE CONTENTS

---

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Cabinet Panels (Top, Bottom, Sides, Back, Doors)
- Adjustable Shelves (4 included)
- Locking Mechanism with 2 Keys
- Handles
- Assembly Hardware (screws, bolts, nuts, etc.)
- Leveling Feet (optional installation)
- Instruction Manual

---

## SETUP AND ASSEMBLY

---

The Yizosh Metal Storage Cabinet requires assembly. It is recommended to have at least two people for assembly due to the size and weight of the components. A screwdriver is included, but a power drill may expedite the process.

1. **Prepare the Area:** Clear a spacious, flat, and clean area for assembly. Lay down a blanket or cardboard to protect the cabinet parts and your floor.
2. **Identify Parts:** Unpack all components and identify them using the provided parts list in the separate assembly instructions. Each part and fastener is typically labeled.
3. **Assemble the Frame:** Begin by attaching the side panels to the bottom panel, followed by the top panel. Ensure all connections are secure.
4. **Install Back Panel:** Secure the back panel to the assembled frame.
5. **Attach Doors:** Mount the two swing doors to the cabinet frame using the provided hinges. Ensure they open and close smoothly.
6. **Install Handles and Lock:** Attach the metal handles to the doors and install the locking mechanism. Test the lock with the provided keys.
7. **Insert Shelves:** Place the adjustable shelves into the desired positions. The cabinet features multiple slots for shelf height customization.
8. **Install Leveling Feet (Optional):** If your floor is uneven, attach the leveling feet to the bottom of the cabinet and adjust them to ensure stability. Access holes in the bottom shelf allow for adjustment without tipping the cabinet.



Figure 2: Assembling and organizing the cabinet shelves.

## OPERATING INSTRUCTIONS

---

### Adjusting Shelves

The cabinet comes with four adjustable shelves, allowing you to customize the storage space according to your needs. To adjust a shelf:

- Empty the shelf of all contents.
- Carefully lift the shelf and remove it from its current position.
- Align the shelf supports with the desired slots on the cabinet's side panels.
- Ensure the shelf is level and securely seated in all four supports before placing items on it.



Yizosh

# 5-Tier Adjustable



Books



Toys



Sundries



Tools

Figure 3: Shelf adjustment and versatile storage options.

## Locking and Unlocking

The cabinet is equipped with a high-quality lock to secure your valuables. Two keys are provided.

- To **lock** the cabinet, ensure both doors are fully closed. Insert a key into the lock cylinder and turn it clockwise until the lock indicator shows a locked position. Remove the key.
- To **unlock** the cabinet, insert a key into the lock cylinder and turn it counter-clockwise until the lock indicator shows an unlocked position. The doors can then be opened using the metal handles.
- The doors also feature magnetic stoppers to keep them closed when not locked.




Figure 4: Key features including metal handle, safety lock, adjustable shelf, and magnetic stopper.

## MAINTENANCE

To ensure the longevity and appearance of your Yizosh Metal Storage Cabinet, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the cabinet surfaces with a dry, soft cloth. For stubborn dirt, a slightly damp cloth with mild soap can be used, followed by immediate drying. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Inspection:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.
- **Shelf Load:** Always adhere to the maximum weight capacity per shelf (140 lbs / 63.5 kg) and distribute weight evenly to prevent warping or damage.
- **Lock Mechanism:** If the lock mechanism becomes stiff, a small amount of graphite lubricant can be applied to the keyhole.

## TROUBLESHOOTING

If you encounter any issues with your cabinet, refer to the following common problems and solutions:

- **Doors do not close properly:**
  - Check if the cabinet is level. Adjust the leveling feet if needed.
  - Ensure all assembly screws, especially those for the frame and hinges, are fully tightened.
  - Verify that no items inside the cabinet are obstructing the doors.
- **Shelves are wobbly:**
  - Ensure the shelf supports are fully seated in the corresponding slots on both sides.
  - Check that the cabinet itself is stable and level.
- **Lock mechanism is stiff or difficult to turn:**
  - Apply a small amount of graphite lubricant into the keyhole.
  - Ensure the key is fully inserted before turning.
- **Cabinet feels unstable:**
  - Confirm all assembly hardware is tightened.
  - Adjust the leveling feet to ensure all corners are firmly on the ground.
  - Consider anchoring the cabinet to a wall for maximum stability, especially if storing heavy items.

## SPECIFICATIONS

| Feature                | Detail                                                                    |
|------------------------|---------------------------------------------------------------------------|
| Model Number           | 72HLC-1850                                                                |
| Dimensions (H x W x D) | 71.8 inches x 35.4 inches x 17.7 inches (182.4 cm x 89.9 cm x 45 cm)      |
| Weight                 | 88.18 lbs (40 kg)                                                         |
| Material               | Alloy Steel (Cold-rolled steel plate)                                     |
| Color                  | Black                                                                     |
| Number of Doors        | 2 (Swing doors)                                                           |
| Number of Shelves      | 4 (Adjustable)                                                            |
| Shelf Weight Capacity  | 140 lbs (63.5 kg) per shelf                                               |
| Lockable               | Yes (with 2 keys included)                                                |
| Assembly Required      | Yes                                                                       |
| Special Features       | Magnetic door stoppers, Leveling feet, Anti-corrosion, Moisture-resistant |



Figure 5: Shelf thickness and load capacity details.

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact the retailer where the product was acquired. Keep your purchase receipt as proof of purchase. For further assistance, you may also visit the official Yizosh website or contact their customer service department directly. Contact details are typically found on the product packaging or the manufacturer's website.

