

Lamshaw 18mm Stretch Elastic Smart Watch Band

Lamshaw 18mm Stretch Elastic Smart Watch Band Instruction Manual

Model: 18mm Stretch Elastic Smart Watch Band

1. PRODUCT OVERVIEW

The Lamshaw 18mm Stretch Elastic Smart Watch Band is designed for comfort and compatibility with specific smart watch models. Crafted from high-quality, skin-friendly nylon, this band offers a breathable and lightweight wearing experience. Its single-layer pattern construction ensures durability and a secure fit.

Key Features:

- **Material:** Single-layer nylon and first-level cotton construction for skin-friendly, durable, breathable, and lightweight wear.
- **Design:** Elastic stretch bracelet style with multiple patterns available.
- **Adjustability:** Features an adjustable buckle for a customized fit.
- **Attachment:** Equipped with watch lugs on both ends for precise and secure attachment to your device.



Figure 1: Key features of the Lamshaw Stretch Elastic Watch Band, highlighting its breathable, lightweight, and soft nylon material.

2. COMPATIBILITY

This 18mm watch band is specifically designed to be compatible with the following smart watch models:

- Mindrose H80 1.47 inch Watch
- Wontrum Y70 Watch

Ensure your device matches these specifications for proper fit and function.



Figure 2: The watch band is compatible with Mindrose H80 1.47 inch and Wontrum Y70 watches.

3. SETUP AND INSTALLATION

The watch band features quick-release pins for easy installation and removal. Follow these steps to attach the band to your smart watch:

1. Locate the quick-release pin on the back of the watch band.
2. Align one end of the pin with the lug hole on your watch.
3. Push the quick-release lever inward to retract the pin, then slide the band into place between the watch lugs.
4. Release the lever, ensuring the pin snaps securely into the opposite lug hole. Gently tug on the band to confirm it is properly attached.
5. Repeat the process for the other half of the watch band.

Compatible with Model



Wontrum Y70 Watch



Mindrose H80 Watch

Figure 3: The watch band features quick-release pins for straightforward installation.

Video: Band Installation and Features

Your browser does not support the video tag.

Video 1: Demonstrates the installation process and highlights key features of the Lamshaw Smart Watch Band.

4. OPERATING AND ADJUSTMENT

The elastic design allows for comfortable wear, and the adjustable buckle provides a customizable fit for various wrist sizes. The band is suitable for wrist circumferences between 5.51 inches (140mm) and 9.06 inches (230mm).

Adjusting the Band:

1. Hold the adjustment buckle firmly.
2. Gently push or pull the strap through the buckle to achieve your desired tightness.
3. Ensure the band is snug but not overly tight to maintain comfort and proper sensor function for your smart watch.

HOW TO ADJUST



1 Hold the adjustment buckle and then push the strap into the adjustment buckle



2 Hold the adjustment buckle and then push the strap into the adjustment buckle



Breathable



Adjustable



Soft



Seamless

Figure 4: Step-by-step guide on how to adjust the elastic watch band for a comfortable fit.



Figure 5: The band fits wrist sizes from 5.51 to 9.06 inches (140mm to 230mm).

5. MAINTENANCE AND CARE

To ensure the longevity and cleanliness of your Lamshaw watch band, follow these care instructions:

- **Cleaning:** Hand wash the band with mild soap and cool water. Gently rub to remove dirt or sweat.
- **Drying:** Air dry the band completely before reattaching it to your watch. Avoid direct sunlight or high heat, which can damage the elastic material.
- **Avoid Harsh Chemicals:** Do not use strong detergents, bleach, or abrasive cleaners, as these can degrade the fabric and colors.
- **Storage:** Store the band in a clean, dry place when not in use.

6. TROUBLESHOOTING

If you encounter any issues with your watch band, consider the following common solutions:

- **Band feels loose or slides:** Re-adjust the buckle to a tighter setting. Ensure the strap is pulled through the buckle firmly. The elastic nature of the band may require occasional re-adjustment.
- **Difficulty attaching the band:** Ensure the quick-release pins are fully retracted when inserting the

band between the watch lugs. Verify that the pin ends align correctly with the lug holes before releasing the lever.

- **Skin irritation:** Ensure the band is clean and dry. If irritation persists, discontinue use and consult a healthcare professional. Ensure the band is not worn too tightly.

7. SPECIFICATIONS

Brand	Lamshaw
Model	18mm Stretch Elastic Smart Watch Band
Material	Nylon
Band Width	18mm
Clasp Type	Tang Buckle (Adjustable)
Wrist Size Compatibility	5.51" - 9.06" (140mm - 230mm)
Compatible Devices	Mindrose H80 1.47 inch Watch, Wontrum Y70 Watch

8. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the seller or manufacturer's official website. Keep your purchase receipt for any warranty claims.

Manufacturer: Lamshaw