

[Manuals.plus](#) /

› [PHI VILLA](#) /

› PHI VILLA 13-Piece Patio Furniture Set with 45-inch Fire Pit Table User Manual

PHI VILLA 13-Piece Patio Furniture Set with 45-inch Fire Pit Table

PHI VILLA 13-Piece Patio Furniture Set with 45-inch Fire Pit Table User Manual

Model: 13-Piece Patio Furniture Set with 45-inch Fire Pit Table | Brand: PHI VILLA

INTRODUCTION

This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your PHI VILLA 13-Piece Patio Furniture Set with 45-inch Fire Pit Table. Please read all instructions carefully before use and retain this manual for future reference.

IMPORTANT SAFETY INFORMATION

WARNING: Failure to follow these instructions could result in fire, explosion, or carbon monoxide poisoning, which could cause property damage, personal injury, or death.

- Always ensure the fire pit is placed on a level, non-combustible surface.
- Keep children and pets away from the fire pit during operation.
- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- Never leave the fire pit unattended when in use.
- Ensure proper ventilation when operating the fire pit.
- Turn off the propane supply at the tank when the fire pit is not in use.
- Do not attempt to repair or alter the appliance. Contact qualified service personnel for repairs.
- Keep the area around the fire pit clear and free from combustible materials, gasoline, and other flammable vapors and liquids.
- Always use the provided fire glass. Do not substitute with other materials.
- Allow the fire pit to cool completely before covering or moving.

SETUP AND ASSEMBLY

Assembly is required for this patio furniture set. Please follow the detailed instructions provided in the separate assembly guide included with your product. Ensure all components are present and undamaged before beginning assembly.

Fire Pit Table Assembly

The 45-inch fire pit table features a hidden storage compartment for the propane tank. This design ensures a clean aesthetic and keeps the tank safely out of sight.



Hidden propane tank storage

50,000 BTU Super Heat



Figure 1: Hidden propane tank storage compartment.

Connect the propane tank hose to the pre-installed ignition device located inside the fire pit table's storage area. Ensure all connections are secure to prevent leaks.



Figure 2: Fire pit burner with blue fire glass.

The fire pit comes with 11 lbs of blue fire glass. Carefully place the fire glass over the burner area, ensuring not to obstruct the igniter or burner holes.

Furniture Assembly

The sectional sofa pieces are designed for flexible arrangement. Seat clips are provided to connect the sofa pieces and prevent them from shifting during use, ensuring a stable and cohesive seating arrangement.



Figure 3: Example arrangement of the conversation set.

OPERATING INSTRUCTIONS

Fire Pit Operation

1. **Connect Propane Tank:** Ensure the propane tank is securely connected and the tank valve is open.
2. **Ignition:**
 - Locate the control knob on the side of the fire pit table.
 - Push and turn the control knob to the "LOW" position.
 - While holding the knob in, press the electronic igniter button repeatedly until the flame ignites. Hold the knob in for 15-45 seconds after ignition to ensure the thermocouple heats up and keeps the flame lit.
 - If the flame does not ignite after several attempts, release the knob, wait 5 minutes for gas to dissipate, and try again.
3. **Adjust Flame:** Once ignited, release the control knob. You can then rotate the knob to adjust the flame height from "LOW" to "HIGH" as desired.
4. **Manual Ignition (Backup):** If the electronic igniter fails, you can manually light the fire pit. With the propane tank valve open, push and turn the control knob to "LOW". Immediately use a long lighter or match to ignite the gas at the burner. Hold the knob in for 15-45 seconds after ignition.
5. **Shut Down:** To turn off the fire pit, turn the control knob to the "OFF" position. Then, close the valve on the propane tank.

Your browser does not support the video tag.

Video 1: Demonstration of fire pit operation, including propane tank connection and ignition.

Your browser does not support the video tag.

Video 2: Overview of the patio furniture set with fire pit in use.

Your browser does not support the video tag.

Video 3: Detailed view of the PHI VILLA Outdoor Wicker Furniture Set with Fire Pit.

CARE AND MAINTENANCE

General Cleaning

To maintain the appearance and longevity of your patio furniture set, wipe surfaces with a damp cloth as needed. Avoid harsh chemicals or abrasive cleaners.

Cushion Care

The sofa cushions are made from premium outdoor slub fabric, designed for durability, stain resistance, and fade resistance (rated for over 2000 hours in the sun). While water repellent, it is recommended to store cushions indoors during heavy rain or prolonged periods of non-use to extend their lifespan.



Figure 4: Water-repellent cushion fabric.

Rattan and Frame Care

The furniture is crafted from durable all-weather handwoven rattan wicker and a rust-proof steel frame. To clean the rattan, use a soft brush and mild soap solution, then rinse thoroughly with water. The frame can be wiped clean with a damp cloth.



Figure 5: Construction details of the rattan and frame.

Fire Pit Maintenance

Regularly inspect the fire pit burner and hose connections for any signs of damage or leaks. Keep the fire glass clean and free of debris. The removable lid on the fire pit table can be used to protect the burner area when not in use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Fire pit does not ignite electronically.	Propane tank valve closed. Low propane level. Igniter not sparking. Gas flow obstructed.	Open propane tank valve fully. Check propane tank level; replace if empty. Ensure igniter electrode is clean and properly positioned. Use manual ignition as a backup. Check hose for kinks or obstructions.
Low flame or inconsistent flame.	Low propane level. Partially closed propane tank valve. Burner holes obstructed.	Check propane tank level; replace if empty. Ensure propane tank valve is fully open. Clean burner holes of any debris or fire glass.
Gas odor detected.	Gas leak.	Immediately turn off propane supply at the tank. Do not operate the fire pit. Check all connections for leaks using a soapy water solution. Bubbles indicate a leak. If odor persists, contact emergency services or a qualified gas technician.

For further assistance or issues not covered here, please contact PHI VILLA customer support.

PRODUCT SPECIFICATIONS

- **Brand:** PHI VILLA
- **Model:** 13-Piece Patio Furniture Set with 45-inch Fire Pit Table
- **Material:** Rattan (all-weather handwoven), Rust-proof Steel Frame, High-density Foam Cushions, Tempered Glass (coffee table)
- **Fire Pit BTU:** 50,000 BTU
- **Fire Pit Certification:** CSA Certified
- **Fire Glass:** 11 lbs Blue Fire Glass included
- **Cushion Fabric:** Premium outdoor slub fabric (durable, stain-resistant, fade-resistant >2000 hours)
- **Assembly:** Required
- **Dimensions (Approximate):**
 - Corner Sofa: 29.5"L x 29.5"W x 25"H
 - Armless Sofa: 25.5"L x 29.5"W x 25"H
 - Fire Pit Table: 45"L x 23"W x 24.8"H
 - Coffee Table: 25.5"L x 25.5"W x 12.5"H

WARRANTY AND SUPPORT

For any questions, concerns, or assistance with your PHI VILLA patio furniture set, please contact our customer support team. While specific warranty details are not provided in this document, PHI VILLA is committed to customer satisfaction. Please refer to your purchase documentation or the PHI VILLA official website for detailed warranty information. You can contact us anytime for assistance with your PHI VILLA patio furniture set.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question