

SIBRILLE FLH-036-F2

LED Floor Lamp User Manual

Model: **FLH-036-F2** | Brand: **SIBRILLE**

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your SIBRILLE LED Floor Lamp. Please read this manual thoroughly before use to ensure proper function and safety.

SAFETY INFORMATION

- Ensure the power supply voltage matches the lamp's requirements (100-240V AC, 50/60Hz).
- Do not disassemble or modify the lamp.
- Keep the lamp away from water and high humidity environments. This product is not waterproof.
- Do not look directly into the LED light source for extended periods.
- Unplug the lamp from the power outlet before cleaning or performing any maintenance.
- The LED bulbs are non-replaceable. Do not attempt to replace them.

PACKAGE CONTENTS

Please verify that all components are present:

- LED Floor Lamp (main body with 3 rotatable lights)
- Lamp Base
- Remote Control (*Note: AAA batteries are not included for the remote control*)
- User Manual

ASSEMBLY INSTRUCTIONS

The SIBRILLE LED Floor Lamp is designed for quick and easy assembly, typically within 5 minutes, with no tools required.

1. Carefully unpack all components from the packaging.
2. Attach the lamp pole sections by screwing them clockwise until secure.
3. Screw the assembled lamp pole into the lamp base firmly.
4. Ensure all connections are tight and stable before plugging the lamp into a power outlet.



Figure 1: Fully assembled SIBRILLE LED Floor Lamp with its remote control.

Your browser does not support the video tag.

Video 1: Demonstration of the easy assembly process for the LED Floor Lamp.

OPERATING INSTRUCTIONS

Powering On/Off

Plug the lamp into a standard electrical outlet. The lamp can be turned on or off using either the touch control on the lamp pole or the remote control.

Remote Control Functions

The included remote control allows for convenient adjustment of the lamp's settings from a distance of up to 50 feet. Ensure AAA batteries are installed in the remote control.

- **ON/OFF Button:** Powers the lamp on or off.
- **Brightness +/-:** Adjusts the brightness level from 5% to 100%.
- **Color Temperature +/-:** Cycles through 4 color temperatures: 2700K (Warm White), 4000K (Natural White), 5000K (Cool White), and 6500K (Daylight White).
- **Individual Light Control (1, 2, 3 buttons):** Each of the three rotatable lights can be turned on/off independently.
- **Reading Mode:** Sets the lamp to an optimized brightness and color temperature for reading.
- **Sleeping Mode (Night Mode):** Activates a softer, lower light setting suitable for sleeping or relaxation.
- **1H Timer:** Sets the lamp to automatically turn off after 1 hour.
- **One Click Recovery (M button):** Restores the lamp to a default or previously saved setting.



Figure 2: Detailed functions of the remote control for the SIBRILLE LED Floor Lamp.

Your browser does not support the video tag.

Video 2: Overview of the 36W Modern Floor Lamp with Remote Control features.

Touch Control Functions

The lamp pole features touch-sensitive controls for direct adjustments:

- **Short Press:** Cycles through color temperatures (2700K - 4000K - 5000K - 6500K - OFF).
- **Long Press:** Activates continuously adjustable brightness (stepless dimming) from 5% to 100%.

Eye Caring

No strobe, no glare, prevent eye fatigue,
maintain uniform light frequency



Figure 3: Illustration of both touch control and remote control functionalities.

Adjustable Lamp Heads

Each of the three lamp heads can be independently adjusted to direct light precisely where needed:

- **350° Rotation:** Each lamp head can rotate horizontally up to 350 degrees.
- **180° Tilt:** Each lamp head can tilt vertically up to 180 degrees (up/down).

Flexible Lamp Heads

Control light up or down according your needs

180°
up/down adjustable



350°
rotation adjustable

Figure 4: Demonstration of the flexible and adjustable lamp heads.

Memory Function

The lamp features a memory function that remembers your last used brightness and color temperature settings when turned off and on again.

Versatile Applications

Your browser does not support the video tag.

Video 3: Examples of the lamp's wide application in various room settings.

MAINTENANCE

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe the lamp. Do not use abrasive cleaners or solvents.
- **Bulb Replacement:** The integrated LED bulbs are designed for long service life (approximately 50,000 hours) and

are non-replaceable.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Not plugged in; power outlet issue; loose connection.	Ensure the power cord is securely plugged into a working outlet. Check all lamp pole connections.
Remote control not working.	Batteries are dead or not installed; remote out of range; signal obstruction.	Install 2 AAA batteries (not included) or replace existing ones. Ensure remote is within 50 feet and has a clear line of sight to the lamp.
Light flickers or is unstable.	Loose connection; power fluctuation.	Check all connections. Try plugging the lamp into a different outlet. If the problem persists, contact customer support.
Cannot change color temperature or brightness.	Remote control issue (see above); touch control not responding.	Ensure remote batteries are fresh. For touch control, ensure your finger makes full contact with the sensor.

SPECIFICATIONS

Feature	Detail
Model	FLH-036-F2
Wattage	36W LED (equivalent to 360W incandescent)
Luminous Flux	Up to 2500 Lumens
Color Temperatures	2700K, 4000K, 5000K, 6500K
Brightness Adjustment	Stepless Dimmable (5% - 100%)
Control Method	Remote Control & Touch Control
Power Source	Corded Electric
Voltage	100-240V AC
Material	Plastic, Metal (Iron)
Product Dimensions	17.2"D x 13.19"W x 67"H (approx. 43.7cm D x 33.5cm W x 170cm H)
Item Weight	9.26 pounds (approx. 4.2 kg)
Average Life	50,000 Hours
Special Features	Adjustable Light Head, Dimmable, Individual Control, Memory Function, Timer

Dimension

Wattage: 36W Total (12W*3)

Luminous Flux: 2500 Lumen

Input Power Supply: 100–240V AC
50/60Hz

Color Temperature: 2700K–6500K

Luminous angle: 120°

Control Method: Remote Control/Touch

Dimmable: YES

Material: Iron + PC



Figure 5: Detailed dimensions and electrical specifications of the lamp.

WARRANTY AND SUPPORT

SIBRILLE offers a **2-year quality warranty** for this LED Floor Lamp. We also provide a **30-day return policy** for your satisfaction.

For any problems, suggestions, or support inquiries, please contact SIBRILLE customer service via Amazon. We are committed to providing prompt assistance and ensuring your satisfaction.

© 2025 SIBRILLE. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question