

Keurig K-Supreme SMART

Keurig K-Supreme SMART Single Serve Coffee Maker USER MANUAL

Introduction

The Keurig K-Supreme SMART Single Serve Coffee Maker offers a personalized brewing experience with its WiFi compatibility and advanced features. This manual provides essential information for setting up, operating, and maintaining your coffee maker and the accompanying 3-Month Brewer Maintenance Kit.



Image: The Keurig K-Supreme SMART coffee maker shown alongside the 3-Month Brewer Maintenance Kit, which includes descaling solution, water filter cartridges, and rinse pods.

Setup

Follow these steps to set up your Keurig K-Supreme SMART coffee maker for first use.

1. **Unpack the Brewer:** Remove all packaging materials from the brewer and its components. Place the brewer on a stable, level surface.
2. **Clean the Water Reservoir:** Wash the water reservoir and lid with warm, soapy water. Rinse thoroughly and dry.
3. **Fill the Water Reservoir:** Fill the reservoir with fresh, filtered water up to the MAX fill line.
4. **Power On:** Plug the brewer into a grounded outlet. The brewer will automatically power on.
5. **Initial Cleansing Brew:** Perform a cleansing brew without a K-Cup pod. Lift and lower the handle, select a large brew size (e.g., 10 oz), and press the brew button. Discard the hot water. Repeat this process once more.
6. **Connect to WiFi (Optional):** Download the Keurig app on your smartphone to connect your brewer to WiFi. This enables smart features like BrewID technology and remote brewing.





Image: The Keurig K-Supreme SMART coffee maker with its clear water reservoir on the left and a red mug positioned on the drip tray, ready for brewing.

Operating Instructions

Learn how to brew your favorite beverages and utilize the smart features of your Keurig K-Supreme SMART brewer.

Brewing a Beverage

1. **Place Mug:** Place a mug on the drip tray.
2. **Insert K-Cup Pod:** Lift the handle and insert a K-Cup pod into the K-Cup pod holder. Lower the handle completely to close the lid.
3. **Select Brew Settings:** The brewer's BrewID technology will recognize the K-Cup pod and suggest optimal brew settings. You can further customize by choosing from five strength settings, six temperature settings, and four cup sizes (6, 8, 10, 12 oz).
4. **Start Brewing:** Press the illuminated brew button. The brewing process will begin.
5. **Enjoy:** Once brewing is complete, carefully remove the K-Cup pod and discard it.

Key Technologies and Features

- **BrewID Technology:** This feature automatically recognizes the specific brand and roast of your K-Cup pod and adjusts brew settings for optimal flavor.
- **MultiStream Technology:** Water is saturated more evenly across the coffee grounds, extracting full flavor and aroma from your K-Cup pod.
- **Brew Over Ice:** For refreshing iced coffee, place a cup filled with ice on the drip tray, insert your K-Cup pod, and select the "Brew Over Ice" option (if available on your model or via app settings).
- **Connected Convenience:** Through the Keurig app, you can schedule brews, manage favorites, and receive personalized recommendations.

KEURIG® K-Supreme® SMART

SINGLE SERVE COFFEE MAKER



BrewID™

recognizes your K-Cup® pod and customizes the settings to make each cup distinctively delicious



ULTIMATE CUSTOMIZATION

5 strength, 6 temperature, 4 cup size, and brew ice settings



MULTISTREAM TECHNOLOGY™

saturates the coffee grounds more evenly* to extract full flavor and aroma

**vs. leading national Keurig® K-Classic® brewer*



CONNECTED CONVENIENCE

brew from anywhere, get personalized recommendations, manage your favorites



66 oz

dual-position reservoir



Image: The Keurig K-Supreme SMART coffee maker with visual callouts explaining its key features: BrewID, Ultimate Customization, MultiStream Technology, Connected Convenience, and the 66 oz dual-position reservoir.

Maintenance

Regular cleaning and maintenance are crucial for extending the life of your Keurig brewer and ensuring the best taste for your beverages. The 3-Month Brewer Maintenance Kit provides essential supplies for this.

Descaling Your Brewer

Descaling removes mineral buildup that can affect brewer performance and coffee taste. It is recommended to descale your brewer every 3 months or when the descale indicator light illuminates.

1. **Prepare Descaling Solution:** Pour the entire bottle of Keurig Descaling Solution into the empty water reservoir.
2. **Fill with Water:** Fill the empty descaling solution bottle with water and pour it into the reservoir. Do not use a K-Cup pod.
3. **Perform Descaling Brews:** Place a large mug on the drip tray. Lift and lower the handle. Select the largest brew size and press the brew button. Repeat this process until the "ADD WATER" light illuminates.
4. **Soak:** Let the brewer stand for at least 30 minutes while it is still powered on.

5. **Rinse Brews:** After soaking, discard any remaining solution from the reservoir and rinse it thoroughly. Fill the reservoir with fresh water. Perform at least 12 cleansing brews using the largest brew size, refilling the reservoir as needed, until the descaling solution is completely rinsed out.

Replacing Water Filter Cartridges

Replace your water filter cartridge every 2 months or 60 tank refills to ensure optimal water quality.

1. **Prepare Filter:** Soak a new water filter cartridge in fresh water for 5 minutes.
2. **Insert Filter:** Rinse the filter holder. Insert the new filter into the lower part of the filter holder. Snap the upper part of the filter holder over the filter.
3. **Place in Reservoir:** Place the assembled filter holder into the water reservoir, ensuring it is seated properly.

Using Keurig Rinse Pods

Rinse Pods help reduce flavor carry-over between brews and clean the K-Cup pod holder. Use them weekly or after brewing flavored beverages.

1. **Insert Rinse Pod:** Place a large mug on the drip tray. Insert a Keurig Rinse Pod into the K-Cup pod holder, just like a regular K-Cup pod.
2. **Brew:** Lower the handle and select the 8 oz brew size. Press the brew button.
3. **Discard:** Once brewing is complete, remove and discard the Rinse Pod.
4. **Final Rinse:** Perform one more 8 oz water-only brew to rinse the brewer.



Image: The components of the Keurig 3-Month Brewer Maintenance Kit, including a bottle of descaling solution, multiple rinse pods, and two water filter cartridges.

Troubleshooting

If you encounter issues with your Keurig K-Supreme SMART brewer, refer to the common problems and solutions below.

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Brewer not turning on	Not plugged in; power outage; circuit breaker tripped.	Ensure brewer is securely plugged into a working outlet. Check household circuit breaker.
No water dispensing	Water reservoir empty; air in lines; brewer needs descaling.	Fill reservoir. Perform a cleansing brew without a K-Cup pod. Descale the brewer if necessary.
Coffee tastes weak or watery	Incorrect brew size selected; K-Cup pod not properly pierced; brewer needs descaling.	Select a smaller brew size. Ensure K-Cup pod is fully seated and pierced. Descale the brewer.
"ADD WATER" light stays on after filling	Water level sensor issue; reservoir not seated correctly.	Remove and re-seat the water reservoir firmly. Ensure it is filled above the minimum line.
Brewer not connecting to WiFi	Incorrect WiFi password; out of range; network issues.	Verify WiFi password. Move brewer closer to router. Restart router and brewer. Consult Keurig app for specific connection steps.

Specifications

Detailed specifications for the Keurig K-Supreme SMART Single Serve Coffee Maker.

- **Brand:** Keurig
- **Model:** K-Supreme SMART
- **Color:** White
- **Coffee Maker Type:** Drip Coffee Machine, Single-Serve Brewer
- **Coffee Input Type:** K-Cup Pods
- **Water Reservoir Capacity:** 66 oz (Removable)
- **Brew Sizes:** 6, 8, 10, 12 oz
- **Special Features:** WiFi Compatibility, BrewID Technology, MultiStream Technology, Brew Over Ice, Strength Control, Temperature Control, Removable Tank, Water Filter
- **Included Components:** Keurig K-Supreme SMART Brewer, 3-Month Brewer Maintenance Kit (1 Descaling Solution, 2 Water Filter Cartridges, 4 Rinse Pods)
- **Operation Mode:** Fully Automatic
- **Human Interface Input:** Buttons
- **ASIN:** B0C4DC5C6X
- **First Available:** May 5, 2023

Warranty and Support

For specific warranty details and customer support, please refer to the documentation included with your product or visit the official Keurig website. Keurig provides support for product inquiries, troubleshooting, and warranty claims.

Online Support: www.keurig.com/support

Phone Support: Refer to your product packaging or the Keurig website for the most current contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question