

## Bayer Design 62633AB

# Bayer Design 62633AB Doll Play Center Instruction Manual

MODEL: 62633AB

## 1. INTRODUCTION

---

Thank you for choosing the Bayer Design 62633AB Doll Play Center. This multi-functional toy is designed to provide an engaging play experience, allowing children to care for their dolls with an integrated high chair, changing table, mobile, and storage compartment. Please read this manual carefully before assembly and use to ensure safe and proper operation.

## 2. SAFETY WARNINGS

---

- **WARNING:** Not suitable for children under 3 years due to small parts which may present a choking hazard.
- **WARNING:** For safety reasons, please remove all wires, plastic threads, elastic bands, labels, or other fastening materials from the toy before giving it to a child.
- This product is not intended for use by a real baby or child. It is a toy for dolls only.
- **WARNING:** Be aware of pinch points during folding and unfolding operations.
- **WARNING:** To be used only under adult supervision.
- Assembly and disassembly must be performed by an adult.

## 3. PACKAGE CONTENTS

---

Please ensure all components are present before beginning assembly:

- Doll Play Center Frame (main structure)
- Integrated High Chair with Tray
- Changing Table Surface
- Mobile Arm with Hanging Toys
- Doll Bedding (blanket and pillow)
- Storage Compartment (integrated)

## 4. ASSEMBLY INSTRUCTIONS

#### 4. ASSEMBLY INSTRUCTIONS

Adult assembly is required. Follow these general steps to set up your doll play center:

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Unfold Frame:** Extend the main frame of the doll play center until it locks securely into place. Ensure all locking mechanisms are engaged.
3. **Attach High Chair:** Secure the integrated high chair to its designated position on the frame. Ensure the tray is firmly attached.
4. **Install Mobile:** Insert the mobile arm into its slot on the frame. Hang the decorative toys onto the mobile arm.
5. **Prepare Changing Area:** Ensure the changing table surface is properly positioned and stable.
6. **Place Bedding:** Lay the provided blanket and pillow inside the doll bed area.



Figure 4.1: Front view of the assembled Bayer Design 62633AB Doll Play Center, showing the high chair, mobile, and bed area.



Figure 4.2: Side view of the doll play center, highlighting the mesh window on the side of the doll bed.

## 5. OPERATING INSTRUCTIONS

The Bayer Design 62633AB Doll Play Center offers multiple play functions:

### 5.1 Using the High Chair

Place your doll in the integrated high chair. The attached tray allows for pretend feeding scenarios. Ensure the doll is seated securely.

### 5.2 Using the Changing Table

The changing table area is located behind the high chair. Lay your doll on the changing surface for pretend diaper changes or dressing. The mobile can be positioned over this area to entertain the doll.



Figure 5.1: A child interacting with the mobile feature of the doll play center, which can be used to entertain dolls during play.

### 5.3 Storage Compartment

The play center includes a storage compartment, accessible via a Velcro closure. This space is ideal for keeping doll accessories, clothes, or other small toys organized.



Figure 5.2: A close-up view of the integrated storage compartment, showing its capacity for doll accessories.



Figure 5.3: A child demonstrating access to the storage compartment, which is secured with a Velcro closure.

#### **5.4 Doll Bed Area**

The main section of the play center serves as a comfortable bed for your doll. Use the provided bedding to ensure your doll has a cozy place to rest.



Figure 5.4: The doll play center shown with its included bedding, ready for a doll to rest.

## 6. CARE AND MAINTENANCE

- **Cleaning:** Wipe surfaces with a damp cloth and mild soap. Do not use abrasive cleaners.
- **Storage:** When not in use, the play center can be folded for compact storage. Ensure it is clean and dry before storing.
- **Inspection:** Regularly check for any loose parts, tears in fabric, or damage to the frame. Discontinue use if any damage is found.

## 7. TROUBLESHOOTING

- **Difficulty Assembling:** Ensure all parts are correctly oriented and that locking mechanisms are fully engaged. Refer to Section 4.
- **Instability:** Verify that the frame is fully extended and locked. Check that all connections are secure.
- **Missing Parts:** If any parts are missing upon opening, please contact customer support immediately.

## 8. SPECIFICATIONS

Feature	Detail
Model Number	62633AB
Dimensions (L x W x H)	14.5 x 57 x 36.5 cm (Product) / 68 x 33 x 72 cm (Approx. assembled)
Weight	1.63 kg
Recommended Age	36 months - 10 years
Main Material	Fabric, Metal
Color	Grey, Pink
Educational Value	Encourages role-play and imaginative play

## 9. WARRANTY AND SUPPORT

Bayer Design products are manufactured with quality and care. For any questions, concerns, or support needs regarding your Bayer Design 62633AB Doll Play Center, please contact Bayer Design customer service. Please retain your proof of purchase for warranty claims, if applicable. Specific warranty details may vary by region and retailer.