

[Manuals.plus](#) /

› [Pomya](#) /

› Pomya Mechanical Gaming Keyboard User Manual

Pomya Pomya4kgd6nvce2-14

Pomya Mechanical Gaming Keyboard User Manual

Model: Pomya4kgd6nvce2-14

INTRODUCTION

Thank you for purchasing the Pomya Mechanical Gaming Keyboard. This manual provides essential information for setting up, operating, and maintaining your new keyboard. Please read it thoroughly before use to ensure optimal performance and longevity of your device.



Figure 1: Pomya Mechanical Gaming Keyboard (Orange and Black)

This image displays the Pomya Mechanical Gaming Keyboard, featuring a striking design with orange and black keycaps. The keyboard is connected via a durable USB cable, ready for plug-and-play use with your computer.

PACKAGE CONTENTS

Ensure all items are present in the package:

- Pomya Mechanical Gaming Keyboard (87-key)
- USB Cable (integrated)
- Keycap Puller
- Spare Key Switches (if included)




Figure 2: Included Accessories - Key Switches and Keycap Puller

This image shows two blue mechanical key switches, which are spare components for the keyboard, and a metal keycap puller tool. These

accessories are provided for potential keycap or switch replacement and maintenance.

SETUP

1. **Unpack the Keyboard:** Carefully remove the keyboard and its accessories from the packaging.
2. **Connect to Computer:** Insert the USB connector of the keyboard cable into an available USB port on your PC or laptop.



Figure 3: USB Connector

This image provides a close-up view of the USB-A connector, which is used to connect the keyboard to your computer's USB port.

3. **Automatic Driver Installation:** The keyboard is plug-and-play. Your operating system will automatically detect and install the necessary drivers. This process may take a few moments.
4. **Verify Functionality:** Once installed, the keyboard is ready for use. Test key presses and backlight functionality.

Basic Operation

The Pomya Mechanical Gaming Keyboard features 87 standard keys and 12 multimedia keys for enhanced functionality.

Backlight Modes

The keyboard supports up to 9 different backlight modes, providing a customizable visual experience. Use the designated key combinations to cycle through these modes and adjust brightness.



Figure 4: Rainbow Backlighting in Operation

This image illustrates the keyboard's vibrant rainbow backlighting feature, showcasing the illuminated keys in a dark environment, highlighting its aesthetic appeal during use.

Multimedia Keys

Access multimedia functions using the **Fn** key in combination with the F-keys (F1-F12). Refer to the keycap legends for specific functions such as volume control, media playback, and more.

MAINTENANCE

- **Cleaning:** Regularly clean the keyboard to prevent dust and debris buildup. Use a soft brush or compressed air to remove particles between keys. For keycap surfaces, a slightly damp cloth can be used. Ensure the keyboard is disconnected before cleaning.
- **Keycap Removal:** If deep cleaning is required or if you wish to replace keycaps, use the provided keycap puller. Gently hook the puller onto the keycap and pull straight up.



Figure 5: Removing a Keycap

This close-up image demonstrates the removal of the ESC key from the keyboard, illustrating how keycaps can be detached for cleaning or replacement.

- **Storage:** When not in use for extended periods, store the keyboard in a dry, cool place away from direct sunlight.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Keyboard not responding	Loose USB connection, faulty USB port, driver issue.	Ensure USB cable is securely plugged in. Try a different USB port. Restart your computer.
Backlight not working	Backlight turned off, low brightness setting.	Press the backlight control keys (refer to keyboard legends) to turn on or adjust brightness.
Keys not registering	Debris under keycap, faulty switch.	Remove keycap and clean. If issue persists, the switch may need replacement (use spare switches if provided).

SPECIFICATIONS

Feature	Detail
Model Number	Pomya4kgd6nvce2-14
Number of Keys	87
Connectivity	Wired USB
Backlight Modes	9 (Rainbow Backlit)
Key Life	50 million keystrokes
Material	Acrylonitrile Butadiene Styrene (ABS)
Color	Orange Black
Compatible Devices	Laptop, PC
Item Weight	1.63 pounds
Package Dimensions	15.35 x 7.09 x 1.97 inches

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Pomya website or contact your retailer. Keep your purchase receipt as proof of purchase for warranty claims.

Manufacturer: Pomya

Date First Available: May 5, 2023

For further assistance, you may visit the [Pomya Store on Amazon](#).

© 2023 Pomya. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question