

[Manuals.plus](#) /

› [Harman Kardon](#) /

› Harman Kardon Aura Studio 4 - Bluetooth Home Speaker User Manual

Harman Kardon HKAURAS4BLKAM

Harman Kardon Aura Studio 4 - Bluetooth Home Speaker User Manual

Model: HKAURAS4BLKAM

1. PRODUCT OVERVIEW

The Harman Kardon Aura Studio 4 is a Bluetooth home speaker designed to deliver 360-degree audio with integrated ambient light effects. Its transparent dome and themed lighting enhance the listening experience. The speaker features distinct channels, dedicated amplifiers, and a 6-speaker array for clear sound reproduction, complemented by a 5.2-inch down-firing subwoofer for deep bass tones. It supports seamless wireless streaming from mobile devices and is constructed with recycled materials.





Figure 1.1: The Harman Kardon Aura Studio 4 speaker, showcasing its transparent dome and integrated lighting.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your product packaging:

- Aura Studio 4 Speaker
- Power Cable
- Quick Start Guide
- Safety Sheet
- Warranty Card



WHAT'S IN THE BOX

Figure 2.1: Illustration of the contents included in the Aura Studio 4 package.

3. SETUP GUIDE

3.1 Power Connection

Connect the provided power cable to the power input port on the back of the Aura Studio 4 speaker. Plug the other end of the power cable into a suitable wall outlet. The speaker will power on automatically or can be powered on using the power button.

3.2 Initial Bluetooth Pairing

1. Ensure the Aura Studio 4 is powered on.
2. On your mobile device (smartphone, tablet, etc.), enable Bluetooth.
3. Press the Bluetooth button on the Aura Studio 4 (usually indicated by a Bluetooth icon). The speaker will enter pairing mode, and its indicator light may flash.
4. On your device, search for available Bluetooth devices. Select "Harman Kardon Aura Studio 4" from the list.
5. Once connected, the speaker's indicator light will typically become solid, and you will hear an audible confirmation.



Figure 3.1: The Aura Studio 4 integrated into a home environment, ready for setup.

4. OPERATING INSTRUCTIONS

4.1 Basic Controls

Control	Function
Power Button	Press to turn the speaker On/Off.
Bluetooth Button	Press to enter Bluetooth pairing mode.
Volume + / -	Adjust the audio volume.
Lighting Effect Button	Cycle through different diamond-effect lighting themes.

4.2 Lighting Effects

The Aura Studio 4 features five distinct diamond-effect lighting presets that can be cycled through using the dedicated lighting button. These effects are designed to sync with your music, creating a dynamic visual experience.

AMBIENT LIGHTING

Unique diamond-effect lighting that dances to the music




Figure 4.1: The unique diamond-effect lighting of the Aura Studio 4.

4.3 Sound Performance

The speaker's 6-speaker array and 5.2-inch subwoofer provide clear, 360-degree sound with rich bass. For optimal audio experience, ensure the speaker is placed on a stable, flat surface away from obstructions.

SUPERIOR SOUND PERFORMANCE

Your music is reproduced with pinpoint accuracy, thanks to the speaker's distinct channels and dedicated amplifiers, reproducing every sonic detail with breathtaking clarity.



Dimension (H x W x D): 11.2" x 9.1" x 9.1"

Figure 4.2: The Aura Studio 4 delivers superior sound performance, complementing its design.

5. CARE AND MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior surfaces of the speaker. Avoid using abrasive cleaners, waxes, or solvents.
- **Placement:** Place the speaker on a stable, flat surface to prevent accidental falls. Ensure adequate ventilation around the speaker.
- **Environmental Conditions:** Avoid exposing the speaker to extreme temperatures, humidity, or direct sunlight. This product is not waterproof.
- **Storage:** If storing the speaker for an extended period, disconnect it from power and store it in a cool, dry place.

6. TROUBLESHOOTING

If you encounter issues with your Aura Studio 4, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
No Power	Power cable not properly connected; Power outlet issue.	Ensure power cable is securely connected to both speaker and outlet. Try a different outlet.
No Bluetooth Connection	Speaker not in pairing mode; Device Bluetooth off; Out of range.	Press Bluetooth button on speaker. Enable Bluetooth on device. Move device closer to speaker.
No Sound	Volume too low; Muted on device; Incorrect audio source.	Increase volume on speaker and device. Check device's audio output settings.
Distorted Sound	Volume too high; Poor audio source quality.	Lower volume. Try a different audio source or file.

7. TECHNICAL SPECIFICATIONS

Feature	Specification
Model Name	Aura Studio 4
Item Model Number	HKAURAS4BLKAM
Dimensions (D x W x H)	9.1"D x 9.1"W x 11.2"H
Item Weight	7.9 Pounds (3.58 kg)
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Speaker Type	Multimedia
Subwoofer Diameter	5.2 Inches
Speaker Maximum Output Power	100 Watts
Signal-to-Noise Ratio	80 dB
Power Source	Corded Electric
Is Waterproof	False
Manufacturer	Harman Kardon



Figure 7.1: Key dimensions of the Aura Studio 4 speaker.

8. WARRANTY AND SUPPORT

The Harman Kardon Aura Studio 4 comes with a limited warranty. Please refer to the included Warranty Card in your package for detailed terms and conditions, including coverage period and limitations.

For technical support, troubleshooting assistance, or warranty claims, please visit the official Harman Kardon support website or contact their customer service. Contact information can typically be found in the Quick Start Guide or on the manufacturer's website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question