

GreenForest L-Shaped Gaming Desk (B0C4GTZ2TJ)

GreenForest L-Shaped Gaming Desk 128cm Instruction Manual

Model: L-Shaped Gaming Desk (B0C4GTZ2TJ) | Brand: GreenForest

INTRODUCTION

Thank you for choosing the GreenForest L-Shaped Gaming Desk. This manual provides essential information for the safe assembly, proper operation, and effective maintenance of your new desk. Please read these instructions thoroughly before beginning assembly and retain them for future reference.

SAFETY INFORMATION

- Weight Limit:** Do not overload the table beyond 90 kg (approximately 198 lbs). Exceeding this limit may cause damage to the desk or lead to injury.
- Assembly:** Assemble the table carefully according to the provided instructions to ensure structural integrity and user safety. Incorrect assembly can result in instability.
- Placement:** Place the desk on a flat, stable surface to prevent wobbling.
- Maintenance:** Regularly check all screws and connections to ensure they remain tight. Retighten as necessary.
- Children:** Keep small parts away from children during assembly.

PRODUCT SPECIFICATIONS

Feature	Detail
Product Dimensions (L x W x H)	128 x 108 x 75 cm (50.4 x 42.5 x 29.5 inches)
Weight	19.34 kg (42.6 lbs)
Material Type	Metal frame, Engineered wood top
Color	Black
Item Shape	L-Shape
Assembly Required	Yes

Feature	Detail
Maximum Weight Capacity	90 kg (198 lbs)
Included Features	Integrated Monitor Stand, Cup Holder, Headphone Hook

PACKAGE CONTENTS

Before assembly, please ensure all components are present and undamaged. Refer to the separate parts list included in your packaging for exact quantities and identification. Typical contents include:

- Desk Panels (Main, Side, Monitor Stand)
- Metal Frame Components (Legs, Support Bars)
- Assembly Hardware (Screws, Bolts, Allen Wrench)
- Cup Holder
- Headphone Hook
- Instruction Manual (this document)

ASSEMBLY INSTRUCTIONS

Detailed assembly instructions and numbered components are provided in your product packaging. Please follow those instructions step-by-step. The following information highlights key features and considerations during assembly.

1. Understand Desk Dimensions

Familiarize yourself with the overall dimensions of the desk to plan your space effectively. The desk measures 128 cm (50.4 in) on the longer side and 108 cm (42.5 in) on the shorter side, with a height of 75 cm (29.5 in).



Image: Overall dimensions of the L-shaped gaming desk, including the monitor stand section.

2. Reversible L-Shape Configuration

The L-shaped design of this desk is reversible. You can choose to assemble the longer tabletop section on either the right or left side, depending on your room layout and personal preference. Decide on your preferred orientation before attaching the main desk panels to the frame.




Image: Visual guide showing how the L-shaped desk can be configured with the short or long side on the left.

3. Monitor Stand Assembly

The desk includes a fixed monitor stand designed to elevate your screen, promoting better posture and saving workspace on the main desk surface. Ensure it is securely attached according to the assembly guide.




Image: Comparison of sitting posture, highlighting the ergonomic benefits of using the built-in monitor stand.

4. Attaching Accessories: Cup Holder and Headphone Hook

The cup holder and headphone hook can be installed on either the left or right side of the desk, depending on your preference. These accessories help keep your workspace organized and prevent spills.

*left or right
installation freely*



Hook

Cup Holder



Image: Close-up of the headphone hook and cup holder, demonstrating their placement flexibility.

5. Final Assembly Check

Once all components are assembled, ensure all screws and bolts are tightened securely. Gently test the desk for stability before placing heavy items on it.



Image: The GreenForest L-Shaped Gaming Desk fully assembled and set up for use.

OPERATING INSTRUCTIONS

- **Weight Distribution:** Distribute weight evenly across the desk surface. Avoid concentrating heavy items in one small area.
- **Monitor Placement:** Utilize the integrated monitor stand for optimal ergonomic positioning of your display.
- **Accessory Use:** Use the cup holder for beverages to prevent spills on electronic equipment. Hang headphones on the hook to keep them organized and off the desk surface.
- **Movement:** When moving the desk, lift it rather than dragging it to prevent damage to the legs or floor.

MAINTENANCE

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as they may damage the finish.

- **Spills:** Clean up spills immediately to prevent staining or damage to the desk material.
- **Hardware Check:** Periodically inspect all screws and fasteners. Tighten any loose connections to maintain the desk's stability.
- **Avoid Heat/Moisture:** Do not place hot items directly on the desk surface without protection. Avoid prolonged exposure to excessive moisture.

TROUBLESHOOTING

- **Desk is Wobbly:**
 - Ensure all screws and bolts are fully tightened.
 - Verify the desk is placed on a level surface. Adjust floor glides if present.
- **Parts Missing or Damaged:**
 - Carefully check all packaging materials. If parts are genuinely missing or damaged, contact GreenForest customer support.
- **Difficulty with Assembly:**
 - Review the assembly instructions carefully, paying attention to diagrams and numbered steps.
 - Ensure you are using the correct hardware for each step.

WARRANTY AND SUPPORT

For warranty information, specific product support, or to inquire about replacement parts, please contact GreenForest customer service directly. Refer to your purchase documentation or the GreenForest official website for contact details. GreenForest is committed to providing professional pre- and after-sales service to ensure customer satisfaction.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C4GTZ2TJ>

More documents and user manuals: <https://manuals.plus/>