

[manuals.plus](#) /

› [LIFETIME](#) /

› [LIFETIME 90630 Adventure Tower Deluxe Swing Set Instruction Manual](#)

LIFETIME 90630

LIFETIME 90630 Adventure Tower Deluxe Swing Set Instruction Manual

Model: 90630 | Brand: LIFETIME



1. INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your LIFETIME 90630 Adventure Tower Deluxe Swing Set. Please read all instructions carefully before beginning assembly or allowing children to use the playset. Proper assembly and adherence to safety guidelines are crucial for ensuring a secure and enjoyable play environment.



Image 1: The LIFETIME 90630 Adventure Tower Deluxe Swing Set, showcasing its various play features in a spacious outdoor setting.

2. SAFETY INFORMATION

Important: Adult supervision is required at all times. Ensure children are aware of and follow all safety rules.

- Inspect the playset regularly for loose bolts, worn parts, or structural damage.
- Ensure all ground anchors are securely in place to prevent tipping.
- Maintain a safe fall zone around the playset, free of obstacles.
- Do not allow children to wear loose clothing or jewelry that could get caught.
- Maximum recommended age: 12 years. Minimum recommended age: 3 years.
- Maximum number of users: 10 children.
- This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm (Proposition 65 warning).

3. ASSEMBLY INSTRUCTIONS

Assembly of the LIFETIME 90630 Adventure Tower Deluxe Swing Set requires careful attention to detail and proper organization. It is recommended that two adults perform the assembly, which typically takes approximately 10-11 man-hours.

3.1 Preparation

- Unpack all components and lay them out in an organized manner. Categorize nuts, bolts, and individual pieces according to the provided parts list.
- Ensure you have the necessary tools, including an impact driver for self-tapping metal screws and a metric wrench for certain nuts (as standard Allen wrenches may strip).
- Select a level, clear area for installation, ensuring adequate clearance around all play features.

3.2 Step-by-Step Guidance

For detailed, visual step-by-step assembly instructions, refer to the official YouTube video accessible via the QR code provided in your product packaging. This video serves as a comprehensive guide, walking you through each stage of the assembly process.

3.3 Ground Anchoring

The playset includes ground anchors designed to be driven approximately 12-18 inches into the ground. These arrowhead-style anchors provide essential stability and prevent the playset from rocking or tipping during use. Ensure all anchors are installed correctly and securely.



Image 2: A view of the playset highlighting the monkey bars and the main tower structure, emphasizing its robust construction.

4. FEATURES OVERVIEW

The LIFETIME 90630 Adventure Tower Deluxe Swing Set offers a variety of engaging features designed for active play:

- **Clubhouse with Hardtop Roof:** A spacious 5-foot tall decking area with a rigid hardtop roof, providing shade and a dedicated play space.
- **Storefronts and Doors:** Four integrated storefronts and two functional doors enhance imaginative play within the clubhouse.
- **Rock Climbing Walls:** Two sturdy 3-D climbing walls with colorful holds challenge physical coordination and strength.
- **9-foot Wavy Slide:** A durable and smooth slide for exhilarating descents.
- **Steering Wheel:** Located on the upper deck, encouraging imaginative role-play.
- **Swing Bar with Swings and Trapeze:** Includes two traditional swings and one trapeze bar for swinging and acrobatic fun.
- **Monkey Bars:** A classic feature for developing upper body strength and coordination.
- **Fireman Pole:** A vertical pole for quick and fun descents.
- **Chalk Boards:** Two integrated chalkboards for creative expression.

- **Arched Climber:** An additional climbing structure for varied physical activity.
- **Car Map:** A molded car map on the clubhouse floor for imaginative vehicle play.



Image 3: The playset's main tower with its slide, rock climbing holds, and upper deck, designed for multi-child interaction.

5. OPERATING GUIDELINES

The LIFETIME 90630 Adventure Tower Deluxe Swing Set is designed for children aged 3 to 12 years. It can safely accommodate up to 10 players simultaneously. Ensure that all users adhere to the following guidelines:

- Only one child per swing at a time.
- Slide feet first, in a seated position.
- Do not climb on the outside of the playset structure or roof.
- Keep hands and feet clear of moving parts, especially swings.
- Avoid overcrowding on any single play feature.

Your browser does not support the video tag.

Video 1: An overview of the LIFETIME 90630 Adventure Tower Deluxe Playset, demonstrating its various features and robust construction.

6. MAINTENANCE

The LIFETIME 90630 Adventure Tower Deluxe Swing Set is constructed from UV-protected high-density polyethylene (HDPE) and powder-coated steel, making it durable and weather-resistant. It will not warp, rot, crack, or splinter. To ensure longevity and safety, perform the following maintenance:

- **Regular Cleaning:** Clean plastic and metal surfaces with mild soap and water. Avoid abrasive cleaners.
- **Hardware Check:** Periodically check all nuts, bolts, and fasteners for tightness. Tighten as necessary.
- **Component Inspection:** Inspect swings, chains, and other moving parts for wear or damage. Replace any worn components immediately.
- **Ground Anchors:** Verify that ground anchors remain firmly embedded and secure.
- **Surface Material:** If using loose-fill surfacing (e.g., wood chips), ensure it is maintained at the recommended depth.




Image 4: A close-up of the durable chains and swing seat, highlighting the quality of components designed for long-term use.

7. TROUBLESHOOTING

Should you encounter any issues with your playset, consider the following common solutions:

- **Playset Instability:** Re-check all ground anchors and ensure they are fully secured. Verify all structural bolts are tightened.
- **Squeaking Swings:** Apply a small amount of lubricant to the swing hangers.
- **Loose Components:** Refer to the assembly instructions and tighten any loose nuts or bolts.

8. SPECIFICATIONS

Feature	Detail
---------	--------


Feature	Detail
Brand	LIFETIME
Model Number	90630
Product Dimensions (D x W x H)	36.7"D x 114"W x 48"H
Frame Material	Alloy Steel, Polyethylene
Finish Type	Smooth Plastic
Assembly Required	Yes
Set Name	Adventure Tower Deluxe Swing Set
Manufacturer Recommended Age	3 years and up
Item Weight	500 pounds
UPC	081483804460


9. WARRANTY AND SUPPORT

The LIFETIME 90630 Adventure Tower Deluxe Swing Set comes with a **5-year limited warranty**. For warranty claims, replacement parts, or additional support, please refer to the contact information provided in your product packaging or visit the official LIFETIME website.




Related Documents - 90630

	<p>Lifetime Model 71281 Owner's Manual: Assembly, Operation, and Care This owner's manual provides essential information for the Lifetime Model 71281 basketball system, including detailed assembly steps, safety precautions, parts identification, operational guidance, and maintenance advice from Lifetime Products, Inc.</p>



[Lifetime Model 71525 Owner's Manual and Assembly Guide](#)

This owner's manual provides comprehensive instructions for assembling, operating, and maintaining the Lifetime Model 71525 basketball system. Includes parts lists, safety warnings, and warranty information.




[Lifetime 60331 Utility Shed Assembly Instructions and Guide](#)

This document provides comprehensive assembly instructions for the Lifetime 60331 Utility Shed. It details required tools, parts, and step-by-step guidance for building a durable outdoor storage solution. Includes important safety warnings and customer support information.



[Lifetime 15' x 8' Storage Shed Assembly Instructions \(Model 60318\)](#)

Comprehensive assembly guide for the Lifetime 15' x 8' Storage Shed (Model 60318). This manual provides step-by-step instructions, required tools, safety precautions, and customer support details. Available in English, French, and Spanish. Features BILT app integration for enhanced assembly.



[Lifetime 60495U Outdoor Storage Shed Assembly Instructions](#)

Step-by-step assembly guide for the Lifetime 60495U Outdoor Storage Shed, providing detailed instructions and safety information for proper setup and use.