

YITAHOME AFHIHJHxT5

YITAHOME 9-Drawer Fabric Dresser Instruction Manual

Model: AFHIHJHxT5

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- **Anti-Tip Safety:** To prevent serious injury, this dresser must be securely attached to the wall using the provided anti-tip kit.
- **Weight Limits:** Do not exceed the recommended weight capacity for the top surface or individual drawers. Overloading can cause instability and damage.
- **Children Safety:** Keep children away from the assembly area. Do not allow children to climb on or play with the dresser.
- **Assembly:** Assemble the unit on a soft, clean surface to prevent scratches. Ensure all parts are correctly installed and fasteners are tightened before use.
- **Placement:** Place the dresser on a level surface to ensure stability. Use the adjustable feet to compensate for uneven floors.

2. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Metal Frame Components
- Engineered Wood Top Panel
- Fabric Drawers (3 small, 6 large)
- Wooden Handles
- Adjustable Plastic Feet
- Assembly Hardware (screws, wrench, etc.)
- Anti-Tip Kit

3. PRODUCT SPECIFICATIONS

Feature	Specification
Brand	YITAHOME
Model Number	AFHIHJHxT5
Overall Dimensions (L x W x H)	100 cm x 29 cm x 100 cm (39.4" x 11.8" x 39.4")
Small Drawer Dimensions (L x W x H)	29 cm x 27 cm x 21 cm (11.4" x 10.6" x 8.3")
Large Drawer Dimensions (L x W x H)	45 cm x 27 cm x 21 cm (17.7" x 10.6" x 8.3")
Number of Drawers	9 (3 small, 6 large)
Material	Engineered Wood (top), Metal Frame, Non-woven Fabric (drawers)
Item Weight	14.7 kg (32.4 lbs)
Assembly Required	Yes
Mounting Type	Wall (with anti-tip kit)

PRODUCT SIZE




Figure 1: Product Dimensions. This diagram illustrates the overall dimensions of the dresser and the sizes of the small and large fabric drawers.

4. SETUP AND ASSEMBLY

Follow these steps carefully to assemble your YITAHOME 9-Drawer Fabric Dresser. All necessary hardware and tools are included.

- 1. Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent damage.
- 2. Assemble Metal Frame:** Connect the metal frame components according to the detailed instructions provided in the separate assembly guide. Ensure all screws are finger-tightened initially.
- 3. Attach Top Panel:** Secure the engineered wood top panel to the assembled metal frame using the designated screws. Fully tighten all frame screws once the top panel is in place.
- 4. Install Adjustable Feet:** Screw the four adjustable plastic feet into the bottom of the metal frame. Adjust them as

needed to ensure the dresser is level and stable on your floor.

5. **Prepare Fabric Drawers:** Unfold each fabric drawer and insert the bottom support panel to create a rigid structure.
6. **Attach Wooden Handles:** Secure the wooden handles to the front of each fabric drawer.
7. **Insert Drawers:** Slide the assembled fabric drawers into their respective slots in the dresser frame.
8. **Install Anti-Tip Kit:** For safety, attach the anti-tip kit to the back of the dresser and secure it to a wall stud following the instructions provided with the kit. This step is crucial to prevent tipping.

EASY ASSEMBLY

- ▶ Installation Kit Included
- ▶ Instruction Manual Attached




Figure 2: Easy Assembly Overview. This image provides a visual guide to the straightforward assembly process.




Figure 3: Key Features. This image highlights the waterproof desktop, abrasion-resistant fabric, easy cleaning, and adjustable leveling feet.

5. OPERATING INSTRUCTIONS

The YITAHOME 9-Drawer Fabric Dresser is designed for convenient storage in various rooms.

- **Drawer Use:** Gently pull the wooden handles to open and close the fabric drawers. Avoid forcing drawers open or shut.
- **Storage Capacity:** Utilize the three smaller top drawers for smaller items like accessories, socks, or undergarments. The six larger bottom drawers are suitable for clothing, linens, or other bulkier items.
- **Top Surface:** The engineered wood top provides a stable surface for lamps, books, decorative items, or other lightweight objects. Do not place excessively heavy items on the top surface.
- **Weight Distribution:** Distribute items evenly within the drawers to maintain balance and prevent strain on the frame.



Figure 4: Drawer Capacity. This image demonstrates the storage potential of the dresser with drawers open, showing various items stored inside.



Figure 5: Organization Example. This image illustrates how the dresser can help organize a living space.

6. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your dresser.

- **Cleaning the Frame and Top:** Wipe the metal frame and engineered wood top with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Cleaning Fabric Drawers:** The fabric drawers are made of durable, breathable non-woven fabric. Clean them with a damp cloth and allow them to air dry completely. Do not machine wash or tumble dry.
- **Spills:** Immediately wipe any spills on the waterproof desktop or fabric drawers to prevent staining.
- **Inspection:** Periodically check all fasteners to ensure they remain tight. Re-tighten if necessary.

7. TROUBLESHOOTING

If you encounter any issues with your dresser, refer to the following common solutions:

- **Dresser is Wobbly:**

Solution: Ensure the dresser is on a level surface. Adjust the plastic feet by rotating them until the dresser is stable and does not rock. Check that all frame screws are securely tightened.

- **Drawers Do Not Slide Smoothly:**

Solution: Verify that the fabric drawers are correctly assembled with the bottom support panel fully inserted. Ensure no items are obstructing the drawer's path. Check if the metal frame is assembled squarely.

- **Missing Parts or Damaged Components:**

Solution: If you find any parts missing or damaged upon unpacking, do not proceed with assembly. Contact YITAHOME customer support immediately for assistance.

8. CONTACT AND SUPPORT

For further assistance, questions, or to report missing/damaged parts, please visit the YITAHOME store on Amazon or contact their customer service directly.

YITAHOME Store: [Visit YITAHOME Store](#)

© 2026 YITAHOME. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

