

Calor SV6120C0

Calor SV6120C0 Express Essential Steam Generator Iron User Manual

Model: SV6120C0

INTRODUCTION

Thank you for choosing the Calor SV6120C0 Express Essential Steam Generator Iron. This appliance is designed to make your ironing tasks efficient and effortless with its powerful steam performance and large water tank. Please read this manual carefully before first use and keep it for future reference. Proper use and maintenance will ensure optimal performance and longevity of your steam generator iron.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the steam generator iron.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against a risk of electric shock, do not immerse the iron or base in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been dropped or damaged in any manner.
- The iron must be used and rested on a stable surface.
- Never leave the appliance unattended when it is connected to the power supply.
- Do not use outdoors.
- Do not use the appliance for other than intended use.
- Always ensure the voltage rating on the appliance corresponds to your mains voltage.

PRODUCT COMPONENTS

Familiarize yourself with the different parts of your Calor SV6120C0 Express Essential steam generator iron.



Figure 1: The Calor SV6120C0 Express Essential Steam Generator Iron, showing the iron resting on its base unit. The water tank is visible on the right side of the base, and the steam hose connects the iron to the base.



Figure 2: A side view of the Calor SV6120C0 Express Essential Steam Generator Iron, highlighting the ergonomic handle and the steam button located beneath the handle.



Figure 3: The ceramic soleplate of the Calor SV6120C0 Express Essential Steam Generator Iron, featuring multiple steam vents for even steam distribution and "Xpress Glide" technology for smooth gliding.

- **Iron:** The handheld unit with the soleplate and temperature dial.
- **Soleplate:** Ceramic-coated for smooth gliding and even heat distribution.
- **Steam Hose:** Connects the iron to the base unit for steam delivery.
- **Base Unit:** Houses the water tank and steam generator.
- **Water Tank:** Removable, XL capacity for extended ironing sessions.
- **Control Panel:** Buttons on the base unit for power and steam settings.
- **Temperature Dial:** Located on the iron, for selecting fabric-specific heat settings.

SETUP

1. **Unpacking:** Carefully remove the steam generator iron from its packaging. Retain the packaging for storage or transport.
2. **Positioning:** Place the base unit on a stable, heat-resistant surface, such as an ironing board designed for steam generators. Ensure there is enough space for comfortable ironing.
3. **Filling the Water Tank:**
 - Remove the water tank from the base unit.
 - Fill the tank with tap water up to the "MAX" fill line. For optimal performance and to prolong the life of your appliance, it is recommended to use demineralized or distilled water, especially in areas with hard water.
 - Reinsert the water tank securely into the base unit.




Figure 4: Illustration demonstrating the process of filling the removable water tank. The tank is shown being filled with water from a tap.

4. **Connecting to Power:** Unwind the power cord completely and plug it into a grounded electrical outlet.

OPERATING INSTRUCTIONS

1. **Power On:** Press the power button on the base unit. The indicator light will illuminate.
2. **Heating Up:** The iron will begin to heat up. The indicator light will flash during heating and remain solid when the desired temperature is reached. This typically takes a few minutes.
3. **Select Temperature:** Turn the temperature dial on the iron to the appropriate setting for your fabric type (e.g., silk, wool, cotton, linen). Always check the garment's care label.
4. **Steam Generation:** Once the iron is hot and the indicator light is solid, press and hold the steam trigger located under the iron's handle to release steam. For continuous steam, some models may have a lock feature on the steam trigger.
5. **Ironing:** Iron your garments as usual, moving the iron smoothly over the fabric. The powerful steam will help remove wrinkles efficiently.
6. **Vertical Steaming:** For delicate fabrics or to refresh hanging garments, hold the iron vertically a few centimeters away from the fabric and press the steam trigger.
7. **Auto Shut-off:** For safety, the appliance may feature an auto shut-off function if left unattended for a period. Refer to the specific details in the full manual for your model.
8. **Power Off:** After use, press the power button on the base unit to turn off the appliance. Unplug the power cord from the outlet.

MAINTENANCE AND CLEANING

Regular maintenance ensures the longevity and optimal performance of your steam generator iron.

- **Emptying the Water Tank:** After each use, or before storing, empty any remaining water from the tank.
- **Cleaning the Soleplate:** If the soleplate becomes dirty, clean it with a damp cloth and a non-abrasive cleaner designed for iron soleplates. Do not use abrasive pads or harsh chemicals.
- **Descaling:** The SV6120C0 Express Essential features an integrated anti-calc system. However, regular descaling is still recommended, especially in hard water areas. Follow the instructions in the full product manual for the specific descaling procedure for your model. This typically involves rinsing the boiler or using a descaling solution.
- **Storage:** Allow the appliance to cool completely before storing. Wrap the power cord and steam hose neatly around the designated storage areas on the base unit. Store in a dry, safe place.

TROUBLESHOOTING

If you encounter issues with your steam generator iron, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|-------------------------------------|--|--|
| No steam is being produced. | Water tank is empty. Iron not hot enough. Steam button not pressed. | Refill the water tank. Wait for the iron to reach the set temperature (indicator light solid). Press and hold the steam trigger. |
| Water drips from the soleplate. | Iron temperature is too low for steam. Steam boost used too frequently. | Increase the iron temperature setting. Allow a few seconds between steam boosts. |
| White flakes or residue on clothes. | Mineral deposits from hard water. | Perform a descaling procedure. Use demineralized or distilled water. |
| Iron is not heating up. | Not plugged in. Power button not pressed. Faulty outlet. | Check power connection. Press the power button. Try a different electrical outlet. |

If the problem persists after trying these solutions, please contact Calor customer support.

SPECIFICATIONS

- **Model:** SV6120C0
- **Brand:** Calor
- **Power:** 2200 Watts
- **Special Features:** XL Water Tank, Powerful Steam Performance
- **Soleplate Material:** Ceramic
- **Color:** White and Red (Note: Product appearance may vary slightly)
- **Weight:** Approximately 3.65 Kilograms
- **Recommended Use:** For ironing clothes and fabrics

WARRANTY AND SUPPORT

Your Calor SV6120C0 Express Essential Steam Generator Iron comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.

For technical assistance, spare parts, or any questions not covered in this manual, please contact Calor customer support. Contact information can typically be found on the Calor website or on your product packaging.