

[Manuals.plus](#) /

› [Ohniyou](#) /

› Ohniyou 40-inch Ceiling Fan with Lights and Remote User Manual

Ohniyou GLX053

Ohniyou 40-inch Ceiling Fan with Lights and Remote User Manual

Model: GLX053

1. INTRODUCTION

Thank you for choosing the Ohniyou 40-inch Ceiling Fan. This modern ceiling fan with integrated lights and remote control is designed to provide comfort and style to your indoor or covered outdoor spaces, such as bedrooms, patios, and living rooms. This manual provides detailed instructions for safe installation, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your fan.



Image 1: Ohniyou 40-inch Ceiling Fan with integrated light.

2. SAFETY INFORMATION

Please read all safety instructions carefully before installation and use. Failure to follow these instructions may result in electric shock, fire, or serious personal injury.

- Ensure the power is turned off at the circuit breaker before beginning installation or performing any maintenance.
- All wiring must be in accordance with national and local electrical codes. If you are unsure about wiring, consult a qualified electrician.
- The mounting structure must be capable of supporting the weight of the fan (approximately 9.6 ounces, plus dynamic

load during operation).

- Do not bend the fan blades when installing or cleaning the fan.
- Keep hands, clothing, and other objects away from the fan blades when the fan is in operation.
- This fan is suitable for indoor and covered outdoor use (Patio). Ensure it is not exposed directly to water.


3. PACKAGE CONTENTS

Verify that all components are present and undamaged before installation. If any parts are missing or damaged, contact Ohniyou customer support.


- Ceiling Fan Motor Assembly with Integrated LED Light
- Fan Blades (4 pieces)
- Remote Control
- Downrods (5-inch and 10-inch options)
- Mounting Bracket and Hardware
- Instruction Manual (PDF available online)

40"

Semi Flush Ceiling Fan



ROOM SIZE
12ftx 12ft to 18ftx 18ft



2 Downrods

Indoor

Covered

Outdoor

WET RATING
Dry Covered

Image 2: Illustration of fan dimensions (40-inch width, 13/18-inch height with downrods) and included downrod sizes (5-inch and 10-inch).

4. SETUP AND INSTALLATION

Professional installation is recommended for safety and proper functionality. Refer to the official installation manual for detailed step-by-step instructions and diagrams. A digital version of the manual can be found [here](#).

Installation Video Guide

Your browser does not support the video tag.

Video 1: An official video demonstrating the installation process for the Ohniyou ceiling fan. This video covers key steps from assembly to mounting, providing a visual guide to supplement the written instructions.

For a quick visual reference, you can also scan the QR code below to access an installation video:



Image 3: A QR code that links to an installation video for the ceiling fan. The image shows the fan installed in a bedroom setting.

Direct link to video: <https://www.youtube.com/watch?v=quAxl0Cvy7U>

5. OPERATING INSTRUCTIONS

The Ohniyou ceiling fan is operated using the included remote control. Ensure batteries are correctly inserted into the remote.

Remote Control Functions



Image 4: Diagram illustrating the functions of the remote control, including fan on/off, light on/off, wind speed adjustment (1-6), forward/natural wind mode, reverse mode, and timing options (1H, 2H, 4H).

- **Power On/Off:** Press the 'All off' button to turn off both fan and light.
- **Fan On/Off:** Use the 'Fan on/off' button to control the fan independently.
- **Wind Speed:** Select from 6 wind speeds (1-6) to adjust airflow. Speed 1-2 is ideal for sleeping, 3-4 for working, and 5-6 for cooling.
- **Light Control:** Press 'Light on/off' to toggle the light.
- **Color Temperature Adjustment:** Cycle through Cold White Light (6000K), Natural Light (4500K), and Warm Light (3000K) by pressing the 'Light on/off' button repeatedly.
- **Timing Function:** Set the fan to turn off automatically after 1, 2, or 4 hours.
- **Reversible DC Motor:** The fan features a reversible DC motor for year-round use.

Summer and Winter Modes




Image 5: Illustration of the fan's reversible DC motor functionality. In Downdraft Mode (Summer), the fan rotates clockwise to create a cooling breeze. In Updraft Mode (Winter), it rotates counter-clockwise to circulate warm air.

- **Summer Mode (Forward Rotation):** The fan blades rotate counter-clockwise, pushing air downwards to create a cooling effect.
- **Winter Mode (Reverse Rotation):** The fan blades rotate clockwise, drawing air upwards to circulate warm air trapped near the ceiling, helping to keep the room warm.

6. MAINTENANCE

Regular maintenance ensures the fan's optimal performance and extends its lifespan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure power is off before cleaning.
- **Blade Care:** Periodically check that all blade screws are tight. Over time, they may loosen, causing the fan to wobble.

- **Light Source:** The integrated LED light is designed for long-lasting use. If replacement is ever needed, consult a qualified technician.

7. TROUBLESHOOTING

If you encounter issues with your Ohniyou ceiling fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not operate / No power.	No power supply; Loose wiring; Remote control battery dead.	Check circuit breaker; Ensure all connections are secure; Replace remote control batteries.
Light changes color unexpectedly.	Rapid toggling of wall switch or remote.	This is a feature. To set desired color, turn off the light for a few seconds, then turn it back on. The light will cycle through colors with quick toggles. Pause on desired color.
Fan wobbles.	Loose blade screws; Unbalanced blades; Loose mounting bracket.	Tighten all blade screws; Use balancing kit (if included) to balance blades; Ensure mounting bracket is securely fastened to the ceiling joist.
Noise from fan.	Loose screws; Motor hum; Blades hitting an obstruction.	Check and tighten all screws; Ensure no wires or objects are touching the fan blades or motor housing.
Remote control not working.	Dead batteries; Remote not paired; Obstruction between remote and receiver.	Replace batteries; Refer to manual for pairing instructions; Ensure clear line of sight.

8. SPECIFICATIONS

Feature	Detail
Brand	Ohniyou
Model Number	GLX053
Color	White
Dimensions	12.4 x 7.67 x 17.51 inches (Product)
Fan Diameter	40 inches
Item Weight	9.6 ounces
Voltage	120 Volts
Light Source Type	LED

Feature	Detail
Light Wattage	18 watts
DC Wattage	25 watts
Number of Light Sources	1
Shade Material	Wood
Indoor/Outdoor Usage	Indoor / Covered Outdoor (Patio)
Mounting Type	Ceiling Mount
Assembly Required	Yes

9. WARRANTY AND SUPPORT

For warranty information, technical support, or to purchase replacement parts, please visit the official Ohniyou Store or contact their customer service directly.

- **Ohniyou Store:** [Visit the Ohniyou Store on Amazon](#)
- **User Guide PDF:** [Download the Installation Manual \(PDF\)](#)

© 2024 Ohniyou. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C4KGH5PJ>

More documents and user manuals: <https://manuals.plus/>