

Ardes AR5ST40PN

Ardes AR5ST40PN Pedestal Fan User Manual

Model: AR5ST40PN | Brand: Ardes

	Introduction	Safety	Package
Contents	Setup	Operation	Maintenance
	Troubleshooting	Specifications	Warranty & Support

1. INTRODUCTION

Thank you for choosing the Ardes AR5ST40PN Pedestal Fan. This manual provides important information regarding the assembly, operation, maintenance, and troubleshooting of your new fan. Please read this manual thoroughly before use and keep it for future reference.





Figure 1.1: Front view of the Ardes AR5ST40PN Pedestal Fan.

The Ardes AR5ST40PN is designed to provide efficient air circulation, helping to keep your rooms cool and comfortable. It features a 40 cm base, 5 blades, adjustable oscillation, and tilt, along with 3 speed settings for customized airflow.

2. IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions.

- Read all instructions before using this fan.
- Ensure the power supply matches the voltage specified on the fan's rating label.
- Do not operate the fan with a damaged cord or plug. If the cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- Do not place the fan near heat sources, such as radiators, heat registers, stoves, or other apparatus that produce heat.
- Do not use the fan in wet or damp locations, such as bathrooms or laundry areas.
- Keep fingers, pencils, or any other objects out of the fan grille when it is operating.

- Unplug the fan from the outlet when not in use, when moving it from one location to another, and before cleaning.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

3. PACKAGE CONTENTS

Carefully unpack your fan and check that all items are present and in good condition. If any items are missing or damaged, please contact customer support.

- Fan Motor Unit with Blades and Grilles
- Adjustable Stand Pole (Upper and Lower sections)
- Cross Base
- Base Locking Nut
- Instruction Manual

4. ASSEMBLY AND SETUP

Follow these steps to assemble your Ardes AR5ST40PN Pedestal Fan:

1. **Assemble the Base:** Insert the two parts of the cross base into each other to form a stable cross shape.



AMPIA BASE D'APPOGGIO AD INCASTRO

Figure 4.1: The stable cross base provides excellent support.

2. **Attach the Stand Pole:** Insert the lower section of the stand pole into the center hole of the assembled cross base. Secure it from underneath with the large base locking nut, turning clockwise until tight.
3. **Adjust Pole Height:** Loosen the height adjustment knob on the stand pole. Extend the upper section of the pole to your desired height (between 100 cm and 120 cm) and tighten the knob securely.
4. **Mount the Fan Head:** Place the fan motor unit onto the top of the adjustable stand pole. Ensure it is firmly seated and secured.





Figure 4.2: Side view of the fully assembled fan.

5. **Connect to Power:** Plug the power cord into a standard electrical outlet (230V AC).

5. OPERATING INSTRUCTIONS

Your Ardes AR5ST40PN fan is designed for simple and effective operation.

5.1 Power On/Off and Speed Control

The fan features 3 speed settings. Locate the control knob/buttons on the fan motor unit. Turn the knob or press the buttons to select your desired speed:

- **0:** Off
- **1:** Low Speed
- **2:** Medium Speed
- **3:** High Speed



3 VELOCITÀ

Figure 5.1: Control panel indicating 3 speed settings.

5.2 Oscillation Function

To activate the automatic oscillation, pull up the oscillation knob located on top of the motor housing. The fan head will then sweep from side to side, distributing air across a wider area.

To stop oscillation and direct airflow in a fixed direction, push down the oscillation knob.



AMPIO RAGGIO DI OSCILLAZIONE ARIA FRESCA IN TUTTA LA STANZA

Figure 5.2: The fan provides a wide range of oscillation for broad air distribution.

5.3 Adjustable Tilt

The fan head can be tilted up or down to direct the airflow precisely where needed. Gently push or pull the fan head to adjust its vertical angle. Do not force it beyond its natural range of motion.



Figure 5.3: The fan head can be tilted to adjust airflow direction.

6. MAINTENANCE AND CLEANING

Regular cleaning will help maintain your fan's performance and extend its lifespan.

- **Always unplug the fan before cleaning.**
- **Exterior Cleaning:** Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners or solvents, as these may damage the finish.
- **Grille and Blades Cleaning:** Dust and lint can accumulate on the grilles and blades, affecting airflow.
 - a. Carefully remove the front grille by unscrewing any retaining clips or screws.
 - b. Wipe the blades with a soft, damp cloth.
 - c. Clean the grilles with a soft brush or vacuum cleaner to remove dust.
 - d. Once clean and dry, reattach the front grille securely.
- **Storage:** When not in use for extended periods, store the fan in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.

7. TROUBLESHOOTING

If you experience issues with your fan, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply. Fan not plugged in. Power outlet faulty.	Ensure the fan is properly plugged into a working electrical outlet. Check the circuit breaker.
Weak airflow.	Dust accumulation on blades/grille. Incorrect speed setting.	Clean the fan blades and grilles as described in the Maintenance section. Increase the speed setting.
Fan is noisy.	Loose parts. Fan not on a level surface. Dust/debris in motor.	Check all assembly points to ensure they are secure. Place the fan on a flat, stable surface. Clean the fan thoroughly. If noise persists, contact customer support.
Oscillation not working.	Oscillation knob not engaged.	Ensure the oscillation knob on top of the motor housing is pulled up.

If the problem persists after trying these solutions, please contact Ardes customer support.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Ardes
Model	AR5ST40PN
Color	Black
Product Dimensions	70 x 70 x 120 cm (Depth x Width x Height)
Weight	2.3 kg
Wattage	50 watts
Voltage	230 Volt (AC)
Special Features	Adjustable Tilt, Oscillating
Electric Fan Design	Floor Fan (Pedestal)
Power Source	Corded Electric
Blade Diameter	40 cm
Number of Blades	5
Speed Settings	3

9. WARRANTY AND CUSTOMER SUPPORT

Ardes products are manufactured to high-quality standards. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. Please refer to the warranty card included in your package for specific terms and conditions, or visit the official Ardes website for detailed warranty information.

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact Ardes customer support:

- **Website:** www.ardes.it (Please check the official website for contact details specific to your region.)
- **Email:** Refer to the official website or product packaging.
- **Phone:** Refer to the official website or product packaging.

When contacting support, please have your product model number (AR5ST40PN) and purchase date ready.

© 2025 Ardes. All rights reserved. Information in this manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question