

[Manuals.plus](#) /

› [RUBEHOOW](#) /

› RUBEHOOW X60-BM800 Live Sound Card Mixer Kit with BM800 Microphone User Manual

## RUBEHOOW X60-BM800

# RUBEHOOW X60-BM800 Live Sound Card Mixer Kit with BM800 Microphone User Manual

## INTRODUCTION

The RUBEHOOW X60-BM800 Live Sound Card Mixer Kit is a comprehensive audio solution designed for live streaming, recording, karaoke, and gaming. This kit includes a versatile sound card mixer and a high-quality BM800 condenser microphone, providing users with tools for easy sound effect adjustments, effective noise reduction, and real-time audio monitoring. Its user-friendly design ensures quick and easy connection to computers and mobile phones, making it suitable for various applications from guitar recordings to podcasts and social media live broadcasts.

## PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- RUBEHOOW X60-BM800 Live Sound Card Mixer
- BM800 Condenser Microphone
- Microphone Shock Mount
- Pop Filter
- Adjustable Scissor Arm Stand
- Table Mounting Clamp
- Foam Windscreen
- XLR to 3.5mm Cable
- USB Type-C Cable
- 3.5mm Audio Cables (x2)
- User Manual



Image: All components of the RUBEHOOW X60-BM800 Live Sound Card Mixer Kit laid out, including the mixer, microphone, stand, cables, and accessories.

## SETUP GUIDE

### 1. Microphone Assembly

1. Attach the shock mount to the adjustable scissor arm stand. Secure it by tightening the screw.
2. Gently place the BM800 condenser microphone into the shock mount.
3. Install the pop filter onto the stand, positioning it in front of the microphone.
4. Place the foam windscreen over the microphone head to reduce plosives and wind noise.



Image: Illustration showing how to attach the microphone shock mount to the stand.



Image: Diagram showing the foam windscreen being placed over the microphone.

## 2. Stand Installation

Attach the table mounting clamp to the edge of your desk. Insert the adjustable scissor arm stand into the clamp and tighten it securely. Adjust the stand to your desired position.



Image: Steps for installing the table mounting clamp and attaching the microphone stand.

## 3. Connecting the Mixer and Microphone

Connect the XLR end of the XLR to 3.5mm cable to the BM800 microphone. Plug the 3.5mm end into one of the 'Condenser Mic' inputs on the RUBEHOOW X60-BM800 mixer.

## 4. Connecting to Devices

The mixer supports multiple connection types:

- **PC/Laptop:** Use the provided USB Type-C cable to connect the mixer's 'OTG/PC Live' port to your computer.
- **Mobile Phone (Live Streaming/Recording):** Use the 3.5mm audio cables to connect the mixer's 'Live1' or 'Live2' ports to your phone's audio input.
- **Headphones:** Connect your headphones to the 'Headset' port for real-time audio monitoring.
- **Accompaniment Input:** Connect an external audio source (e.g., another phone, MP3 player) to the 'Accompany' port using a 3.5mm audio cable to play background music.



Image: The back panel of the RUBEHOOW X60-BM800 mixer, illustrating various input and output ports for microphones, headsets, live streaming, accompaniment, and charging, with examples of connected devices.

## 5. Charging

Connect the USB Type-C cable to the 'Charging' port on the mixer and to a 5V/1A power adapter or a computer USB port to charge the device.

## OPERATING INSTRUCTIONS

### 1. Power On/Off

Press and hold the power button (usually located centrally on the mixer) to turn the device on or off.

### 2. Volume and Effect Adjustments

The mixer features several knobs and buttons for fine-tuning your audio:

- **Mic Volume:** Adjust the 'Mic' knob to control the microphone input level.
- **Reverb:** Use the 'Reverb' knob to add or reduce reverberation effects to your voice.
- **Accompaniment Volume:** Control the volume of background music with the 'Accompany' knob.

- **Monitor Volume:** Adjust the 'Monitor' knob to control the headphone output volume.
- **Treble/Bass:** Use the 'Treble' and 'Bass' knobs to adjust the high and low frequencies of your microphone input.

### 3. Scene Modes and Sound Effects

The mixer offers various preset scene modes and sound effects to enhance your audio:

- **Scene Modes:** Select from modes like 'Primal sound', 'Recording studio', 'PRO', 'POP', and 'MC' to instantly apply optimized settings for different scenarios.
- **Sound Effects:** Utilize the dedicated buttons for various sound effects such as 'Giggle', 'DinDin', 'Awkward', 'Gunshot', 'Kiss', 'Laughter', 'Applause', and more.
- **Electric Sound:** Activate the 'Electric sound' button for specific vocal effects.
- **Mute:** Press the 'MUTE' button to temporarily silence the microphone input.
- **Noise Reduction:** The mixer features effective noise reduction to ensure clear audio.

## Sechs Szenario-Nutzungsmodi



1.Urklang 2.Aufnahmestudio 3.Major 4.Popmusik 5.Rap 6.Karaoke



Image: The control panel of the RUBEHOOW X60-BM800 mixer, highlighting the various knobs for volume and effects, and buttons for scene modes and sound effects.

### 4. Real-time Monitoring

Connect headphones to the 'Headset' port to monitor your audio in real-time, allowing you to hear exactly what your audience hears and make adjustments as needed.

### 5. Bluetooth Connectivity

Press the 'BT' button to activate Bluetooth. Pair your mobile device with the mixer to wirelessly stream accompaniment music.

## MAINTENANCE

---

To ensure the longevity and optimal performance of your RUBEHOOW X60-BM800 kit, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the mixer and microphone. Avoid using liquid cleaners or abrasive materials.
- **Storage:** Store the kit in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Handle the microphone and mixer with care to prevent physical damage. Avoid dropping or subjecting them to strong impacts.
- **Cable Care:** Do not bend or crimp cables excessively. Disconnect cables by pulling the plug, not the cable itself.

## TROUBLESHOOTING

---

If you encounter issues with your RUBEHOOW X60-BM800 kit, please refer to the following common solutions:

- **No Sound Output:**
  - Ensure the mixer is powered on and fully charged.
  - Check all cable connections (microphone, headphones, live output).
  - Verify that all volume knobs on the mixer are turned up appropriately.
  - Confirm that the microphone is correctly connected to a 'Condenser Mic' input.
- **Poor Sound Quality/Noise:**
  - Ensure the foam windscreen and pop filter are correctly installed on the microphone.
  - Adjust the 'Mic' gain and 'Treble/Bass' knobs on the mixer.
  - Activate the noise reduction feature on the mixer.
  - Check for interference from other electronic devices.
- **Device Not Recognized by PC/Phone:**
  - Ensure the USB Type-C cable is securely connected to the 'OTG/PC Live' port and your computer.
  - For phones, ensure the 3.5mm audio cables are correctly connected to the 'Live' ports and your phone's audio input. Some phones may require an adapter.
  - Try restarting your computer or phone.
- **Bluetooth Pairing Issues:**
  - Ensure the 'BT' button on the mixer is pressed and flashing.
  - Make sure your mobile device's Bluetooth is enabled and discoverable.
  - Try unpairing and re-pairing the device.

## SPECIFICATIONS

---

Brand	RUBEHOOW
-------	----------

<b>Model Number</b>	X60-BM800
<b>Dimensions (Package)</b>	41.5 x 23.8 x 7.8 cm
<b>Item Weight</b>	1.2 Kilograms
<b>Material</b>	Metal
<b>Connectivity Technology</b>	USB Type-C
<b>Power Source</b>	Electric Cable
<b>Number of Channels</b>	1
<b>Audio Input</b>	XLR, Jack, USB
<b>Output Connector Type</b>	Jack, USB, or USB-C
<b>Device Compatibility</b>	Personal Computer
<b>UPC</b>	746957227090

## WARRANTY AND SUPPORT

Each RUBEHOOW X60-BM800 kit undergoes a thorough quality check before shipment. Should you encounter any issues during the use of your product, please do not hesitate to contact our customer support. We are committed to providing the best possible solution within 24 hours of your inquiry.

© 2023 RUBEHOOW. All rights reserved.