

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [BULIST](#) /

› [UD01 Keypad Door Lock - User Code and One-time Guest Code - Backlit Keypad - Human Voice Prompt - Long Battery Life - Auto Lock Enable/Disable - Easy Installation and Programming - Satin Nickel](#)

## BULIST UD01

# BULIST UD01 Keypad Door Lock - User Manual

Model: UD01 | Brand: BULIST

## 1. INTRODUCTION

This user manual provides comprehensive instructions for the installation, operation, and maintenance of your BULIST UD01 Keypad Door Lock. Please read this manual thoroughly before installation and use to ensure proper function and safety. The UD01 offers secure keyless entry with user codes, one-time guest codes, a backlit keypad, and human voice prompts for enhanced convenience and security.



Figure 1.1: BULIST UD01 Keypad Door Lock (Satin Nickel finish)

## 2. SAFETY INFORMATION

**WARNING:** Failure to follow these instructions could result in damage to the product, property damage, or personal injury.

- Do not attempt to disassemble or modify the lock. This may cause damage and void the warranty.
- Use only the specified battery type (4 AA alkaline batteries). Do not mix old and new batteries or different battery types.
- Keep all components out of reach of children.
- Protect the keypad from excessive moisture or direct water exposure. While the lock has IP54 waterproofing, prolonged exposure can cause damage.
- Avoid using abrasive cleaners or chemicals on the lock's surface.

### 3. PRODUCT OVERVIEW AND COMPONENTS

The BULIST UD01 Keypad Door Lock consists of an exterior keypad assembly, an interior assembly, a latch mechanism, and mounting hardware. Familiarize yourself with all components before beginning installation.




Figure 3.1: Product Dimensions and Component Layout

This image illustrates the various components of the BULIST UD01 lock, including the exterior keypad, interior assembly, and latch, along with their key dimensions for proper fitment on standard doors (35mm-70mm thickness, 60mm or 70mm backset).

## 4. INSTALLATION

---

Follow these steps carefully for a successful installation. A screwdriver is typically the only tool required.

### 4.1 Prepare the Door

- Ensure your door thickness is between 1-3/8" and 2-3/4" (35mm-70mm).
- Verify the backset (distance from door edge to center of bore hole) is either 2-3/8" (60mm) or 2-3/4" (70mm).

### 4.2 Install the Latch

Adjust the latch length if necessary to match your door's backset. Insert the latch into the door edge and secure it with screws.

Your browser does not support the video tag.

Video 4.1: UD01 Installation Video (Source: BULIST Seller)

This video provides a step-by-step guide for installing the BULIST UD01 Keypad Door Lock, covering all physical installation procedures.

## 5. OPERATING INSTRUCTIONS

---

The BULIST UD01 offers multiple convenient ways to operate your lock.

### 5.1 Adding User Codes

You can program up to 50 permanent user codes and 10 one-time guest codes. To add a user code, enter the setting mode by pressing the unlock button for 2 seconds, then follow the voice prompts.



## Keyless Entry

Up to 50 PIN codes and 10 one-time codes



All codes can be cleared at once in case you can't remember them

Figure 5.1: Keyless Entry with User Codes

The keypad allows for easy entry using programmed PIN codes, supporting up to 50 user codes and 10 one-time guest codes. All codes can be cleared at once if needed.

# BULIST

Better your life smarter



Figure 5.2: Sending One-Time PIN Codes

This image demonstrates the convenience of generating and sending one-time PIN codes to guests or service providers, allowing temporary access without compromising your main codes.

## 5.2 Anti-Peeping Passcode

To enhance security, you can add random digits before or after your actual PIN code. The lock will still recognize your correct code within the sequence.



Figure 5.3: Anti-Peeping Passcode Feature

This feature allows you to enter random digits before or after your actual PIN code, preventing others from easily guessing your code by observing your hand movements.

### 5.3 Human Voice Prompts

The UD01 features human voice prompts for various operations, including lock status, low battery reminders, and error warnings. The volume can be adjusted from 1 to 5 levels.



## Dimensions and Specifications



Right-Handed door



Left-Handed door



$\varphi 2-1/8"$  (54mm)



2-3/8" or 2-3/4"  
(60mm or 70mm)




Figure 5.4: Voice Prompts Functionality

The lock provides clear human voice prompts for various functions, including confirming lock/unlock status, low battery warnings, and guiding through function settings.

Your browser does not support the video tag.

Video 5.5: UD01 Function Setting Video (Source: BULIST Seller)

This video demonstrates how to access and navigate the function settings of the BULIST UD01 lock, including adding/deleting user codes, setting auto-lock, and adjusting voice volume.

### 5.4 Auto-Lock Function

The auto-lock feature can be enabled or disabled, and its delay time can be set between 10 to 99 seconds. This provides added peace of mind, ensuring your door is always secured.




Figure 5.6: Auto-Lock and One-Second Locking

The lock can be configured to auto-lock after a delay of 10 to 99 seconds. Alternatively, a quick one-second press on the keypad's lock button can instantly secure the door.

## 6. MAINTENANCE

---

### 6.1 Battery Replacement

The lock is powered by 4 AA alkaline batteries. When the battery is low, the voice prompt will indicate "Low battery, please replace the battery." Replace all four batteries simultaneously for optimal performance. The lock is designed for long battery life, up to 1 year under normal use.



Figure 6.1: Long Battery Life and Low Battery Reminder

The lock features a long battery life of up to one year and provides a voice reminder when the battery level is low, indicating it's time for replacement.

## 6.2 Cleaning

Clean the lock's surface with a soft, damp cloth. Do not use harsh chemicals or abrasive materials, as these can damage the finish.

## 7. TROUBLESHOOTING

- **Lock not responding:** Check battery levels. Replace batteries if low. Ensure cables are securely connected inside the interior assembly.
- **Codes not working:** Re-enter the setting mode and reprogram user codes. Ensure you are pressing the unlock button after entering the code.
- **Voice prompts unclear or too loud/quiet:** Adjust the volume level in the function settings (refer to Section 5.3).
- **Auto-lock not functioning:** Verify the auto-lock feature is enabled and the delay time is set correctly in the function settings.
- **Difficulty with installation:** Refer to the detailed installation video (Section 4.2) and the provided installation manual. Ensure all measurements (door thickness, backset) are correct.

## 8. SPECIFICATIONS

Feature	Detail
Brand	BULIST
Model Name	UD01
Material	Nickel, Zinc
Color	Satin Nickel
Item Dimensions (L x W x H)	3.4 x 7 x 10 inches
Item Weight	2.31 pounds
Special Feature	Smart Lock, Human Voice Prompt, Backlit Keypad, Auto Lock Enable/Disable
Connectivity Protocol	Bluetooth
Power Source	4 AA Batteries (not included)
Operating Temperature	-22°F to 158°F (-30°C to 70°C)
Waterproof Rating	IP54
Keypad Life Test	100,000 times
Battery Life	Up to 1 Year

## 9. WARRANTY AND SUPPORT

BULIST provides a limited warranty for this product. For detailed warranty information, technical support, or assistance with any issues not covered in this manual, please contact BULIST customer service through the retailer's platform or visit the official BULIST store on Amazon.

[Visit the BULIST Store on Amazon](#)