

[Manuals.plus](#) /

› [argoclima](#) /

› Argoclima Kall Plus Portable Air Conditioner User Manual

argoclima Kall Plus

Argoclima Kall Plus Portable Air Conditioner User Manual

Model: Kall Plus

1. IMPORTANT SAFETY INFORMATION

Please read this manual carefully before operating your Argoclima Kall Plus portable air conditioner. Keep this manual for future reference.

- Always connect the unit to a grounded power outlet.
- Do not operate the unit with a damaged cord or plug.
- Ensure proper ventilation around the unit. Do not block air inlets or outlets.
- Do not insert objects into the air outlets.
- Keep children and pets away from the unit during operation.
- Unplug the unit before cleaning or performing any maintenance.
- Do not use the unit in wet environments or near water.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- Argoclima Kall Plus Portable Air Conditioner Unit
- Exhaust Hose
- Window Sealing Kit
- Remote Control (with batteries)
- Drain Hose (for continuous drainage)
- User Manual

3. PRODUCT OVERVIEW

The Argoclima Kall Plus is a compact and efficient portable air conditioner designed to provide cooling comfort. Familiarize yourself with its main components:



Figure 3.1: Front view of the Argoclima Kall Plus portable air conditioner. The unit is white, rectangular, and stands upright on four small black wheels. The top features a dark gray grille for air output.

Key Components:

- **Control Panel:** Located on the top of the unit, with buttons for power, mode selection, fan speed, and temperature adjustment.
- **Air Outlet:** Top grille where cooled air is discharged.
- **Air Inlet/Filter:** Located on the rear or side, where air is drawn in and filtered.
- **Exhaust Air Outlet:** Connection point for the exhaust hose to expel hot air.
- **Drain Port:** For manual or continuous drainage of condensed water.
- **Casters:** Wheels at the base for easy mobility.

4. SETUP

1. **Placement:** Place the unit on a flat, stable surface, ensuring at least 50 cm (20 inches) of clear space around the air inlets and outlets for proper airflow. Avoid direct sunlight.
2. **Exhaust Hose Installation:**
 - Screw one end of the exhaust hose to the exhaust hose connector on the back of the unit.
 - Attach the other end of the exhaust hose to the window adapter.
 - Open a window or sliding door and fit the window adapter into the opening, ensuring it is sealed to prevent hot air from re-entering the room.
3. **Power Connection:** Plug the power cord into a grounded 220-240V / 50Hz electrical outlet.
4. **Remote Control Batteries:** Insert the provided batteries into the remote control, observing polarity.

5. OPERATING INSTRUCTIONS

5.1. Control Panel and Remote Control

The unit can be operated using the control panel on top of the unit or the supplied remote control. The functions are identical.

5.2. Basic Operation

1. **Power On/Off:** Press the **POWER** button to turn the unit on or off.
2. **Mode Selection:** Press the **MODE** button to cycle through available modes:
 - **Cool:** For cooling the room.
 - **Fan:** Circulates air without cooling.
 - **Dry (Dehumidify):** Reduces humidity in the air.
3. **Temperature Adjustment:** In Cool mode, use the **UP** and **DOWN** arrows to set the desired temperature.
4. **Fan Speed:** Press the **FAN SPEED** button to select low, medium, or high fan speed.

5. **Timer Function:** Use the **TIMER** button to set a delay for turning the unit on or off.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your unit.

6.1. Air Filter Cleaning

Clean the air filter every two weeks, or more frequently if the unit is used often or in dusty environments.

1. Unplug the unit from the power outlet.
2. Locate and remove the air filter from its housing (usually on the back or side).
3. Wash the filter under running water (warm, not hot) or use a vacuum cleaner to remove dust.
4. Allow the filter to dry completely before reinserting it into the unit.

6.2. Water Drainage

The unit will accumulate condensed water during operation. It has an auto-evaporation system, but in high humidity, the internal tank may fill. The unit will stop operating and display an error code when full.

1. Unplug the unit.
2. Place a shallow pan or tray under the drain port (usually at the bottom rear).
3. Remove the drain plug to allow water to flow out.
4. Once drained, replace the drain plug securely.
5. For continuous drainage, attach the provided drain hose to the drain port and direct it to a suitable drain.

6.3. Storage

If storing the unit for an extended period:

- Drain all accumulated water.
- Clean the air filter.
- Run the unit in Fan mode for a few hours to dry the internal components.
- Unplug the unit and coil the power cord.
- Store the unit in a dry, cool place, preferably covered to protect from dust.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not turn on.	No power; power cord unplugged; circuit breaker tripped.	Check power outlet; ensure plug is fully inserted; reset circuit breaker.
Unit cools poorly.	Air filter clogged; exhaust hose not properly installed; room too large; windows/doors open.	Clean air filter; ensure exhaust hose is sealed; close windows/doors; consider unit capacity for room size.
Unit is noisy.	Unit not on a flat surface; fan obstruction.	Place on a flat surface; check for obstructions in fan area.
Water leaks from unit.	Drain plug loose; drain hose not connected properly (if using continuous drainage).	Ensure drain plug is secure; check drain hose connection.
Remote control not working.	Batteries dead or incorrectly inserted; obstruction between remote and unit.	Replace batteries; ensure correct polarity; remove obstructions.

If the problem persists after trying these solutions, please contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	Argoclima
Model	Kall Plus
Cooling Capacity	13000 BTU (British Thermal Units)
Control Method	Remote Control
ASIN	B0C4LC154X

9. WARRANTY AND SUPPORT

Your Argoclima Kall Plus portable air conditioner comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details. For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact Argoclima customer service. Contact information can typically be found on the manufacturer's official website or on the product packaging.

Note: Amazon's return policy (Garanzia e recesso) is separate from the manufacturer's product warranty.