Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Vactidy /
- > Vactidy Robot Vacuum T6 User Manual

Vactidy vacuum

Vactidy Robot Vacuum T6 User Manual

Brand: Vactidy | Model: vacuum

1. INTRODUCTION AND OVERVIEW

Welcome to the Vactidy Robot Vacuum T6 user manual. This guide provides essential information for setting up, operating, and maintaining your new robotic vacuum cleaner. The Vactidy T6 is designed to simplify your cleaning routine with its powerful suction and intelligent features.



Figure 1: Vactidy Robot Vacuum T6 and accessories.

Key Features:

- **Powerful Suction:** Up to 2000Pa suction power for effective cleaning on hard floors and low-pile carpets.
- Slim Design: With a height of only 2.89 inches, it can easily clean under furniture.
- **Multiple Control Options:** Control via Vactidy App, Alexa, Siri, Google Assistant, or the included remote control.
- Versatile Cleaning Modes: Auto, Spot, Edge, and Room clean modes to suit different cleaning needs.
- Quiet Operation: Operates at a low noise level of 60dB in quiet mode.
- Self-Charging: Automatically returns to the charging base when battery is low.

2. WHAT'S IN THE BOX

Please check the contents of your package to ensure all items are present:

- Robot Vacuum Cleaner (x1)
- Charging Base (x1)
- Adapter (x1)

- Remote control (x1)
- HEPA filter (x2)
- Cleaning Brush (x1)
- Side Brush (x4)
- User Manual (x1)




Figure 2: Package Contents.

3. SETUP

Follow these steps to set up your Vactidy Robot Vacuum T6:

- 1. Place the Charging Base: Position the charging base against a wall in an open, uncluttered area. Ensure there is at least 1 meter (3 feet) of clear space in front of the base and 0.5 meters (1.5 feet) on either side.
- 2. **Connect Power:** Plug the adapter into the charging base and then into a wall outlet. Ensure the indicator light on the charging base illuminates.
- 3. **Initial Charge:** Place the robot vacuum onto the charging base. Ensure the charging contacts on the robot align with those on the base. Allow the robot to fully charge before its first use (approximately 4-5 hours). The indicator light on the robot will change when fully charged.
- 4. **Install Side Brushes:** Snap the side brushes onto their respective posts on the bottom of the robot.
- 5. **Download the Vactidy App:** Search for "Vactidy App" in your mobile app store (iOS or Android) and download it.
- 6. Connect to Wi-Fi:
 - Open the Vactidy App and follow the on-screen instructions to add your T6 robot vacuum.
 - Ensure your T6 robot is on and charging in the charging dock.
 - Press and hold the start button on the robot for 5 seconds until it enters pairing mode.
 - Connect your phone to a 2.4GHz Wi-Fi network. The robot only supports 2.4GHz Wi-Fi.
 - Select and connect to the Wi-Fi network named "SL-Vactidy-XXXX" (where XXXX is a unique identifier).
 - Wait for the robot to pair successfully with the app.



Figure 3: App Connection Guide.

4. OPERATING YOUR ROBOT VACUUM

Your Vactidy T6 offers various ways to initiate and manage cleaning tasks:

Control Methods:

- Vactidy App: Use the app to set schedules, select cleaning modes, monitor cleaning progress, and check consumable records.
- **Voice Control:** Integrate with Amazon Alexa, Siri, or Google Assistant for hands-free control. Simply use voice commands to start, stop, or send the robot back to its charging base.
- Remote Control: The included remote control provides direct access to start/stop cleaning, change modes, and manually direct the robot.




Figure 4: Smart Control Options.

Cleaning Modes:

The Vactidy T6 features four distinct cleaning modes:

- Auto Cleaning: The robot intelligently navigates and cleans your home in a systematic pattern.
- **Spot Cleaning:** Focuses on a specific dirty area, cleaning in a spiral pattern for concentrated removal of debris.
- Edge Cleaning: Cleans along walls and furniture edges to ensure thorough coverage.
- Room Clean: Designed for cleaning a single room.



Figure 5: Versatile Cleaning Modes.

Automatic Recharging:

When the battery level is low, the robot will automatically return to its charging base to recharge. Ensure the charging base is always powered on and accessible.




Figure 6: Automatic Recharging.

5. MAINTENANCE

Regular maintenance ensures optimal performance of your Vactidy T6 robot vacuum. Always turn off the robot and disconnect it from the charging base before performing any maintenance.

Dustbin and Filter Cleaning:

- Empty the dustbin after each use.
- Clean the HEPA filter and pre-filter regularly (e.g., weekly) by tapping off debris. Do not wash the HEPA filter with water.

Brushes Cleaning:

- Remove and clean the main roller brush regularly, removing any tangled hair or debris.
- Clean the side brushes and remove any hair or debris. Replace them if they are worn or damaged.

Sensors and Charging Contacts:

• Wipe the anti-drop sensors and charging contacts on both the robot and the charging base with a clean, dry cloth to ensure proper function.




Figure 7: Robot Components for Maintenance.

6. TROUBLESHOOTING

If your Vactidy T6 robot vacuum encounters issues, refer to the following common troubleshooting tips:

- **Robot not charging:** Ensure the charging contacts on both the robot and the base are clean and free of dust. Verify the power adapter is securely plugged into the wall outlet and the charging base.
- Robot gets stuck frequently: Clear obstacles from the cleaning path. Ensure cables, small rugs, or loose items are removed. The slim design helps, but some areas may still be problematic.
- **Reduced suction power:** Check and empty the dustbin. Clean or replace the HEPA filter. Remove any tangled hair or debris from the main roller brush and side brushes.
- Robot not connecting to Wi-Fi: Ensure your Wi-Fi network is 2.4GHz. Restart your router and the robot. Follow the app connection steps carefully.
- **Unusual noises:** Check for any foreign objects caught in the brushes or wheels. Clean all components as per the maintenance section.

For more detailed troubleshooting or persistent issues, please consult the full User Manual PDF or contact Vactidy customer support.

7. Specifications

Feature	Specification
Brand	Vactidy
Model Number	vacuum
Special Feature	Bagless
Color	Black
Product Dimensions	16"L x 13"W x 4"H
Filter Type	Cartridge, Cloth, Foam
Battery Life	100 minutes
Voltage	240 Volts
Power Source	Battery Powered
Form Factor	Robotic
Item Weight	7.48 pounds


8. WARRANTY AND SUPPORT

Vactidy offers professional service and support for its products. Your Vactidy Robot Vacuum T6 comes with a 1-year professional service warranty.

For further assistance, detailed instructions, or warranty claims, please refer to the official User Manual PDF or contact Vactidy customer support through their official channels.

• User Manual (PDF): Download Here

• User Guide (PDF): Download Here



© 2024 Vactidy. All rights reserved.

Related Documents - vacuum



Vactidy T6 Robot Vacuum Cleaner User Manual

Comprehensive user manual for the Vactidy T6 Robot Vacuum Cleaner, covering safety instructions, product operation, maintenance, specifications, and troubleshooting.

