

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [iRobot](#) /

› [iRobot Roomba Combo i5+ Robot Vacuum and Mop User Manual](#)

iRobot Roomba Combo i5+

iRobot Roomba Combo i5+ Robot Vacuum and Mop

Official User Manual

PRODUCT OVERVIEW

The iRobot Roomba Combo i5+ is a versatile robotic cleaning device designed for both vacuuming and mopping. It features a 4-Stage Cleaning System for powerful pickup of dirt and debris, and the ability to automatically empty its bin for up to 60 days. With Imprint Smart Mapping, the robot learns your home's layout, allowing for customized cleaning by room. It also incorporates Dirt Detect Technology to focus on dirtier areas and supports voice commands for convenient operation.



Image: The iRobot Roomba Combo i5+ robot vacuum and mop, shown with its Clean Base Automatic Dirt Disposal and a smartphone displaying the iRobot app. This setup allows for hands-free cleaning and automatic bin emptying.

KEY FEATURES

- **Powerful 4-Stage Cleaning System:** Utilizes Dual Multi-Surface Rubber Brushes and power-lifting suction to effectively clean various floor types, including pet hair.
- **Self-Emptying Capability:** The Clean Base Automatic Dirt Disposal allows the robot to empty its vacuum bin automatically for up to 60 days, reducing manual intervention.
- **Smart Mapping and Room-Specific Cleaning:** Learns your home's layout to create Imprint Smart Maps, enabling you to direct the robot to clean specific rooms or areas on demand or on a schedule.
- **Dirt Detect Technology:** Identifies and focuses on dirtier areas of your home for a more thorough clean when the vacuum bin is installed.
- **Dual Functionality (Vacuum & Mop):** Easily converts from a vacuum-only robot to a vacuum and mop by swapping the vacuum bin with the Roomba Combo Bin.
- **Voice Assistant Compatibility:** Works with Alexa, Siri, and Google Assistant-enabled devices for convenient voice control.
- **Wi-Fi Connectivity:** Requires a 2.4 GHz network for setup and operation.

SETUP GUIDE

- 1. Unpack the Robot and Base:** Carefully remove the Roomba Combo i5+ robot, Clean Base Automatic Dirt Disposal, and all accessories from the packaging.
- 2. Place the Clean Base:** Choose a location for the Clean Base that is against a wall, on a level surface, and free from obstructions. Ensure there is adequate space around the base for the robot to dock and maneuver.
- 3. Connect Power:** Plug the Clean Base power cord into a wall outlet.
- 4. Charge the Robot:** Place the Roomba Combo i5+ robot onto the charging contacts of the Clean Base. Ensure the robot is properly aligned. The light ring on the robot will indicate charging status. Allow the robot to fully charge before its first use.
- 5. Download the iRobot Home App:** Download the iRobot Home app from your device's app store. This app is essential for setup, smart mapping, scheduling, and controlling your robot.
- 6. Connect to Wi-Fi:** Follow the in-app instructions to connect your robot to your home's 2.4 GHz Wi-Fi network. Both your phone and the robot must be on the 2.4 GHz network during setup.
- 7. Initial Mapping Run:** Once connected, the app will guide you through an initial mapping run. This allows the robot to learn your home's layout and create an Imprint Smart Map.

Learns and maps your home with Imprint Smart Mapping




Image: The Roomba Combo i5+ robot actively mapping a home's floor plan, illustrating its Imprint Smart Mapping capability to learn and navigate your living spaces efficiently.

OPERATING INSTRUCTIONS

Starting a Cleaning Job

- **Using the iRobot Home App:** Open the app and select "Clean" to start a full cleaning job. You can also select specific rooms or zones from your Imprint Smart Map.
- **Using the CLEAN Button:** Press the CLEAN button on the robot to start a general cleaning job. Press it again to pause, and once more to resume. Hold the button for a few seconds to end the job and send the robot back to its base.
- **Voice Commands:** If paired with a compatible voice assistant (Alexa, Siri, Google Assistant), use commands like "Alexa, tell Roomba Combo to start vacuuming" or "Hey Google, clean the kitchen."

Vacuuming and Mopping Modes

The Roomba Combo i5+ offers both vacuum-only and vacuum-and-mop functionalities. The robot automatically detects which bin is installed.

- **Vacuum-Only Mode:** Use the standard Vacuum Bin for dry debris pickup on all floor types. The robot will automatically empty this bin into the Clean Base.
- **Vacuum and Mop Mode:** To mop, swap the Vacuum Bin with the Roomba Combo Bin. Fill the Combo Bin with water or a compatible cleaning solution (refer to iRobot website for approved solutions). Attach the microfiber mop pad. The robot will then vacuum and wet mop hard floors simultaneously. *Note: Automatic Dirt Disposal is not available when the Mopping Bin is installed.*



Image: The Roomba Combo i5+ robot with its two interchangeable bins: the Vacuum Bin for dry cleaning and the Roomba Combo Bin for combined vacuuming and wet mopping, demonstrating its dual functionality.



Fill with water or compatible cleaning solutions



Image: Hands filling the Roomba Combo Bin with liquid from a faucet, illustrating the process of preparing the robot for wet mopping with water or a compatible cleaning solution.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your Roomba Combo i5+.

Cleaning Frequency

Component	Recommended Cleaning Frequency
Vacuum Bin & Filter	After each use (bin), weekly (filter)
Roomba Combo Bin & Mop Pad	After each mopping use
Dual Multi-Surface Rubber Brushes	Weekly

Component	Recommended Cleaning Frequency
Edge-Sweeping Brush	Monthly
Charging Contacts & Sensors	Monthly
Clean Base Dirt Disposal Bag	Approximately every 60 days, or when full

Detailed Cleaning Steps

- **Vacuum Bin:** Press the bin release button and pull out the bin. Open the bin door and empty debris. Tap the bin against a trash can to dislodge any remaining dirt.
- **Filter:** Remove the filter from the bin. Tap the filter against a trash can to clean it. Do not wash the filter. Replace the filter every two months or as needed.
- **Roomba Combo Bin & Mop Pad:** Remove the Combo Bin. Discard any remaining liquid. Remove the mop pad and rinse it thoroughly with water. Allow the pad to air dry completely before reattaching.
- **Brushes:** Pinch the brush frame release tabs and lift the frame. Remove the brushes and clean any hair or debris wrapped around them or trapped beneath the caps. Reinstall the brushes, ensuring they click into place.
- **Edge-Sweeping Brush:** Use a coin or small screwdriver to remove the screw holding the brush. Pull the brush off and remove any hair or debris. Reinstall the brush.
- **Charging Contacts & Sensors:** Use a clean, dry cloth to wipe the charging contacts on both the robot and the Clean Base. Also, wipe the cliff sensors and other optical sensors on the robot's underside.
- **Clean Base Dirt Disposal Bag:** When the bag is full, lift the lid of the Clean Base. Pull up on the plastic collar of the bag to seal it, then remove and discard. Insert a new bag, ensuring it is fully seated.




Image: An underside view of the Roomba Combo i5+ robot, highlighting its edge-sweeping brush, dual multi-surface rubber brushes, power-lifting suction area, and the mop pad, illustrating the components of its 4-stage cleaning system.

Empties its Vacuum Bin for up to 60 days*



*Automatic Dirt Disposal not available when Mopping Bin is installed

Image: The Roomba Combo i5+ robot docked with its Clean Base, which automatically empties the robot's vacuum bin. This feature allows for up to 60 days of hands-free debris disposal.

TROUBLESHOOTING

If your Roomba Combo i5+ encounters an issue, consult the following common troubleshooting steps. For more detailed information, refer to the official user guide or the iRobot Home app.

- Robot Not Charging:** Ensure the robot is properly seated on the Clean Base. Wipe the charging contacts on both the robot and the base with a clean, dry cloth. Check that the power cord is securely plugged into the wall outlet.
- Robot Not Connecting to Wi-Fi:** Verify your Wi-Fi network is 2.4 GHz. Ensure your mobile device is also connected to the 2.4 GHz network during setup. Restart your router, the robot, and your mobile device.
- Robot Getting Stuck:** Clear any loose cables, rugs with tassels, or small objects from the cleaning area. Use virtual wall barriers (sold separately) or set Keep Out Zones in the app to restrict the robot from problem areas.
- Poor Cleaning Performance:** Clean the Dual Multi-Surface Rubber Brushes, Edge-Sweeping Brush, and filter. Empty the vacuum bin. If mopping, ensure the mop pad is clean and the Roomba Combo Bin is filled with

water/solution.

- **Robot Not Emptying Bin:** Ensure the Clean Base dirt disposal bag is not full and is properly installed. Check for any obstructions in the Clean Base's suction port or the robot's vacuum bin.
- **Error Messages:** The robot's light ring or voice prompts will indicate specific error codes. Refer to the iRobot Home app for detailed explanations and solutions for each error.

For further assistance, please visit the [iRobot Store](#) or consult the comprehensive [Safety Information \(PDF\)](#) document.

SPECIFICATIONS

Attribute	Detail
Brand	iRobot
Model Name	Roomba Combo i5+
Model Number	i557020
Special Features	Smart Mapping, Clean by room, Cleans in neat rows, Self-Emptying
Color	Black
Product Dimensions	13.4" L x 13.5" W x 3.6" H
Item Weight	7 pounds
Included Components	1 Roomba i5 Robot Vacuum, 2 Cleaning Pads, 1 Extra High-Efficiency Filter, 1 Roomba Combo Bin, 2 Dirt Disposal Bags, 1 Clean Base Automatic Dirt Disposal
Filter Type	Cartridge
Battery Life	180 minutes
Voltage	14.4 Volts
Power Source	Battery Powered
Control Method	Voice
Compatible Devices	Amazon Echo
UPC	885155040640

WARRANTY INFORMATION

The iRobot Roomba Combo i5+ comes with a manufacturer's warranty. For detailed terms and conditions, including coverage and duration, please refer to the official [Warranty \(PDF\)](#) document provided by iRobot. Keep your proof of purchase for warranty claims.

iRobot does not certify the quality or authenticity of products purchased from non-authorized resellers on Amazon, and will only cover warranty claims, provide service or offer replacements for products purchased from authorized sellers.






SUPPORT

For additional support, technical assistance, or to purchase replacement parts and accessories, please visit the official [iRobot Store on Amazon](#) or the iRobot official website. You can also find helpful resources and FAQs within the iRobot Home app.

© 2024 iRobot Corporation. All rights reserved.

Roomba is a registered trademark of iRobot Corporation.

Related Documents - Roomba Combo i5+

	<p>Roomba i3+ Robot Vacuum FAQ - iRobot</p> <p>Frequently asked questions about the iRobot Roomba i3+ robot vacuum, covering cleaning performance, smart features, maintenance, and compatibility.</p>
	<p>iRobot Roomba Combo i8+ Owner's Guide: Setup, Operation, and Maintenance</p> <p>Your essential guide to the iRobot Roomba Combo i8+ robot vacuum and mop. Learn how to set up, operate, maintain, and troubleshoot your device for a cleaner home.</p>
	<p>iRobot Roomba Combo i5+ User Manual</p> <p>This user manual provides comprehensive instructions for the iRobot Roomba Combo i5+ robot vacuum and mop, including setup, operation, maintenance, and troubleshooting. Learn how to use the Clean Base Automatic Dirt Disposal and the iRobot Home app for optimal cleaning.</p>
	<p>iRobot Roomba Combo i8 Owner's Guide: Setup, Operation, and Maintenance</p> <p>Learn how to set up, operate, and maintain your iRobot Roomba Combo i8 robot vacuum and mop. This guide provides essential safety information, usage instructions, and care tips for optimal performance.</p>
	<p>iRobot Roomba Combo j9+ Owner's Guide: Safety, Setup, and Maintenance</p> <p>Comprehensive owner's guide for the iRobot Roomba Combo j9+ robot vacuum and mop, including essential safety information, setup instructions, cleaning procedures, and troubleshooting tips for the robot and Clean Base™ Auto-Fill Dock.</p>
	<p>iRobot Roomba j6+ and i7+ Robot Vacuums: User Guide</p> <p>A comprehensive guide to the iRobot Roomba j6+ and i7+ self-emptying robot vacuums, detailing features like pet waste avoidance, smart mapping, automatic dirt disposal, and essential maintenance tips.</p>

