

[Manuals.plus](#) /

› [BODEGACOOOLER](#) /

› BODEGACOOOLER UL-JC-70 24-Bottle Freestanding Wine Cooler Instruction Manual

BODEGACOOOLER UL-JC-70

BODEGACOOOLER UL-JC-70 24-Bottle Freestanding Wine Cooler Instruction Manual

Model: UL-JC-70

1. INTRODUCTION

Thank you for choosing the BODEGACOOOLER UL-JC-70 24-Bottle Freestanding Wine Cooler. This appliance is designed to provide an optimal environment for storing your wine collection, ensuring each bottle is kept at its ideal temperature. Please read this manual thoroughly before installation and operation to ensure proper use and maintenance.



Image 1.1: BODEGACOOLER UL-JC-70 24-Bottle Freestanding Wine Cooler.

2. IMPORTANT SAFETY INFORMATION

To reduce the risk of fire, electric shock, or injury when using your wine cooler, follow these basic precautions:

- Read all instructions before using the appliance.
- Do not touch cold surfaces immediately after the unit has been plugged in.
- Ensure the appliance is properly grounded.
- Do not use damaged cords or plugs.
- Keep ventilation openings clear of obstruction.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

- Children should be supervised to ensure that they do not play with the appliance.

3. PRODUCT OVERVIEW AND FEATURES

The BODEGACOOLER UL-JC-70 is a freestanding wine cooler designed for optimal wine preservation. Key features include:

- **Electronic Digital Thermostat:** Maintains a stable temperature range of 41°F to 64.4°F (5°C to 18°C).
- **Quiet Cooling System:** Advanced compressor technology with a built-in fan ensures consistent temperature and minimal noise.
- **Double-Paned Thermopane Glass:** Protects wine from harmful UV light and provides insulation.
- **Soft Interior LED Lighting:** Illuminates the interior with a gentle white light, ideal for wine storage.
- **Removable Chrome Shelves:** Wavy chrome racks designed to securely hold standard 750ml wine bottles.
- **Smart Memory Chip:** Restores original settings after a power failure or reboot.



Image 3.1: Key features of the BODEGACOOLER Wine Cooler.

4. SETUP AND INSTALLATION

4.1 Unpacking

Carefully remove all packaging materials. Inspect the wine cooler for any damage. Keep packaging materials for future transport if needed.

4.2 Placement

This is a freestanding unit. Ensure adequate ventilation around the appliance. Do not block the ventilation openings. Place the unit on a flat, stable surface away from direct sunlight and heat sources. Allow at least 5 inches of space between the back and sides of the cooler and any adjacent walls to ensure proper air circulation.



Image 4.1: Product dimensions for placement consideration.

4.3 Leveling

Adjust the leveling legs at the bottom of the unit to ensure it is perfectly level. This is crucial for proper operation and door alignment.

4.4 Initial Power-On

After placement, allow the unit to stand upright for at least 2-4 hours before plugging it into a power outlet. This allows the refrigerant to settle. Plug the unit into a dedicated, grounded electrical outlet.

5. OPERATING INSTRUCTIONS

5.1 Digital Temperature Control

The wine cooler features an electronic digital thermostat with a temperature range of 41°F to 64.4°F. The control panel is located on the top of the door.

- **Unlock:** To adjust the temperature, press and hold the unlock button (often represented by a lock icon) for approximately 3-4 seconds until the display flashes.
- **Adjust Temperature:** Use the 'Up' (▲) and 'Down' (▼) arrows to set your desired temperature.
- **Lock:** The control panel will automatically lock after a few seconds of inactivity to prevent accidental changes.




Image 5.1: Digital touch control panel for temperature adjustment.

Your browser does not support the video tag.

Video 5.1: Demonstration of the BODEGACOOLER 24 Bottle Compressor Wine Cooler's controls and interior.

5.2 Internal LED Lighting

The wine cooler is equipped with soft white LED lighting. To turn the light on or off, press the light bulb icon on the control panel. This lighting is energy-efficient and designed not to affect the wine's quality.



Image 5.2: Soft LED lighting illuminates the wine cooler interior.

5.3 Arranging Shelves and Bottles

The wine cooler features removable chrome shelves. These shelves can be adjusted or removed to accommodate different bottle sizes and quantities. Gently pull out the shelves to place or retrieve bottles. The wavy design ensures bottles are securely cradled.

Your browser does not support the video tag.

Video 5.2: Demonstration of arranging bottles on the shelves of the BODEGACOOLER 24 Bottle Wine Cooler.

6. MAINTENANCE

6.1 Cleaning

- **Interior:** Unplug the unit before cleaning. Use a soft cloth dampened with a solution of mild detergent and warm water. Avoid abrasive cleaners.
- **Exterior:** Wipe the exterior with a soft, damp cloth. For stainless steel surfaces, use a non-abrasive stainless steel cleaner.
- **Shelves:** Remove shelves and wash them with mild soap and water. Dry thoroughly before returning them to the unit.

6.2 Defrosting

The BODEGACOOLER UL-JC-70 features an automatic defrost system, minimizing the need for manual defrosting. If excessive frost builds up, unplug the unit and allow the frost to melt naturally. Collect melted water with a towel.

6.3 Power Outage Recovery

This wine cooler is equipped with a smart memory chip. In the event of a sudden power failure, the unit will automatically restore to its original temperature settings once power is reinstated, eliminating the need for manual reset.

7. TROUBLESHOOTING

If you experience issues with your wine cooler, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit does not operate	Not plugged in; circuit breaker tripped; power switch off	Ensure plug is secure; reset circuit breaker; turn power switch on
Temperature is not cold enough	Door not closed properly; excessive door opening; warm items added; poor ventilation; temperature set too high	Check door seal; minimize door openings; allow items to cool before placing; ensure proper clearance; adjust temperature setting
Unit is making noise	Normal operation sounds (compressor, fan); unit not level	These sounds are normal; adjust leveling legs to ensure stability
Vibrations	Unit not level; contact with wall or other appliance	Adjust leveling legs; move unit away from contact points

8. SPECIFICATIONS

Feature	Specification
Brand	BODEGACOOLER
Model Info	UL-JC-70
Capacity	24 Bottles / 35 Liters
Temperature Range	41°F - 64.4°F (5°C - 18°C)
Product Dimensions (D x W x H)	17.7" x 16.9" x 29.33"
Item Weight	49.9 pounds (22.68 Kilograms)
Installation Type	Freestanding
Door Material Type	Glass+ABS (Double-Paned Thermopane Glass)
Shelf Type	Wire (Chrome)
Number of Shelves	5
Defrost System	Automatic
Special Features	Adjustable Shelves, Digital Temperature Control, Smart Memory Chip
Annual Energy Consumption	160 Kilowatt Hours

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product packaging or visit the official BODEGACOOLER website. Keep your purchase receipt as proof of purchase for any warranty claims.

