

CoolBox COO-AUB-TWS01

CoolBox TWS-01 Wireless Headphones User Manual

Model: COO-AUB-TWS01

1. INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your CoolBox TWS-01 Wireless Headphones. Please read this manual thoroughly before using the product and retain it for future reference.

2. PRODUCT OVERVIEW

2.1 Package Contents

- CoolBox TWS-01 Wireless Headphones (Left and Right)
- Charging Case
- USB-C Charging Cable
- Ear Tips
- User Manual

2.2 Components

Familiarize yourself with the main components of your CoolBox TWS-01 headphones and charging case.



Image: The CoolBox TWS-01 wireless headphones, white in color, are shown inside their open charging case. The case is also white and has the "CoolBox" logo on the front. This image provides a clear view of both earbuds and the charging case.



Image: A front-facing view of the CoolBox TWS-01 wireless headphones, nestled within their open charging case. The earbuds are white with silver accents at the bottom of the stems, and the case is white with the CoolBox logo.



Image: A close-up shot of the two CoolBox TWS-01 wireless headphones, showing their individual design with white bodies and silver accents at the bottom of the stems. The ear tips are black.

TWS-01

AURICULARES BLUETOOTH
CON MICRÓFONO

Excepcional calidad de sonido,
con tecnología Bluetooth 5.1 +
EDR y alcance de hasta 10m



Image: A graphic displaying the CoolBox TWS-01 wireless headphones against a blue background, highlighting their exceptional sound quality, Bluetooth 5.1 + EDR technology, and up to 10m range.



Image: A graphic illustrating the touch control functionality of the CoolBox TWS-01 wireless headphones, showing concentric circles emanating from the earbud to represent touch interaction for play/pause, volume control, track skipping, and power.

3. SETUP

3.1 Initial Charging

Before first use, fully charge the headphones and the charging case.

1. Place both earbuds into the charging case.
2. Connect the USB-C charging cable to the charging port on the case and the other end to a USB power source (e.g., computer, wall adapter).
3. The LED indicator on the case will show charging status. A full charge takes approximately 1.5 hours.

3.2 Pairing with a Device

To pair your CoolBox TWS-01 headphones with a Bluetooth-enabled device:

1. Ensure the headphones are charged and inside the charging case.
2. Open the charging case. The headphones will automatically enter pairing mode (or manually activate by pressing

and holding the touch control area on both earbuds for a few seconds if they don't pair automatically).

3. On your device (smartphone, tablet, computer), go to Bluetooth settings and turn Bluetooth on.
4. Search for available devices. You should see "CoolBox TWS-01" or a similar name appear in the list.
5. Select "CoolBox TWS-01" to connect. Once connected, a voice prompt will confirm successful pairing.
6. If pairing fails, turn off Bluetooth on your device, place the earbuds back in the case, close the lid, wait a few seconds, then reopen and try again.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

- **Power On:** Open the charging case, and the earbuds will automatically power on and connect to the last paired device. Alternatively, press and hold the touch control area on both earbuds for 3 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically disconnect and power off. Alternatively, press and hold the touch control area on both earbuds for 5 seconds.

4.2 Touch Controls

The CoolBox TWS-01 headphones feature intuitive touch controls:

Action	Left Earbud	Right Earbud
Play/Pause	Single tap	Single tap
Next Track	Double tap	Double tap
Previous Track	Triple tap	Triple tap
Volume Up	N/A	Press and hold
Volume Down	Press and hold	N/A
Answer/End Call	Single tap	Single tap
Reject Call	Press and hold for 2 seconds	Press and hold for 2 seconds
Activate Voice Assistant	Quadruple tap	Quadruple tap

4.3 Charging the Headphones

Place the earbuds into the charging case. They will automatically begin charging. The LED indicators on the earbuds (if present) or case will indicate charging status. A full charge provides approximately 5 hours of playback.

4.4 Charging the Case

Connect the USB-C cable to the charging port on the case and a power source. The case provides up to 15 hours of additional battery life for the headphones. It takes approximately 1.5 hours to fully charge the case.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earbuds and charging case. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the headphones in their charging case to protect them and keep them charged.

- **Water Resistance:** These headphones are not water-resistant. Avoid exposure to liquids, moisture, and extreme temperatures.
- **Battery Care:** To preserve battery life, charge the headphones and case regularly, even if not in frequent use. Avoid fully depleting the battery for extended periods.

6. TROUBLESHOOTING

Problem	Possible Solution
Headphones not pairing	<ul style="list-style-type: none"> ◦ Ensure headphones are charged. ◦ Turn off and on Bluetooth on your device. ◦ Place earbuds back in case, close lid, wait 5 seconds, then reopen to re-enter pairing mode. ◦ Forget "CoolBox TWS-01" from your device's Bluetooth list and try pairing again.
Only one earbud working	<ul style="list-style-type: none"> ◦ Ensure both earbuds are charged. ◦ Place both earbuds back in the case, close the lid, then reopen. ◦ Try resetting the headphones (refer to manufacturer's specific reset instructions if available, otherwise, a full charge and re-pairing often resolves this).
No sound	<ul style="list-style-type: none"> ◦ Check device volume. ◦ Ensure headphones are connected to the correct device. ◦ Try playing different audio.
Charging issues	<ul style="list-style-type: none"> ◦ Ensure the USB-C cable is properly connected. ◦ Try a different USB-C cable or power adapter. ◦ Clean the charging contacts on the earbuds and inside the case.

7. SPECIFICATIONS

Feature	Detail
Model Number	COO-AUB-TWS01
Bluetooth Version	5.1 + EDR
Wireless Range	Up to 10 meters
Playback Time	5 hours (headphones), up to 15 hours (with charging case)
Charging Time (Case)	1.5 hours (full charge)
Charging Port	USB-C
Weight (per earbud)	4g
Total Weight (with case)	44g

Feature	Detail
Frequency Range	20 Hz - 20,000 Hz
Impedance	32 Ohm
Material	Plastic
Color	White
Compatible Profiles	HSP, HFP, A2DP, AVRCP

8. WARRANTY AND SUPPORT

CoolBox products are designed for reliability and performance. For warranty information and technical support, please refer to the warranty card included with your purchase or visit the official CoolBox website. Keep your proof of purchase for warranty claims.

For further assistance, you may contact CoolBox customer service through their official channels. Please have your model number (COO-AUB-TWS01) ready when contacting support.

© 2023 CoolBox. All rights reserved.