

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [PRITECH](#) /

› [PRITECH Electric Shaver User Manual](#)

PRITECH LD-8001

PRITECH Electric Shaver User Manual

Model: LD-8001

INTRODUCTION

Thank you for choosing the PRITECH Electric Shaver. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your new shaver. Please read it thoroughly before first use and keep it for future reference.

The PRITECH Electric Shaver is designed for comfortable and efficient hair removal on various body parts, including legs, arms, underarms, and the bikini area. It features a multi-functional blade system and supports both wet and dry shaving.

SAFETY INFORMATION

For your safety, please adhere to the following guidelines:

- Always use the provided charging adapter (5V1A) to avoid damaging the shaver's circuit board. Do not use fast charging devices.
- Do not immerse the shaver body in water; only the shaving head is washable.
- Keep the shaver out of reach of children.
- Do not use the shaver if the blades are damaged or deformed, as this may cause injury.
- Avoid dropping the shaver, as this may damage internal components.
- If the shaver malfunctions, do not attempt to repair it yourself. Contact customer support.
- Before cleaning, ensure the shaver is turned off and unplugged from the power source.

Wattage: 2 Watt-hours.

PACKAGE CONTENTS

Please check the package for the following items:

- PRITECH Electric Shaver (Main Unit)
- USB Charging Cable
- USB Dock Charging Base

- Cleaning Brush
- User Manual




Image: The PRITECH Electric Shaver, its charging dock, USB cable, and cleaning brush, displayed alongside its product packaging.

PRODUCT FEATURES


- **Multi-functional Blade System:** Features a straight side blade, floating foil, and curved side blade for different hair lengths and body areas.
- **Wet & Dry Use:** Suitable for convenient dry shaving or wet shaving with gel/foam in the shower.

- **IPX6 Waterproof:** Shaving head is washable under running water for easy cleaning.
- **USB Rechargeable:** Offers direct charging via USB cable or USB dock charging.
- **Long Battery Life:** Provides up to 80 minutes of cordless use after a 2-hour charge.
- **Ergonomic Design:** Slim and sleek body for comfortable handling.

3-in-1 Stainless Steel Blade



1. Move against the direction of hair growth, and trim long or curly hair shorter with a side blade first.



2. Then shaving off the remaining short hair with the middle foil blade to get a close shaving result.

Image: A detailed view of the shaver head, highlighting the straight side blade, foil middle blade, and curved side blade, along with an LED light.



Dry



Wet

Image: Demonstrations of the shaver's versatility, showing it being used for dry shaving on legs and wet shaving with foam.

SETUP

Charging the Shaver

Before first use, fully charge the shaver for approximately 2 hours. A full charge provides up to 80 minutes of cordless use.

1. Connect the USB charging cable to the shaver or the USB dock charging base.
2. Plug the other end of the USB cable into a 5V1A power adapter (not included), a computer, a battery pack, or a car charger.
3. The charging indicator light will illuminate during charging.

4. Once fully charged, disconnect the shaver from the power source.

Note: Using fast charging devices may damage the circuit board and prevent the razor from turning on after charging. Always use a 5V1A adapter.

Charging Faster, Shaving Longer



80
Mins
Runtime

2
Hours
full Charge



Image: The electric shaver connected to its charging dock, which is plugged into a wall outlet, illustrating the charging process.

OPERATING INSTRUCTIONS

Preparing for Shaving

- For best results, moisten the skin with warm water before shaving.
- Apply shaving foam or oil to reduce irritation, especially for wet shaving.

- If hair is very long, it is recommended to trim it shorter with the straight side blade first before using the foil blade for a closer shave.

Shaving Technique

1. Turn on the shaver by pressing the power button.
2. Hold the shaver at a 30-degree angle against your skin.
3. Move the shaver gently against the direction of hair growth.
4. **For arms and legs:** Use the straight side blade for a smooth shave.
5. **For sensitive areas (underarms, bikini line):** Use the curved blade for a gentle yet effective shave.
6. **For a closer shave:** After trimming longer hairs, use the foil blade system to remove residual short hair.



Image: A visual guide indicating the suitable body areas for shaving with the PRITECH Electric Shaver, including legs, arms, underarms,

back, and bikini lines.



Image: A step-by-step illustration demonstrating how to effectively shave using the PRITECH shaver, including initial trimming and subsequent close shaving with the foil blade.



Image: A visual comparison showing the recommended use of the curved side blade for underarm and bikini hair, and the straight side blade for body, arms, and legs.

After Shaving

After shaving, apply a soothing skincare product to moisturize your skin.

MAINTENANCE AND CLEANING

Cleaning the Shaver Head

Regular cleaning ensures optimal performance and hygiene.

1. Turn off the shaver.
2. Remove the shaving head from the shaver body.
3. Rinse the shaving head under running warm water.
4. Use the provided cleaning brush to remove any remaining hair from the blades and foil.
5. Allow the shaving head to air dry completely before reattaching it to the shaver body or storing.

IPX6 Waterproof

Cleaning the blade under the running water with the brush makes it easier and convenient.



Image: The shaver head being cleaned under running water, demonstrating its IPX6 waterproof feature for easy maintenance.

Blade Replacement

Regularly inspect the blades for signs of wear. If the blades become dull or damaged, replace them promptly to ensure safe and effective shaving. Replacement blades can be purchased from authorized PRITECH retailers or the official website.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is low or depleted.	Charge the shaver for 2 hours using the correct 5V1A adapter.
Shaver pulls hair or does not shave effectively.	Blades are dull or clogged with hair. Hair is too long.	Clean the shaving head thoroughly. If blades are dull, replace them. Trim longer hair before shaving.
Skin irritation after shaving.	Improper shaving technique. Dry shaving without preparation.	Ensure skin is moistened. Use shaving foam/oil. Shave gently against hair growth. Apply soothing skincare product after shaving.
Charging indicator light not working.	Incorrect adapter used. Cable or charging dock is faulty.	Ensure a 5V1A adapter is used. Try a different USB cable or charging port.

SPECIFICATIONS

- Model Name:** LD-8001
- Product Dimensions:** 6.89 x 2.68 x 4.84 inches
- Item Weight:** 9.52 ounces
- Power Source:** Battery Powered (USB Rechargeable)
- Battery Type:** Built-in Lithium Battery
- Runtime:** Up to 80 minutes
- Charging Time:** Approximately 2 hours
- Waterproof Rating:** IPX6 (shaving head washable)
- Manufacturer:** Wenzhou Pritech Industrial Co., Ltd.

WARRANTY AND SUPPORT


PRITECH offers a one-year warranty for this product. For warranty claims, technical support, or any inquiries, please contact PRITECH customer service. Refer to the contact information provided in your product packaging or visit the official PRITECH website.

Manufacturer: Wenzhou Pritech Industrial Co., Ltd.

OFFICIAL PRODUCT VIDEOS

Watch these official videos for additional guidance and demonstrations.

No official seller videos are available for embedding at this time.

	<p>PRITECH LD-8001 Lady Shaver User Manual and Instructions</p> <p>Comprehensive user manual for the PRITECH LD-8001 Lady Shaver, detailing features, specifications, charging, usage, maintenance, and warranty information.</p>
	<p>PRITECH RSM-1577 Electric Shaver User Manual</p> <p>User manual for the PRITECH RSM-1577 electric shaver, covering features, charging, usage, cleaning, maintenance, and warranty information.</p>
	<p>PRITECH RSM-1699 Mini Men's Shaver - User Manual & Specifications</p> <p>Comprehensive user manual and technical specifications for the PRITECH RSM-1699 Mini Men's Shaver, including safety guidelines, operating instructions, cleaning procedures, and troubleshooting tips.</p>
	<p>PRITECH 6in1 Men's Grooming Kit LK-860 User Manual</p> <p>Detailed user manual for the PRITECH 6in1 Men's Grooming Kit (Model LK-860, PR-2614). Includes instructions on setup, charging, usage of various attachments (trimmer, shaver, design trimmer, body trimmer), cleaning, maintenance, and safety guidelines.</p>
	<p>PRITECH RSM-1505 Rechargeable Men's Grooming Set - Instruction Manual</p> <p>User manual for the PRITECH RSM-1505 rechargeable men's grooming set, covering introduction, product structure, charging, usage, cleaning, maintenance, and warranty information.</p>
	<p>PRITECH BCM-1138T Rechargeable Callus Remover User Manual</p> <p>User manual for the PRITECH BCM-1138T rechargeable callus remover. Provides instructions on product introduction, usage, charging, cleaning, roller replacement, specifications, storage, and warranty activation.</p>