

[Manuals.plus](#) /

> [PHIXTON](#) /

> PHIXTON Rechargeable Flashlights High Lumens, USB C Chargeable LED Flashlight, Bright Strong Handheld Flash Lights, Long Lasting, Adjustable Focus, 5 Modes, for Emergencies Hiking Gift 21.0 Watt Hours

PHIXTON PHIXTON

PHIXTON Rechargeable Flashlight User Manual

Model: PHIXTON

INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of your PHIXTON Rechargeable Flashlight. Please read thoroughly before operation.

WHAT'S IN THE BOX

- 1x USB C Flashlight (Rechargeable Battery Included)
- 1x USB C Charging Cable
- 1x Bike Mount
- 1x Gift Box
- 1x Battery Tube & Holster



Image: PIXTON Rechargeable Flashlight with all included accessories neatly packed in its hard case.

SETUP

Battery Installation and Initial Charging

Your flashlight comes with a high-capacity rechargeable battery. Before first use, it is recommended to fully charge the battery.

1. Unscrew the tail cap of the flashlight.
2. Remove the protective insulating sheet from the battery compartment.
3. Insert the rechargeable battery into the flashlight, ensuring correct polarity.
4. Screw the tail cap back on securely to ensure proper function and waterproofing.
5. To charge, push or pull the head of the flashlight to reveal the USB C charging port.
6. Connect the provided USB C cable to the flashlight and a suitable USB power source (e.g., wall charger, power bank, car charger).
7. The charging indicator will turn red while charging and green when fully charged. Charging typically takes 6-8 hours. Avoid charging overnight.

Push the head to find out the USB C Interface



Image: The flashlight head slides forward to expose the hidden USB C charging port.

FAST USB C CHARGING



Image: Illustration showing different methods to charge the flashlight using the USB C cable, including wall sockets, car chargers, power banks, and notebooks.

Your browser does not support the video tag.

Video: A detailed unboxing and setup guide for the PHIXTON rechargeable flashlight, including battery installation and initial charging instructions.

Bike Mount Installation

The included bike mount allows you to attach the flashlight to your bicycle handlebars for hands-free illumination during cycling.




Image: Visual representation of the flashlight's five distinct light modes: High, Medium, Low, Strobe, and SOS.



Image: Close-up of the flashlight demonstrating the power button and its function for switching between modes.

Adjustable Focus (Zoom Function)

The flashlight features an adjustable focus mechanism to switch between a narrow spotlight and a wide floodlight.

- To adjust the beam, gently push or pull the head of the flashlight.
- Pushing the head IN will narrow the beam for long-distance spotlighting.
- Pulling the head OUT will widen the beam for close-range floodlighting.



Image: Demonstration of the adjustable focus feature, showing how pushing the head in creates a spotlight for far distances and pulling it out creates a floodlight for near distances.

Your browser does not support the video tag.

Video: A review highlighting the 5000 lumen brightness, adjustable focus, and emergency SOS mode of the flashlight.

MAINTENANCE

- Keep the flashlight clean and dry. Wipe with a soft, damp cloth.
- Store in a cool, dry place when not in use.
- Ensure the battery is fully charged before long-term storage to maintain battery health.
- The flashlight is waterproof and shockproof, but avoid prolonged submersion in water or extreme impacts.



Image: The flashlight is shown with water droplets, highlighting its waterproof and durable aluminum construction.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Flashlight does not turn on.	Battery not installed correctly or not charged. Insulating sheet not removed.	Ensure battery polarity is correct. Remove insulating sheet. Charge the battery fully.
Light turns off automatically.	Low battery. Overheating.	Recharge the battery. Allow flashlight to cool down if used for extended periods on high settings.
Beam is dim or flickering.	Low battery. Loose connections.	Recharge the battery. Ensure tail cap and head are screwed on tightly.

SPECIFICATIONS

- **Brand:** PHIXTON
- **Model:** PHIXTON (T04)
- **Light Source Type:** LED
- **Brightness:** 1000 Lumens (up to 5000 Lumens peak)

- **Light Path Distance:** 300 Meters
- **Power Source:** USB C Charging & Battery Powered
- **Battery Type:** Lithium Ion (Rechargeable)
- **Runtime:** Up to 15 hours
- **Material:** Aluminum
- **Water Resistance Level:** Waterproof
- **Special Features:** Adjustable Light Modes (5 Modes), Long Range & Long Lasting, Adjustable Focus, Durable & Waterproof
- **Product Dimensions:** 3"D x 3"W x 3"H
- **Item Weight:** 12.6 ounces

WARRANTY AND SUPPORT

The PHIXTON Rechargeable Flashlight comes with a Limited Warranty. For any issues or inquiries, please contact PHIXTON customer service. We are committed to providing high-quality products and excellent customer service. Our customer service team is available 24 hours online to assist you. Please feel free to contact us in the first instance if there is anything wrong with the product.