

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Kinganda](#) /
- › [Kinganda Wireless Earbuds Model 750 User Manual](#)

### Kinganda 750

# Kinganda Wireless Earbuds Model 750 User Manual

Brand: Kinganda | Model: 750

## 1. PRODUCT OVERVIEW

The Kinganda Model 750 Wireless Earbuds offer a high-quality audio experience with advanced features designed for convenience and durability. These in-ear Bluetooth earphones provide HiFi stereo sound, efficient ENC noise cancellation for clear calls, and intuitive touch controls. They are lightweight, waterproof, and compatible with a wide range of devices.





Image: Kinganda Model 750 Wireless Earbuds resting in their charging case, showcasing the compact design and LED battery display.

## 2. WHAT'S IN THE BOX

- Kinganda Model 750 Wireless Earbuds (Left and Right)
- Charging Case with LED Display
- USB Type-C Charging Cable
- User Manual

## 3. GETTING STARTED

### 3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the provided USB Type-C cable to the charging port on the case and a compatible USB power source. The LED display on the case will show the charging status for both the case and individual earbuds (L for Left, R for Right).

# UP TO **48** HOURS BATTERY LIFE



## Type-C Fast Charging

8H  
Playing Time

1H  
Charging Time

5-6 times  
Charging case



Image: The Kinganda earbuds charging case with its LED display showing battery percentages for both earbuds and the case, highlighting the Type-C charging port.

A single charge provides up to 8 hours of playback for the earbuds, and the charging case offers an additional 40 hours, totaling 48 hours of combined use.

## 3.2 One-Step Pairing

The Kinganda Model 750 earbuds feature one-step automatic pairing for ease of use.

1. Ensure your device's Bluetooth is turned on.
2. Open the charging case and remove both earbuds. They will automatically power on and enter pairing mode. The red and blue lights on the earbuds will flash alternately.
3. On your mobile phone or tablet, go to Bluetooth settings and search for "YYK-750".
4. Select "YYK-750" to connect. Once connected, a voice prompt will confirm, and the earbud lights will stop flashing.

After the initial pairing, the earbuds will automatically connect to your last paired device when removed from the case.

# AUTOMATIC PAIRING - INSTANT CONNECTION



iOS



Windows



Android

## Broad Compatibility



Image: A smartphone screen showing Bluetooth settings with "YYK-750" connected, next to the earbuds and their charging case, illustrating the automatic pairing process.

Your browser does not support the video tag.

Video: A demonstration of the Kinganda Wireless Earbuds, including unboxing, showing the charging case's LED display, and demonstrating the pairing process and comfortable fit. This video highlights the ease of use and key features.

## 4. OPERATION (TOUCH CONTROLS)

The Kinganda Model 750 earbuds are equipped with smart touch sensors for convenient control of your audio and calls without needing to access your device.

Function	Action
Play/Pause Music	Single tap on either earbud.
Next Track	Double tap on the right earbud.
Previous Track	Double tap on the left earbud.
Volume Up	Triple tap on the right earbud.
Volume Down	Triple tap on the left earbud.
Answer/End Call	Single tap on either earbud.
Reject Call	Press and hold either earbud for 2 seconds.
Activate Voice Assistant	Press and hold either earbud for 3 seconds.

## 5. KEY FEATURES EXPLAINED

### 5.1 Clear Call & HiFi Stereo Sound

Equipped with 13mm speakers and triple-layer composite diaphragms, these earbuds deliver deep bass, stunning treble, and clear mids for a rich HiFi stereo experience. Each earbud includes a built-in microphone with CVC noise reduction, which effectively reduces background noise by 93%, ensuring your voice is heard clearly during phone calls.

# CVC8.0

## EFFICIENT NOISE CANCELLATION



Clearly communicate your voice to the person you are calling,  
even when there is a lot of ambient noise.

## HIFI STEREO

**Wider Range of Tones**  
**Deeper Bass**  
**Brighter Treble**



Image: Diagram illustrating CVC8.0 efficient noise cancellation and HiFi stereo sound, emphasizing clear communication and a wider range of tones, deeper bass, and brighter treble.

### 5.2 IPX7 Waterproof Function

With an IPX7 waterproof rating, the nano-coating on the earbud surface prevents water and sweat from penetrating. This makes the Kinganda Model 750 suitable for sports activities, workouts, or use in light rain, offering protection against moisture.



# IPX7 WATERPROOF FUNCTION

No fear of Sweating  
No fear of Rain Spray



## CONVENIENT TO CARRY

Enjoy your music  
anywhere, anytime



Image: The Kinganda earbuds and charging case with water droplets, illustrating the IPX7 waterproof function, indicating resistance to sweat and rain spray.

### 5.3 Broad Compatibility & Versatile Use

The earbuds are compatible with iOS, Windows, and Android devices, including cellphones and laptops. Their lightweight design (only 4g per earbud) and comfortable fit make them ideal for various activities such as gaming, listening to music,



traveling, sports, daily life, and web meetings.

# APPLICABLE TO ANY SCENE AND STYLE




Image: A collage showing the Kinganda earbuds being used in different scenarios: during sport, in daily life, during a web meeting, and while enjoying music, demonstrating their versatility.

The earbuds support both mono and twin stereo modes, allowing each earbud to be used independently.

## 6. TROUBLESHOOTING

If you encounter issues with your Kinganda Model 750 earbuds, please refer to the following common solutions:

- **Earbuds not pairing:** Ensure both earbuds are removed from the charging case. Check that Bluetooth is enabled on your device and that "YYK-750" is selected. If issues persist, try resetting the earbuds.
- **No sound or intermittent connection:** Ensure earbuds are fully charged. Check the Bluetooth connection on your device. Move closer to your device to avoid interference.
- **Charging issues:** Verify the Type-C cable is securely connected to both the case and the power source. Ensure the power source is active. Clean the charging contacts on the earbuds and inside the case if necessary.
- **How to Reset:** To reset the earbuds, place both earbuds back into the charging case. Close the lid, wait a few seconds, then open the lid and remove them again. This often resolves minor connectivity issues.

For further assistance, please contact Kinganda customer support.

## 7. SPECIFICATIONS

Feature	Detail
Brand	Kinganda
Model Name	750
Connectivity Technology	Wireless (Bluetooth 5.2)
Audio Driver Type	Dynamic Driver (13mm speakers)
Noise Cancellation	ENC (Environmental Noise Cancellation) for calls
Battery Life (Earbuds)	Up to 8 hours
Total Playtime with Case	Up to 48 hours
Charging Interface	Type-C
Control Type	Touch Control
Water Resistance Level	IPX7 Waterproof
Earbud Weight	Approx. 4g each
Ear Placement	In Ear
Compatible Devices	Cellphones (iOS, Android), Laptops (Windows)

## 8. SAFETY INFORMATION

- Avoid prolonged exposure to high volume levels to prevent hearing damage.
- Do not disassemble, repair, or modify the product.
- Keep the earbuds and charging case away from extreme temperatures, direct sunlight, and open flames.
- While IPX7 waterproof, avoid submerging the earbuds in water for extended periods or exposing them to strong water jets. The charging case is not waterproof.
- Use only the provided charging cable or a certified Type-C cable for charging.

- Dispose of the product responsibly according to local regulations.

## 9. WARRANTY AND SUPPORT

Kinganda products are designed and manufactured to the highest quality standards. For detailed warranty information, please refer to the warranty card included with your purchase or visit the official Kinganda website.



If you require technical support or have any questions regarding your Kinganda Model 750 Wireless Earbuds, please contact our customer support team:

**Email:** [support@kinganda.com](mailto:support@kinganda.com)

**Website:** [www.kinganda.com](http://www.kinganda.com)

Please have your model number (750) and purchase details ready when contacting support.

### Related Documents - 750

	<p><a href="#">YYK-Q63 Bluetooth 5.3 Wireless Earbuds User Manual</a></p> <p>Comprehensive user manual for the YYK-Q63 Bluetooth 5.3 wireless earbuds, covering setup, operation, specifications, troubleshooting, and safety precautions in multiple languages.</p>
	<p><a href="#">Kinganda YYK-Q71 Clip-On Wireless Earbuds User Manual</a></p> <p>Comprehensive user manual for the Kinganda YYK-Q71 Clip-On Wireless Earbuds, covering package contents, wearing instructions, product specifications, power on/off, pairing, button controls, charging, reset operations, safety warnings, and after-sales service.</p>
	<p><a href="#">Q16 Pro Open-Ear True-Wireless Earbuds - User Guide and Features</a></p> <p>Discover the Q16 Pro Open-Ear True-Wireless Earbuds. Featuring ergonomic design, open-ear air conduction, IPX6 waterproofing, and 14.2mm drivers for powerful sound. Includes quick start guide and FCC compliance information.</p>

# CLIP ON WIRELESS EARBUDS

## Product Manuals



### 1. Package contents



#### Let's check first.

Make sure you have the complete set before using it. If there is anything missing, please contact the retailer where you purchased it.

#### Packet contents

- Earbuds\*2
- Charging box\*1
- Type-C charging cable\*1
- Product Manual\*1

### 2. Wearing method




1. Check the Left (L) and Right (R) of the earphone. Please attach it so as not to mix it up on the left and right.
2. Hold your ears with one hand and pinch them like earplugs. Adjust the position of the speaker so that it fits the ear hole.

### 3. Product specifications

Model	YYK-Q71
Wireless version	Bluetooth 5.2
Transmission distance	20M
Call time	4 hours
Standby time	80 hours
Charging time	1 hour
Waterproof	IPX4
Product weight	5g
Overall weight	2 * (earbud + 1 * charging compartment)
Color	Black
Complementary items	Charging compartment, charging cable, manual
Size	6.13x7.5x20x18.13mm

### 4. Product Description



### 5. Power on/off

**Power on**  
When the main body of the earphone is removed from the charging case, the earphone will power on and automatically pair.

**Power off**  
When the main body of the earphone is stored in the charging case, the power turns off automatically. (Charging will not start.)

### 6. Connection Pairing



**[Take out]**  
The LED flashes red and blue alternately for 3 seconds, then one of the earphones turns off.

**[Pairing standby mode]**  
The LED flashes red and blue alternately for another single earphone.

**[After the second use]**  
When the earphone is taken out, it will automatically reconnect again.

### 7. Button




#### Audio control

Function	Operation method
Play/Pause music	Press the right button when playing music.
Next track	Press the left button when playing music.
Previous track	Press the right button when playing music.
Volume up/down	Hold down the right button.

#### Answering and ending a call

Function	Operation method
Answer the phone	Press the right button when answering.
End the call	Press the right button when ending the call.

### 8. How to charge



Charging is in progress. Charging is complete.

• **Charging status of the headset**  
When the headset is in the charging case, the LED of the headset is red. The LED of the headset is green when the headset is fully charged.

• **Charging is complete**  
When the headset is fully charged, the LED of the headset is green. The LED of the headset is red when the headset is not fully charged.



• **Charging status of the phone case**  
When the phone case is in the charging case, the LED of the phone case is red. The LED of the phone case is green when the phone case is fully charged.


• **Reset operation**  
When the headset is fully charged, the LED of the headset is green. The LED of the headset is red when the headset is not fully charged.

### 9. Reset operation

• **Reset operation**  
When the headset is fully charged, the LED of the headset is green. The LED of the headset is red when the headset is not fully charged.

### 10. Safety Warning

The following instructions must be observed in order to prevent injury and property damage to the user or others. Please read the text after carefully understanding the contents of the illustrations described and be sure to follow the instructions.



• **Do not use the product in a hazardous environment.**  
Do not use the product in a hazardous environment, such as near fire, gas, or other flammable materials.

• **Do not use the product in a hazardous environment.**  
Do not use the product in a hazardous environment, such as near fire, gas, or other flammable materials.

• **Do not use the product in a hazardous environment.**  
Do not use the product in a hazardous environment, such as near fire, gas, or other flammable materials.

• **Do not use the product in a hazardous environment.**  
Do not use the product in a hazardous environment, such as near fire, gas, or other flammable materials.

• **Do not use the product in a hazardous environment.**  
Do not use the product in a hazardous environment, such as near fire, gas, or other flammable materials.

• **Do not use the product in a hazardous environment.**  
Do not use the product in a hazardous environment, such as near fire, gas, or other flammable materials.

• **Do not use the product in a hazardous environment.**  
Do not use the product in a hazardous environment, such as near fire, gas, or other flammable materials.

• **Do not use the product in a hazardous environment.**  
Do not use the product in a hazardous environment, such as near fire, gas, or other flammable materials.

• **Do not use the product in a hazardous environment.**  
Do not use the product in a hazardous environment, such as near fire, gas, or other flammable materials.

• **Do not use the product in a hazardous environment.**  
Do not use the product in a hazardous environment, such as near fire, gas, or other flammable materials.

• **Do not use the product in a hazardous environment.**  
Do not use the product in a hazardous environment, such as near fire, gas, or other flammable materials.



• **Do not use the product in a hazardous environment.**  
Do not use the product in a hazardous environment, such as near fire, gas, or other flammable materials.

• **Do not use the product in a hazardous environment.**  
Do not use the product in a hazardous environment, such as near fire, gas, or other flammable materials.

• **Do not use the product in a hazardous environment.**  
Do not use the product in a hazardous environment, such as near fire, gas, or other flammable materials.

## YYK-Q71 Clip-On Wireless Earbuds: User Manual & Features

Comprehensive user manual for the YYK-Q71 Clip-On Wireless Earbuds. Learn about package contents, wearing, specifications, pairing, controls, charging, and safety.

	<p><a href="#">Kinganda HYK-580 Wireless Earbuds User Manual</a></p> <p>Comprehensive user manual for the Kinganda HYK-580 wireless earbuds, covering setup, pairing, operation, charging, and troubleshooting.</p>
	<p><a href="#">YYKSQ71 Bluetooth Headset User Manual and Specifications</a></p> <p>This document provides detailed specifications and usage instructions for the YYKSQ71 Bluetooth headset, including charging, power on/off, resetting, and music/call controls.</p>