

Smeg BLF03PKEU

Smeg BLF03PKEU 1.5 L Table Blender Instruction Manual

INTRODUCTION

This instruction manual provides essential information for the safe and efficient operation of your Smeg BLF03PKEU 1.5 L Table Blender. Please read this manual thoroughly before first use and keep it for future reference. Proper use and maintenance will ensure the longevity and optimal performance of your appliance.

IMPORTANT SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- **Read all instructions:** Before operating the blender, read all instructions carefully.
- **Electrical Safety:** Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting. Do not immerse the motor base, cord, or plug in water or other liquids.
- **Children:** This appliance should not be used by children. Close supervision is necessary when any appliance is used near children.
- **Moving Parts:** Avoid contact with moving parts. Always ensure the lid is securely in place before operating the blender.
- **Blades:** Blades are sharp. Handle with extreme care when cleaning.
- **Hot Liquids:** Exercise caution when blending hot liquids, as steam can cause burns. Do not fill the blender jar beyond the maximum hot liquid level.
- **Overload Protection:** The blender is equipped with a motor thermal protection system. If the motor overheats, the appliance will automatically shut off. Allow it to cool down before resuming use.
- **Damage:** Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner. Contact authorized service for examination, repair, or adjustment.
- **Accessories:** The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.

- **Unplug:** Always unplug the appliance from the outlet when not in use, before assembling or disassembling parts, and before cleaning.

PRODUCT OVERVIEW

The Smeg BLF03PKEU Table Blender combines iconic design with powerful performance for a variety of blending tasks. Familiarize yourself with its components and controls.

Components

- **Motor Base:** The main unit housing the 800W motor, controls, and anti-slip feet.
- **1.5 L Tritan Renew Jar:** Durable, BPA-free blending jar with measurement markings and an ergonomic handle.
- **Lid with Measuring Cap:** Secure lid with a removable cap for adding ingredients during blending.
- **Stainless Steel Blades:** Double removable blades designed for efficient blending.

Controls

- **Speed Dial (0-4):** Select from 4 speed levels for varying blending needs.
- **Pulse Button:** Provides short bursts of power for controlled blending.
- **Pre-set Functions:** Dedicated settings for Smoothie, Ice Crush, and Self-Clean.



Figure 1: Front view of the Smeg BLF03PKEU Table Blender, showing the motor base, jar, and controls.



Figure 2: Close-up view of the control panel, including the speed dial and pulse button.

SETUP AND FIRST USE

Unpacking

Carefully remove all packaging materials and ensure all components are present. Keep packaging for future storage or disposal.

Initial Cleaning

1. Before first use, wash the blender jar, lid, and measuring cap in warm, soapy water. Rinse thoroughly and dry.
2. Wipe the motor base with a damp cloth. Do not immerse the motor base in water.

Assembly

1. Place the motor base on a clean, dry, and stable surface.
2. Ensure the stainless steel blades are securely attached to the bottom of the jar.
3. Place the blender jar onto the motor base, ensuring it is correctly aligned and locked into position. The blender will not operate if the jar is not properly seated.
4. Place the lid onto the jar and secure it. Insert the measuring cap into the lid opening.

OPERATING INSTRUCTIONS

Your Smeg BLF03PKEU blender offers versatile blending options with its speed settings and pre-set functions.

General Blending

1. Prepare ingredients and place them into the blender jar. Do not exceed the MAX fill line.
2. Securely attach the lid and measuring cap.
3. Plug the blender into a power outlet.
4. Turn the speed dial to your desired speed (1-4) or select a pre-set function.
5. To stop blending, turn the dial back to '0' or press the 'START/STOP' button if using a pre-set function.
6. Always wait for the blades to stop completely before removing the lid or jar.

Pre-set Functions

- **Smoothie:** Ideal for creating smooth, creamy beverages from fruits and liquids.
- **Pulse:** Use for short bursts of power to chop ingredients, mix gently, or achieve desired consistency.
- **Ice Crush:** Specifically designed to crush ice cubes efficiently for drinks or desserts.
- **Self-Clean:** A convenient function for quick and easy cleaning of the blender jar.

Your browser does not support the video tag.

Video 1: Official Smeg BLF03 Blender demonstration, showcasing its features and various blending functions like smoothie, ice crush, and self-clean.

MAINTENANCE AND CLEANING

Regular cleaning and proper maintenance will extend the life of your blender.

Self-Clean Function

1. After use, rinse the jar.

2. Fill the jar with warm water up to the 0.75 L mark and add a few drops of dish soap.
3. Secure the lid and measuring cap.
4. Select the 'Self-Clean' pre-set function.
5. Once the cycle is complete, empty the jar, rinse thoroughly with clean water, and dry.

Manual Cleaning

- **Blender Jar and Lid:** These parts are dishwasher safe. For hand washing, use warm, soapy water and a non-abrasive sponge. Handle blades with extreme caution.
- **Motor Base:** Wipe the motor base with a soft, damp cloth. Never immerse the motor base in water or any other liquid.
- **Storage:** Store the blender in a dry place with the lid slightly ajar to prevent odors. Use the integrated cable wrap for tidy storage.

TROUBLESHOOTING

If you encounter any issues with your blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; Jar not correctly seated; Overload protection activated.	Check power connection; Ensure jar is locked into place; Unplug, wait 15 minutes for motor to cool, then restart.
Ingredients not blending smoothly.	Too little liquid; Jar overfilled; Ingredients too large.	Add more liquid; Reduce ingredient quantity; Cut ingredients into smaller pieces. Use Pulse function for stubborn ingredients.
Leakage from the bottom of the jar.	Blades not properly tightened; Seal damaged.	Ensure blades are securely tightened; Inspect the seal for damage and replace if necessary.
Unusual noise or odor.	Overloading; Foreign object in jar; Motor issue.	Reduce load; Check for foreign objects and remove; If problem persists, discontinue use and contact customer support.

If the problem persists after trying these solutions, please contact Smeg customer support.

SPECIFICATIONS

Feature	Detail
Brand	Smeg
Model	BLF03PKEU
Capacity	1.5 Liters

Feature	Detail
Power	800W
Voltage	240 Volt
Number of Speeds	4
Special Features	Pre-programmed functions (Smoothie, Pulse, Ice Crush, Self-Clean), Motor safety lock, Anti-slip base, Integrated cable wrap
Product Dimensions	24 x 27.5 x 35 cm
Item Weight	5 kg

WARRANTY AND SUPPORT

For warranty information, product registration, or technical support, please refer to the warranty card included with your product or visit the official Smeg website. Keep your proof of purchase for any warranty claims.

Smeg Official Website: www.smeg.com