

Manuals.plus /

> [FOPETT](#) /

> FOPETT V2030 2.4GHz Wireless Keyboard and Mouse Set Instruction Manual

FOPETT V2030

FOPETT V2030 2.4GHz Wireless Keyboard and Mouse Set

Instruction Manual

Brand: FOPETT | Model: V2030

1. INTRODUCTION

Thank you for choosing the FOPETT V2030 2.4GHz Wireless Keyboard and Mouse Set. This manual provides essential information for setting up, operating, and maintaining your new wireless peripherals. Please read these instructions carefully before use and retain them for future reference.

2. PACKAGE CONTENTS

Ensure all items are present in your package:

- 1 x FOPETT V2030 Wireless Keyboard
- 1 x FOPETT Wireless Mouse
- 1 x USB Receiver (stored in the mouse battery compartment)
- 1 x User Manual

Note: Batteries are not included. The keyboard requires two 1.5V AAA batteries, and the mouse requires one 1.5V AA battery.

3. SETUP INSTRUCTIONS

Follow these steps to set up your FOPETT wireless keyboard and mouse:

1. Install Batteries:

- For the keyboard: Open the battery compartment on the underside of the keyboard and insert two 1.5V AAA batteries, ensuring correct polarity.
- For the mouse: Open the battery compartment on the underside of the mouse. Insert one 1.5V AA battery, ensuring correct polarity.

- 2. Retrieve USB Receiver:** The shared Nano USB receiver is conveniently stored inside the mouse's battery compartment. Carefully remove it.

3. **Connect Receiver:** Plug the USB receiver into an available USB port on your computer, laptop, Smart TV, or other compatible device.
4. **Power On:**
 - For the keyboard: Locate the power-saving switch on the keyboard (often on the side or back) and slide it to the 'ON' position.
 - For the mouse: The mouse typically powers on automatically once the battery is inserted and the receiver is connected.
5. **Automatic Connection:** The keyboard and mouse should automatically connect to the receiver. No additional software installation is required (Plug and Play).



Figure 3.1: FOPETT V2030 Wireless Keyboard and Mouse Set (Blue Colorful variant).



Figure 3.2: Overview of the FOPETT Wireless Keyboard and Mouse Combo, highlighting the 2.4GHz chip and stable wireless receiver.

Video 3.1: A seller-provided video demonstrating the Blue Colorful Wireless Keyboard and Mouse Combo for Laptop, showing its features and use.

4. OPERATING INSTRUCTIONS

4.1 Keyboard Functions

- **Full-Size Layout:** The keyboard features a 105-key full-size US layout for comprehensive functionality.
- **Multimedia Shortcuts:** Access 12 function keys (F1-F12) for quick control over music, volume, email, and more. By default, the media functions are active. To use F1-F12 functions, press the 'Fn' key simultaneously or activate 'Fn Lock' (often F11).
- **Ergonomic Design:** The keyboard is designed with a comfortable tilt angle for improved typing posture.
- **Indicator Lights:** Three indicator lights show Num Lock, Caps Lock, and battery level status.
- **Power-Saving Switch:** Use the dedicated switch to turn off the keyboard when not in use to conserve battery power.

Improve Working Efficiency

Full size keyboard with US layout is fully functional to meet your daily demands. 3 indicator lights are easy to recognize. 12 Multimedia shortcuts make it quickly access to homepage, volume and mouse



Figure 4.1: The FOPETT keyboard showcasing its full-size layout, multimedia shortcuts, and indicator lights for enhanced working efficiency.

4.2 Mouse Functions

- **Silent Clicks:** The mouse utilizes silent micro-motion technology for quiet operation, minimizing disturbance.
- **DPI Settings:** The mouse operates at 1600 DPI for fast and precise cursor control.
- **Ergonomic Design:** Its contoured shape and sweat-resistant, skin-friendly finish provide comfort during extended use.
- **Automatic Power Saving:** The mouse enters auto-sleep mode after 3 seconds of inactivity to conserve battery. Press any key to reactivate.



Figure 4.2: The ergonomic design of the FOPETT wireless mouse, crafted for comfortable handling.



Figure 4.3: The FOPETT wireless keyboard and mouse set demonstrating wide compatibility with various devices and operating systems.

Video 4.1: A seller-provided video showcasing the FOPETT Wireless Keyboard and Mouse Set with its switch button, demonstrating its functionality and design.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the keyboard and mouse. For stubborn dirt, a slightly damp cloth can be used, ensuring no liquid enters the device.
- **Battery Replacement:** Replace batteries when the battery level indicator light on the keyboard signals low power, or when the mouse responsiveness decreases. Always use fresh, high-quality batteries of the specified type (AAA for keyboard, AA for mouse).
- **Storage:** When not in use for extended periods, turn off the keyboard using its power switch and store the USB receiver in the mouse's battery compartment to prevent loss.
- **Splash Resistance:** The keyboard features a waterproof conductive film designed to allow liquids to flow out from within the membrane, offering some splash resistance. However, avoid submerging the device in water.

6. TROUBLESHOOTING

6.1 Common Issues and Solutions

- **No Connection/Interference:**
 - Ensure the USB receiver is securely plugged into a working USB port.
 - Check if the keyboard and mouse are powered on and have fresh batteries.
 - Move the keyboard and mouse closer to the USB receiver (within 10 meters).
 - Avoid using the devices near strong electromagnetic interference sources.
 - If connection issues persist, try re-pairing the devices by removing and reinserting the USB receiver, then

turning the devices off and on.

- **Lost or Damaged USB Receiver:** If your USB receiver is lost or damaged, please contact FOPETT customer support for a replacement.
- **F1-F12 Keys Not Working as Expected:** The keyboard's F1-F12 keys are set to multimedia functions by default. To use their standard F1-F12 functions, press the 'Fn' key simultaneously with the desired F-key, or activate the 'Fn Lock' function (often by pressing F11).

7. SPECIFICATIONS

Feature	Detail
Model Number	V2030
Connectivity Technology	2.4GHz Wireless (USB Receiver)
Keyboard Dimensions	17.5 x 5.5 x 1.3 inches (44.5 x 14 x 3.3 cm)
Keyboard Weight	1.57 lbs (710g)
Mouse Dimensions	4.1 x 2.5 x 1.0 inches (10.4 x 6.35 x 2.54 cm)
Mouse Weight	0.13 lbs (60g)
Mouse DPI	1600
Keyboard Battery	2 x 1.5V AAA (not included)
Mouse Battery	1 x 1.5V AA (not included)
Special Feature	Round Key, Ergonomic Tilt Angle, Silent Mouse Clicks, Power-Saving Switch, Splash Resistance
Compatible Devices	PC, Laptops, MacBooks, Desktops, Chromebooks, Smart TVs
Compatible OS	Windows XP/ME/Vista/7/8/10/11 (Hotkeys may not be fully compatible with Mac systems)

8. WARRANTY AND SUPPORT

FOPETT offers a three-year worry-free warranty and a 60-day money-back guarantee or replacement option for this wireless keyboard and mouse set.

If you have any inquiries or concerns regarding your product, or if you encounter any issues such as receiving a defective item or needing a replacement USB receiver, please do not hesitate to contact FOPETT customer support via Amazon email. Your satisfaction is our top priority, and we are committed to providing satisfactory solutions.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C4TGCPM7>

More documents and user manuals: **<https://manuals.plus/>**