Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SoBuy FST92-W

SoBuy FST92-W Padded Wooden Folding Chair Instruction Manual

Model: FST92-W | Brand: SoBuy

1. Product Overview

The SoBuy FST92-W Padded Wooden Folding Chair is a versatile and space-saving seating solution designed for both indoor and outdoor use. Crafted from quality beech and poplar wood, it offers stability and durability with a maximum load capacity of 120 kg. Its natural finish complements various decor styles. The chair features a soft, padded seat and an ergonomic backrest for optimal comfort during prolonged use. Non-slip feet ensure stability on different floor types.



Image: The SoBuy FST92-W Padded Wooden Folding Chair shown in a modern kitchen environment, highlighting its aesthetic appeal.

2. Unpacking and Initial Setup

Your SoBuy FST92-W chair comes ready to use, requiring no assembly. Simply remove it from its packaging, unfold it, and it's ready for immediate use. This saves time and effort, making it an ideal extra seating option for dining rooms or living rooms, especially when entertaining guests.



Image: The SoBuy FST92-W chair in its fully unfolded state, ready for immediate use without assembly.

3. Operating Instructions: Folding and Unfolding

The chair is designed for easy folding and unfolding to maximize space efficiency. To unfold, gently pull the backrest and seat apart until the chair locks into its open position. To fold, push the seat upwards towards the backrest until the chair collapses into a compact form for storage. Always ensure the chair is fully locked in place before sitting.



Image: A visual representation of the chair in both its unfolded and folded states, demonstrating its space-saving design.

4. Maintenance and Care

To maintain the appearance and longevity of your SoBuy FST92-W chair, follow these simple care instructions:

- **Cleaning:** Wipe the wooden frame with a soft, damp cloth. For the padded seat and backrest, the covers are removable for easy cleaning.
- **Stains:** For spills on the fabric, remove the cover and spot clean with a mild detergent and water. Allow to air dry completely before reattaching.
- **Avoid:** Do not use abrasive cleaners or harsh chemicals on any part of the chair. Avoid prolonged exposure to direct sunlight or extreme humidity to prevent damage to the wood.



Image: A close-up view illustrating the removable seat and backrest covers, facilitating easy cleaning and maintenance.

5. Safety Information

Please read and adhere to the following safety guidelines to ensure safe use of your folding chair:

- **Weight Limit:** Do not use if the weight exceeds 120 kg (264 lbs).
- **Stability:** Do not use on unstable or uneven surfaces. Ensure all legs are firmly on the ground before sitting.
- **Folding/Unfolding:** Open and fold the chair carefully to avoid the risk of injury from pinching or sudden movement.
- **Children:** Keep out of reach of children when folding or unfolding, and supervise children when they are using the chair.

6. Product Specifications

Detailed specifications for the SoBuy FST92-W Padded Wooden Folding Chair:

Feature	Specification
Brand	SoBuy
Model Number	FST92-W
Color	White and Wood
Material	Beech Wood (frame), Fabric (seat), Foam (filling)
Product Dimensions (Depth x Width x Height)	47.5 cm x 59 cm x 77 cm
Item Weight	6.4 kg
Seat Height	44 cm
Seat Depth	40 cm
Maximum Recommended Weight	120 kg
Special Features	Foldable, Padded
Assembly Required	No
Care Instructions	Wipe clean
Indoor/Outdoor Use	Indoor



Image: A diagram detailing the precise measurements of the SoBuy FST92-W chair.

7. Troubleshooting

The SoBuy FST92-W chair is designed for durability and ease of use. Should you encounter any issues, please consider the following:

- **Stability Issues:** Ensure the chair is fully unfolded and locked into position. Check that all four feet are on a flat, stable surface.
- **Folding/Unfolding Difficulty:** Apply gentle, even pressure when folding or unfolding. Do not force the mechanism. Ensure no obstructions are present.
- **Damage:** If any part of the chair appears damaged, discontinue use immediately and contact customer

support.

8. Warranty and Support

SoBuy is committed to providing innovative and modern furnishing solutions. For any questions, suggestions, or support needs regarding your FST92-W Padded Wooden Folding Chair, please do not hesitate to contact us. We will do our best to respond to your needs and inquiries.

Please refer to your purchase documentation or the SoBuy official website for specific warranty details and contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question