

[Manuals.plus](#) /

> [Luqeeq](#) /

> Luqeeq Electric Head Hair Trimmer User Manual - Model Luqeeq3h260579fu

Luqeeq Luqeeq3h260579fu

Luqeeq Electric Head Hair Trimmer User Manual

Model: Luqeeq3h260579fu

INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Luqeeq Electric Head Hair Trimmer. Please read this manual thoroughly before first use and retain it for future reference.

The Luqeeq Electric Head Hair Trimmer is designed for personal grooming, specifically for trimming and cutting hair on the head, face, neck, and jawline. It features a rotary blade system, waterproof design, and is rechargeable for cordless operation.

SAFETY INFORMATION

Important Safety Instructions: Read all instructions before using this appliance.

- Do not immerse the charging cable or power adapter in water or other liquids.
- Keep the appliance away from children.
- Ensure the appliance is fully dry before charging.
- Do not use the appliance if it is damaged. Contact customer support for assistance.
- Only use the provided USB cable for charging.
- Avoid using the trimmer on irritated or broken skin.
- Actual product packaging and materials may contain more and different information than what is shown on our website. We recommend that you do not rely solely on the information presented and that you always read labels, warnings, and directions before using a product.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 x Electric Head Hair Clipper (with Caliper)
- 1 x USB Charging Cable
- 1 x Cleaning Brush



Image: The Luqeeq Electric Head Hair Trimmer, accompanied by its USB charging cable and a small cleaning brush.

PRODUCT FEATURES

- **Anti-Rust and Waterproof Design:** Constructed with steel components to prevent rust and skin irritation. The 360° rotary blade system is fully waterproof, allowing for easy cleaning under running water.
- **Efficient Head Shaving:** Features Skin Protect blades capable of up to 90,000 cutting actions per minute for a fast and close shave. Designed for quick and accurate hair removal.
- **Ergonomic Design:** The trimmer's design conforms to body contours, with blades that automatically adjust to the curves of the head, face, neck, and jaw for comfortable trimming without skin damage.
- **Easy Operation:** Simple to use for self-grooming. The shaving head can be easily removed for washing and maintenance.
- **USB Fast Charging:** Equipped with a robust lithium-ion battery, offering 60 minutes of cordless operation after a 1.5-hour USB charge.

SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Initial Charge:** Before first use, fully charge the trimmer. Connect the USB charging cable to the trimmer's charging port and plug the other end into a compatible USB power source (e.g., computer, wall adapter). The digital display will indicate charging status.

USB charging



Image: The trimmer connected to a USB port for charging. Below, a sequence of images demonstrates how to detach the shaving head for cleaning or replacement.

3. **Inspect:** Ensure the shaving head is securely attached before use.

OPERATING INSTRUCTIONS

1. **Power On/Off:** Press the power button located on the top of the trimmer to turn the device on or off. The digital display will show the remaining battery life in minutes.

Quick trimming, full self service haircut



Image: A close-up of the trimmer's top, highlighting the power button and the digital display which shows the remaining operating time.

2. **Shaving Technique:** Gently press the trimmer against your skin and move it in circular motions for an even shave. The flexible head will adapt to the contours of your head and face.



Shaved head



brush cut

Image: Visual examples of the trimmer's use, showing a shaved head and a brush cut, illustrating its versatility.

Comfortable trimming
Even if the blade touches the skin, it will not damage the skin




Image: An illustration depicting the trimmer's comfortable trimming action, emphasizing that the blades do not damage the skin during use.

3. **Cordless Operation:** The trimmer is designed for cordless use, providing freedom of movement during grooming.
4. **Battery Indicator:** The digital display shows the remaining battery life. Recharge the device when the indicator is low.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your trimmer.

1. After Each Use:

- Turn off the trimmer.
- Remove the shaving head by gently pulling it upwards (refer to setup image for visual guide).
- Use the provided cleaning brush to remove any trapped hairs from the blades and inside the trimmer body.
- Rinse the shaving head under running water. The trimmer is fully waterproof, allowing for thorough cleaning.

Waterproof design Whole body washing



Image: The trimmer submerged in water, illustrating its waterproof capability for easy cleaning.

- Allow the shaving head to air dry completely before reattaching it to the trimmer body.

2. **Storage:** Store the trimmer in a dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is depleted.	Charge the trimmer for 1.5 hours using the provided USB cable.
Poor trimming performance.	Blades are clogged with hair.	Clean the shaving head thoroughly as described in the Maintenance section.
Trimmer makes unusual noise.	Shaving head not properly attached or internal debris.	Ensure the shaving head is securely attached. Clean the trimmer thoroughly. If the issue persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Item Type	Electric Head Hair Trimmer
Brand	Luqeeq
Model Name	Luqeeq3h260579fu
Material	ABS, Steel (Blade: Alloy Steel)
Battery Type	Lithium Battery
Battery Capacity	800mAh
Use Time	60 minutes
Charging Time	1.5 hours
Power Source	Battery Powered, Corded Electric (via USB)
Special Features	Cordless, USB Rechargeable, Waterproof
Target Audience	Men
Parcel Dimensions	23.7 x 14 x 9.5 cm; 690 g

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact Luqeeq customer service. Please note that return policies may vary; refer to your purchase details for specific return period information (e.g., 60-day return policy).
You can often find support contact details on the official Luqeeq website or through your retailer.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0C4TXRG18>

More documents and user manuals: <https://manuals.plus/>