

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [HABA](#) /

> [HABA Wooden Animal Playset - Play World at The Zoo Instruction Manual](#)

**HABA 1306941001**

# HABA Wooden Animal Playset - Play World at The Zoo

## INSTRUCTION MANUAL

### Introduction

This manual provides essential information for the setup, operation, and care of your HABA Wooden Animal Playset, model 1306941001. This interactive wooden zoo playset is designed to encourage fine motor skills, creativity, storytelling, and cognitive growth for children aged 2 and up. Please read these instructions carefully to ensure safe and enjoyable play.

### Components

The HABA Wooden Animal Playset includes 22 wooden pieces and a rulebook, all designed for engaging play. Verify that all components listed below are present in your set.

- Zookeeper George (1 figure)
- Animals: 1 elephant, 1 hippo, 1 giraffe, 1 kangaroo, 1 koala, 1 flamingo, 1 monkey, 1 tiger, 1 lion, 1 polar bear, 1 penguin, 1 crocodile, 1 zebra (13 figures total)
- Accessories: 1 patch of grass, 2 trees, 1 wheelbarrow, 3 fences/rocks, 1 signpost (8 pieces total)
- Rulebook (1)



**MADE IN  
GERMANY**

Image 1: Assortment of wooden animal figures and accessories.



Image 2: All 22 components of the playset, including the carrying case and individual figures.

## Setup Instructions

1. **Unpack Components:** Carefully remove all 22 wooden figures and the rulebook from the carrying case.
2. **Transform the Case:** The illustrated carrying case unfolds to become the zoo play environment. Open the case fully to reveal the play area.
3. **Arrange the Zoo:** Place the wooden fences, trees, and grass patch to create different enclosures and landscapes within the zoo.
4. **Position Animals and Zookeeper:** Arrange the animal figures and Zookeeper George throughout the zoo as desired, ready for imaginative play.



Image 3: The carrying case unfolds to create the zoo play area.



Image 4: The complete zoo playset with all figures arranged.

## Operating Instructions (Play Guide)

The HABA Wooden Animal Playset is designed for open-ended imaginative play. Children can create their own stories and scenarios within the zoo environment. Here are some suggestions for engaging play:

- **Animal Care:** Use Zookeeper George and the wheelbarrow to feed and care for the animals.
- **Habitat Creation:** Arrange the fences and trees to design different habitats for each animal.
- **Storytelling:** Encourage children to invent narratives about the animals' day at the zoo, fostering language development and creativity.
- **Travel Play:** The compact carrying case allows for easy transport, making it an ideal toy for travel or visits.



Image 5: A child engaging in imaginative play with the zoo playset.

Your browser does not support the video tag.

Video 1: An official HABA video demonstrating play with the zoo playset.

## Maintenance and Care

To ensure the longevity and hygiene of your HABA Wooden Animal Playset, follow these care guidelines:

- **Cleaning:** Wipe wooden pieces with a damp cloth and mild soap if necessary. Avoid harsh chemicals or abrasive cleaners. Dry thoroughly immediately after cleaning.
- **Storage:** Store the playset in its original carrying case in a dry place away from direct sunlight and extreme temperatures to prevent warping or fading of the wood.
- **Inspection:** Regularly inspect all pieces for any signs of wear, damage, or splinters. Discontinue use if any piece becomes damaged.

## Troubleshooting

If you encounter any issues with your HABA Wooden Animal Playset, please refer to the following:

- **Missing Pieces:** If any components are missing upon unboxing, please contact HABA customer support immediately.
- **Damaged Pieces:** If any pieces arrive damaged or become damaged during normal use, please contact customer support for assistance.
- **General Inquiries:** For any other questions or concerns, please reach out to HABA customer support.

## Specifications

Feature	Detail
Product Dimensions	9.21 x 12.68 x 4.17 inches
Item Weight	2.5 pounds
Item Model Number	1306941001
Manufacturer Recommended Age	18 months and up
Manufacturer	HABA
Materials	Beech wood and durable cardboard
Origin	Made in Germany

## Warranty Information

For detailed warranty information regarding your HABA Wooden Animal Playset, please refer to the official HABA website or contact HABA customer support directly. Warranty terms and conditions may vary.

## Customer Support

If you require further assistance or have questions not covered in this manual, please contact HABA customer support:

- **Online:** Visit the official HABA store on Amazon: [HABA Store](#)
- **Seller Information:** For direct inquiries related to your purchase, you may contact the seller HABA\_USA via Amazon's platform.