

Gessi 38605

Gessi Emporio Via Manzoni Single-Lever Basin Mixer Instruction Manual

Model: 38605

INTRODUCTION

This manual provides essential instructions for the installation, operation, and maintenance of your Gessi Emporio Via Manzoni single-lever basin mixer. Please read this manual carefully before installation and use, and retain it for future reference. Proper installation and care will ensure optimal performance and longevity of your product.

SAFETY INFORMATION

- Always turn off the main water supply before beginning any installation or maintenance.
- Installation should be performed by a qualified professional to ensure compliance with local plumbing codes.
- Do not use abrasive cleaners or harsh chemicals on the product's surface, as this may damage the finish.
- Ensure all connections are secure and watertight to prevent leaks.

PACKAGE CONTENTS

Verify that all components are present before starting installation.

- 1x Gessi Emporio Via Manzoni Single-Lever Basin Mixer
- Connection hoses (3/8")
- Mounting hardware
- Instruction Manual

SETUP AND INSTALLATION

1. **Prepare the Installation Area:** Ensure the basin or countertop has a single mounting hole. Clean the area thoroughly.
2. **Install the Mixer:** Insert the mixer's base into the mounting hole. From underneath the basin, secure the mixer using

the provided mounting hardware (washer, gasket, and nut). Tighten firmly but do not overtighten.

3. **Connect Water Supply:** Attach the flexible connection hoses (3/8") to the corresponding hot and cold water supply lines. Ensure a watertight seal using appropriate tools and sealing materials if necessary. The mixer is designed for standard 3/8" connections.
4. **Check for Leaks:** Slowly turn on the main water supply and check all connections for any signs of leakage. If leaks are detected, turn off the water supply and re-tighten the connections.
5. **Flush the System:** Allow water to run through the mixer for a few minutes to flush out any debris from the pipes.



Figure 1: Dimensional diagram of the Gessi Emporio Via Manzoni single-lever basin mixer. The total height is approximately 19.51 cm. The overall length from the back of the base to the tip of the spout is 36 cm, and the base width is 6.81 cm. The spout projection is specified as 128 mm (12.8 cm) in the product details. This image illustrates the physical size and proportions of the faucet for installation planning.

OPERATING INSTRUCTIONS

The Gessi Emporio Via Manzoni basin mixer features a single lever for controlling both water flow and temperature.

- **Water Flow:** Lift the lever upwards to increase water flow. Push it downwards to decrease or stop the flow.
- **Water Temperature:** Move the lever to the left for hot water and to the right for cold water. Adjust the position between left and right to achieve the desired temperature.

MAINTENANCE AND CARE

Regular cleaning and proper maintenance will preserve the finish and functionality of your mixer.

- **Cleaning the Finish:** Clean the surface with a soft, damp cloth and mild soap. Rinse thoroughly with clean water and dry with a soft cloth to prevent water spots. Do not use abrasive sponges, scouring pads, or chemical cleaners containing alcohol, ammonia, or bleach.
- **Aerator Maintenance:** Periodically unscrew the aerator at the end of the spout and clean any mineral deposits or debris. Rinse it under running water and reattach it securely.
- **Cartridge Maintenance:** If the mixer experiences persistent drips or difficulty in controlling flow/temperature, the ceramic cartridge may need inspection or replacement. This should ideally be performed by a qualified plumber.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed stopcock; low water pressure.	Clean aerator; ensure stopcocks are fully open; check main water pressure.
Leaking from Spout	Worn cartridge; debris in cartridge.	Replace or clean cartridge (professional recommended).
Leaking at Base	Loose mounting nut; damaged gasket.	Tighten mounting nut; inspect and replace gasket if damaged.
Incorrect Water Temperature	Improper cartridge adjustment; issues with water heater.	Adjust cartridge (professional recommended); check water heater settings.

SPECIFICATIONS

- **Brand:** Gessi
- **Model Name:** Emporio Via Manzoni
- **Model Number:** 38605
- **Type:** Single-Lever Basin Mixer
- **Mounting Type:** Deck Mounted (Single-hole installation)
- **Spout Projection:** 128 mm (12.8 cm)

- **Connection Hoses:** 3/8"
- **Finish:** Polished (Ottica Finox)
- **Color:** Grey (Finox)
- **Number of Handles:** 1
- **Country of Origin:** Italy
- **Approximate Height:** 19.51 cm
- **Approximate Overall Length (base to spout tip):** 36 cm
- **Approximate Base Width:** 6.81 cm

WARRANTY INFORMATION

Gessi products are manufactured to high-quality standards. For specific warranty terms and conditions, please refer to the official Gessi warranty documentation provided with your purchase or visit the official Gessi website. Keep your proof of purchase for warranty claims.

SUPPORT AND CONTACT

If you require further assistance, have questions about installation, or need to report a defect, please contact your retailer or visit the official Gessi website for customer support.

Gessi Official Website: www.gessi.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

