

## Giantex GX4031GN-TG

# Giantex Garden Cart GX4031GN-TG Instruction Manual

Model: GX4031GN-TG

## 1. INTRODUCTION

---

The Giantex Garden Cart GX4031GN-TG is a versatile rolling workseat designed to enhance your gardening experience. It features a 360° rotatable and height-adjustable seat, ample storage with a bottom tool tray and back basket, and durable construction with anti-skid inflatable rubber tires for various terrains. This manual provides essential information for assembly, operation, maintenance, and safety to ensure optimal use of your garden cart.

## 2. SAFETY INFORMATION

---

**Caution: Be careful when adjusting the seat height to its maximum setting to prevent tipping. Always use the product on a stable and level surface.**

- Do not exceed the maximum weight capacity of 330 lbs (150 kg).
- Ensure all bolts and nuts are securely tightened before each use.
- Avoid using the cart on excessively steep or uneven terrain where stability may be compromised.
- Keep hands and feet clear of moving parts, especially during seat adjustment and wheel movement.
- Store the cart in a dry, protected area to prevent rust and prolong its lifespan.

## 3. PACKAGE CONTENTS

---

Please verify that all components are present before beginning assembly:

- Main Cart Frame
- Adjustable Seat with Swivel Mechanism
- Removable Seat Cushion
- Bottom Tool Tray
- Back Storage Basket
- Four 10-inch Inflatable Rubber Wheels
- Long Steering Handle (approx. 24 inches)
- Short Steering Handle (approx. 4.5 inches)
- Hardware Pack (bolts, nuts, washers, wrenches)

## 4. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. It is recommended to have basic hand tools available for assembly. Please follow these steps carefully:

1. **Attach the Wheels:** Secure each of the four inflatable rubber wheels to the cart frame using the provided axles, washers, and nuts. Ensure the wheels spin freely.
2. **Install the Bottom Tool Tray:** Position the tool tray beneath the seat frame and secure it to the designated attachment points on the main frame using the appropriate hardware.
3. **Mount the Back Storage Basket:** Attach the storage basket to the rear of the cart frame.
4. **Assemble the Seat:** Attach the seat base to the swivel mechanism, then secure the swivel mechanism to the main cart frame. Place the removable cushion onto the seat.
5. **Attach the Backrest (if applicable):** If your model includes a separate backrest, attach it to the seat assembly.
6. **Insert the Steering Handle:** Choose either the long or short steering handle and insert it into the front receiver on the cart frame. Ensure it is securely locked in place.
7. **Final Check:** Verify that all connections are tight and secure before using the cart.



### Multi-Purpose Design



Picking Fruits



Sowing Plants



Trimming Plants



Sitting to Repair Your Car

Image: Fully assembled Giantex Garden Cart, showing the long handle, seat, and storage components.

## 5. OPERATING INSTRUCTIONS

### 5.1 Adjusting Seat Height

The seat height can be adjusted from 16.5 inches to 20.5 inches. To adjust, locate the adjustment knob or lever beneath the seat. Loosen it, raise or lower the seat to your desired height, and then securely tighten the knob/lever to lock the seat in position.



Image: Detail of the seat height adjustment mechanism, showing the range of adjustment.

### 5.2 Using the 360° Swivel Seat

The ergonomic seat is designed to rotate 360 degrees, allowing you to easily turn and access different areas without repositioning the entire cart. Simply rotate the seat to face your desired direction.



Image: The seat of the garden cart demonstrating its 360-degree swivel function.

### 5.3 Utilizing Storage Space

The cart is equipped with a bottom tool tray and a back storage basket to keep your gardening tools and supplies within easy reach. The backrest may also feature storage partitions for smaller items.



Image: The garden cart's integrated storage solutions, including the under-seat tray and rear basket.

### 5.4 Moving the Cart

The cart features four 10-inch inflatable rubber tires designed for various terrains. Use the chosen steering handle (long or short) to pull or guide the cart. For minor adjustments while seated, you can gently push

with your feet.

## **HUMANIZED T-SHAPED PULLING HANDLE**

**OURS**



**OTHERS**



### **4.5" & 24" Handles for Your Choice**

Easy to pull the cart  
without back pain



Not friendly to waist

Image: The two available steering handles, offering options for pulling the cart.

# PREMIUM 10" INFLATABLE RUBBER WHEELS

Perfect for all kinds of terrain



Non-skid



Wear-resistant



Shock-absorbing



Asphalt



Brick



Gravel



Grassland

Image: The robust 10-inch inflatable rubber wheels, suitable for various outdoor surfaces.

## 6. MAINTENANCE

- **Cleaning:** Wipe down the metal frame and plastic components with a damp cloth. For stubborn dirt, use mild soap and water. Avoid abrasive cleaners.
- **Tire Pressure:** Periodically check the air pressure in the inflatable rubber tires. Maintain recommended pressure for optimal performance and longevity.
- **Rust Prevention:** The cart features a powder-coated surface to resist rust. However, for long-term outdoor use, it is advisable to store the cart in a dry, covered area when not in use. Inspect for any scratches or chips in the coating and touch up if necessary to prevent rust.
- **Fastener Check:** Regularly inspect all bolts, nuts, and fasteners to ensure they remain tight. Tighten any loose connections to maintain stability and safety.
- **Cushion Care:** The removable cushion can be cleaned according to its fabric care instructions. Store indoors when not in use to protect from prolonged sun exposure and weather.

## 7. TROUBLESHOOTING

---

- **Cart feels wobbly or unstable:** Check all assembly bolts and nuts. Ensure they are securely tightened. Verify that the cart is on a level surface.
- **Difficulty steering or moving:** Ensure all four tires are properly inflated to the recommended pressure. Check for any obstructions around the wheels.
- **Tires losing air:** Inspect tires for punctures or damage. Ensure valve stems are intact and valve caps are securely in place. If necessary, repair or replace damaged tires.
- **Seat adjustment mechanism is stiff:** Apply a small amount of silicone lubricant to the threaded rod or moving parts of the adjustment mechanism.

## 8. SPECIFICATIONS

---

Feature	Detail
Model Number	GX4031GN-TG
Brand	Giantex
Product Dimensions (D x W x H)	90.2 x 58.4 x 73.7 Centimetres
Material	Metal, Rubber
Colour	Green & Black
Item Weight	34 Pounds (15.4 kg)
Weight Capacity Maximum	330 Pounds (150 kg)
Number of Wheels	4
Wheel Diameter	10 inches
Seat Height Adjustment Range	16.5 - 20.5 inches
Caster Type	Swivel
Assembly Required	Yes



Image: Dimensional overview of the Giantex Garden Cart, including seat height and overall size.

## 9. WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the documentation included with your purchase or contact the retailer/manufacturer directly. Keep your purchase receipt as proof of purchase.