

LUXOAK CFT013

LUXOAK Modern Fireplace TV Stand (Model CFT013)

Instruction Manual

Safety

Overview

Contents

Setup

Operation

Storage & Support

Maintenance

Troubleshooting

Specifications

Warranty

1. IMPORTANT SAFETY INFORMATION

WARNING: Read all instructions before using this appliance to reduce the risk of fire, electric shock, and injury to persons.

- Do not place heavy objects on the top of the TV stand that exceed the maximum load capacity of 250 lbs.
- Always follow the assembly instructions carefully to ensure the stability and safety of the TV stand.
- Never block the ventilation of the electric fireplace to prevent the risk of carbon monoxide poisoning.
- Ensure the power outlet is properly grounded and rated for the fireplace's electrical requirements.
- Keep flammable materials at least 3 feet (0.9 meters) away from the front of the fireplace.
- Do not operate the fireplace with a damaged cord or plug, or if the heater malfunctions.
- Supervise children and pets when the fireplace is in operation.

2. PRODUCT OVERVIEW

The LUXOAK Modern Fireplace TV Stand (Model CFT013) is a stylish and functional entertainment center designed for TVs up to 80 inches. It features a high gloss finish, integrated 36-inch electric fireplace, open storage, and customizable LED lighting.

Key Features:

- **High Gloss Finish:** Provides a sleek, modern aesthetic and is easy to clean.
- **36" Electric Fireplace:** Can be used with or without heat. Features temperature control (62°F to 82°F), 3 realistic flame colors, a time setting (1-8 hours), and a 5-level dimmer. Controlled via remote or touch screen. Max 4800 BTU output.
- **Modern Design:** Mirrored fronts with a matte body complement various furniture styles. The TV console includes 12-color LED lights to enhance your living space.
- **Large Storage Space:** Offers open storage and two cabinets, providing ample room for gaming consoles, books, PVRs, DVD players, and remotes.
- **Dimensions & Load Capacity:** Media console measures 70"W x 14"D x 23"H. The fireplace insert is 36"W x 14"H. The top surface has a maximum load capacity of 250 lbs.

FIREPLACE INSTRUCTIONS




3 Colors



62°F to 82°F



1H~8H



5 Levels of Dimmer



The LUXOAK Modern Fireplace TV Stand, showcasing its sleek design and integrated electric fireplace.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. The product is shipped in two separate boxes.

- 1 x TV Stand components
- 1 x Electric Fireplace insert
- 1 x Installation Guide
- 1 x Screw Pack (hardware for assembly)



TV Stand

Two Different Boxes

Two boxes
may arrive at different
times, please be patient.



Electric Fireplace

The TV stand and electric fireplace are shipped in two separate boxes, which may arrive at different times.


4. SETUP & ASSEMBLY

Assembly is required for this TV stand. Please follow the detailed instructions and use the included fittings for proper and safe construction. The estimated assembly time is approximately 1 hour.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Refer to the included Installation Guide to identify each component and hardware piece.
3. **Assemble Frame:** Follow the step-by-step diagrams in the manual to assemble the main frame of the TV stand.
4. **Install Shelves and Doors:** Attach the shelves, including the top shelf supported by stainless steel poles, and the cabinet doors.
5. **Insert Electric Fireplace:** Carefully slide the electric fireplace insert into its designated opening in the TV stand.
6. **Connect Power:** Once fully assembled, plug the electric fireplace into a suitable grounded electrical outlet.

For visual guidance, refer to the detailed diagrams in your included Installation Guide.

FOR TV UP TO 80"



Detail of the stainless steel poles supporting the top panel, creating open storage space, and a cable management solution.

5. OPERATING INSTRUCTIONS

Electric Fireplace Operation:

The 36-inch electric fireplace can be operated using the touch screen controls on the unit or the provided remote control.

- **Power On/Off:** Press the power button to turn the fireplace on or off.
- **Heat Settings:** Adjust the temperature between 62°F and 82°F. The fireplace can be used with or without heat.
- **Flame Colors:** Cycle through 3 realistic flame colors (e.g., red, blue, purple) to match your ambiance.
- **Dimmer:** Select from 5 levels of flame brightness (L1 to L5) to control the intensity of the flame effect.
- **Timer:** Set an automatic shut-off timer for 1 to 8 hours.



MIRRORED FRONTS

Easy to clean and keep surface of TV stand tidy.

Fireplace controls for color, temperature, timer, and dimmer settings.



Visual representation of the 3 flame colors and 5 dimmer levels available for the electric fireplace.

LED Lights Operation:

The TV stand features 12-color LED lights to create various atmospheric effects.

- **Color Selection:** Use the remote control to cycle through the 12 available LED colors.
- **Brightness Adjustment:** Adjust the brightness of the LED lights to your preference.



The TV stand illuminated with purple LED lights and the electric fireplace displaying matching flames.

Official Product Video:

This video demonstrates the various features of the LUXOAK Fireplace TV Stand, including the LED lighting and electric fireplace effects.


6. STORAGE AND CABLE MANAGEMENT

The TV stand is designed with practical storage solutions to keep your entertainment area organized.

- **Open Storage:** The top shelf, supported by stainless steel poles, provides open space for media devices, soundbars, or decorative items.
- **Closed Cabinets:** Two side cabinets offer concealed storage for items you wish to keep out of sight, such as gaming accessories, DVDs, or remotes.
- **Cable Management:** Integrated cable management grommets help route and organize wires, preventing clutter and maintaining a tidy appearance.

STAINLESS STEEL POLES

SUPPORTING TOP PANEL
FORMS OPEN STORAGE SPACE



CABLE MANAGEMENT

MAKE THE WIRES NO
LONGER MESS UP.

The TV stand features ample open and closed storage space, with LED lights illuminating the shelves.

LARGE STORAGE SPACE

2 CABINETS AND OPEN STORAGE SPACE WITH LED LIGHTS



The mirrored cabinet fronts contribute to the modern design and are easy to clean.

7. MAINTENANCE & CARE

To ensure the longevity and appearance of your LUXOAK TV Stand, follow these care instructions:

- **Cleaning:** Wipe the surfaces with a dry, soft cloth. Avoid abrasive cleaners or harsh chemicals that may damage the high gloss finish.
- **Dusting:** Regularly dust the unit to prevent buildup, especially around the fireplace vents.
- **Fireplace Maintenance:** Ensure the fireplace vents are clear of obstructions. Periodically check the electrical cord for any signs of damage.
- **LED Lights:** If LED lights dim or fail, check connections. If issues persist, contact customer support.

8. TROUBLESHOOTING

If you encounter any issues with your TV stand or electric fireplace, refer to the following common solutions:

- **Fireplace Not Turning On:**

- Check if the power cord is securely plugged into a working electrical outlet.
- Ensure the main power switch on the fireplace unit is in the 'ON' position.
- Verify that the circuit breaker has not tripped.

• **No Heat Output:**

- Confirm that the heat function is activated via the control panel or remote.
- Check the temperature setting; ensure it is set above the current room temperature.
- Ensure the air intake and exhaust vents are not blocked.

• **LED Lights Not Working:**

- Check the connection of the LED light strip to its power source.
- Ensure the remote control batteries are functional and correctly inserted.

• **Remote Control Not Responding:**

- Replace the batteries in the remote control.
- Ensure there are no obstructions between the remote and the fireplace's receiver.

If these steps do not resolve the issue, please contact customer support for further assistance.

9. SPECIFICATIONS

Feature	Detail
Brand	LUXOAK
Model Number	CFT013
Color	White
Style	Modern
Material	Engineered Wood
Finish Type	High Gloss
Media Console Dimensions (W x D x H)	70" x 14" x 23"
Fireplace Insert Dimensions (W x H)	36" x 14"
Maximum TV Size Supported	80"
Maximum Load Capacity (Top)	250 lbs
Item Weight	86.4 lbs
Electric Fireplace Output	Max 4800 BTU
Fireplace Temperature Range	62°F to 82°F
Flame Colors	3 realistic colors
Flame Dimmer Levels	5 levels
Timer Settings	1-8 hours
LED Lights	12-colors
Control Method	Remote or Touch Screen
Included Components	TV Stand, Electric Fireplace, Installation Guide, Screw Pack

Feature	Detail
UPC	199169051289

10. WARRANTY & SUPPORT

Warranty Information:

This LUXOAK product typically comes with a 1-year limited warranty from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims. For specific warranty details, refer to the documentation included with your product or contact customer support.

Customer Support:

If you have any questions, require assistance with assembly, or need to report a damaged part, please contact LUXOAK customer service. Our professional service team is ready to help you.

Contact Information:

- **Email:** support@luxoak.com
- **Phone:** 1-800-XXX-XXXX (Monday - Friday, 9 AM - 5 PM EST)
- **Website:** www.luxoak.com/support

© 2026 LUXOAK. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question