



Manuals.plus /

› DEERFAMY /

› DEERFAMY Portable Camping Shower Instruction Manual

DEERFAMY B0C4Y5TM26

DEERFAMY Portable Camping Shower Instruction Manual

Model: B0C4Y5TM26

INTRODUCTION

Thank you for choosing the DEERFAMY Portable Camping Shower. This manual provides essential information for the safe and efficient use of your portable shower. Please read these instructions carefully before operation and retain them for future reference.

PRODUCT COMPONENTS

The DEERFAMY Portable Camping Shower package includes the following items:

- Battery (4400mAh, with lighting device)
- Pump
- Shower head (1pc)
- 6ft hose
- Mesh storage bag
- Hook (1pc)
- Suction cup hook (1pc)
- Suction mount (1pc)
- USB cable (1pc)
- Shower O-ring (2pcs)
- Filter cotton (2pcs)

NOT JUST A SHOWER




Pet Shower



Car Wash



Watering



Outdoor Activities

Image: All components of the DEERFAMY Portable Camping Shower, including the battery, pump, shower head, hose, and accessories.

SETUP

1. **Connect the Hose:** Attach one end of the 6ft hose to the pump and the other end to the shower head. Ensure O-rings are properly seated to prevent water leakage.
2. **Insert the Battery:** Securely connect the battery unit to the pump.
3. **Prepare Water Source:** Place the pump into a bucket or container filled with water.
4. **Mount the Shower Head:** Use the provided hook or suction cup hook to hang the shower head at a desired height.

PROVIDE HANGING TOOLS



Image: Demonstrates how to hang the shower head using the provided hook on a branch and a suction cup hook on a car window.

CHARGING THE BATTERY

The portable shower is equipped with a 4400mAh rechargeable battery. Before first use, ensure the battery is fully charged.

- **Charging Input:** The USB interface requires a 5V/1A input.
- **Compatible Chargers:** Use a laptop USB port, car USB charger, or a standard mobile phone charger.
- **Charging Indicator:** The indicator lights on the battery display the current power level.
- **Battery Life:** A full charge provides approximately 90-100 minutes of operation.



Image: Shows the battery unit with its Type-C charging interface and indicator lights, along with various USB charging options like a car charger, wall adapter, and laptop.

OPERATION

1. **Power On:** Once the pump is submerged in water and the battery is connected, press the power button on the battery unit to turn on the pump.
2. **Control Water Flow:** To activate the water flow from the shower head, press and hold the shower head down. Releasing it will stop the flow.
3. **Water Flow Rate:** The water flow rate is between 0.71-0.79 gallons per minute (2.7-3.0 liters per minute).
4. **Water Saving:** The shower head features a water-saving design with dense outlet holes and an

ON/OFF control by adjusting the shower head position.



Image: Illustrates how to control the water flow by pressing and holding the shower head down.

WATER SAVING DESIGN



Image: Details the shower head's dense water outlet holes and the ON/OFF mechanism by adjusting its position.

LIGHTING DEVICE

The external battery unit includes a built-in lighting device for convenience and safety, especially during nighttime use.

- **Lighting Modes:** The device offers multiple lighting modes, which can be used as independent lighting or for SOS signals in emergencies.
- **Nighttime Safety:** Provides illumination for showering in low-light conditions.

NO NEED for EXTRA LIGHTING for NIGHT SHOWERS

3 Lighting Modes - Which Can Be Used As Independent Lighting Or SOS Calls for Help in The Field



Image: Shows the portable shower in use with its integrated lighting, demonstrating its utility for night showers and as an independent light source.

MAINTENANCE

Cleaning the Filter

The pump includes a built-in filter cotton to purify water. Regular cleaning of the filter is recommended to maintain optimal performance and water quality.

- **Accessing the Filter:** Disconnect the pump from the battery and hose. Carefully open the pump housing to access the filter cotton.
- **Cleaning:** Rinse the filter cotton under clean running water. If heavily soiled, replace it with one of the

spare filter cotton pieces provided.

- **Reassembly:** Ensure the filter is properly seated before reassembling the pump housing.

Battery Care

- **Waterproof Rating:** The battery is waterproof against splashes. However, **do not submerge the battery in water** as this will cause damage.
- **Storage:** Store the unit in a dry place when not in use.



- Built-in Filter Cotton Can Purify Water Quality
- The Portable Water Filter Bag Easily Takes Away The Item with Water

Image: Shows the built-in filter cotton being removed from the pump for cleaning or replacement, and the mesh storage bag for convenient transport.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No water flow / Weak water flow	<ul style="list-style-type: none"> Battery is low or uncharged. Pump not fully submerged. Hose or filter is clogged. Shower head not pressed correctly. 	<ul style="list-style-type: none"> Charge the battery. Ensure pump is fully submerged in water. Clean or replace the filter cotton. Check hose for kinks. Press and hold the shower head firmly.
Water leakage	<ul style="list-style-type: none"> Hose connections are loose. O-rings are missing or damaged. 	<ul style="list-style-type: none"> Tighten all hose connections. Ensure O-rings are present and undamaged. Replace if necessary.
Lighting device not working	<ul style="list-style-type: none"> Battery is low or uncharged. Lighting function not activated. 	<ul style="list-style-type: none"> Charge the battery. Refer to the battery unit for lighting activation instructions.

SPECIFICATIONS

Feature	Detail
Model	B0C4Y5TM26
Battery Capacity	4400mAh
Battery Life	Up to 90-100 minutes
Charging Input	5V/1A USB
Water Flow Rate	0.71-0.79 gal/min (2.7-3.0 L/min)
Lighting Device	130LM (integrated with battery)
Product Dimensions	21.49 x 19.99 x 6.71 cm
Weight	830 g (1.82 lbs)
Material	Plastic
Color	Yellow

WARRANTY AND SUPPORT

DEERFAMY offers a two-year warranty for this product, ensuring zero risk. We also provide lifetime customer service for any inquiries or assistance you may need.

For support, please contact DEERFAMY customer service through the retailer's platform or the official DEERFAMY website.

