Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl 5V AC/DC Adapter

onerbl 5V AC/DC Adapter User Manual

Model: 5V AC/DC Adapter (ASIN: B0C4YDB4TV)

1. Introduction

This manual provides essential instructions for the safe and effective use of your onerbl 5V AC/DC Adapter. Please read this manual thoroughly before using the product and retain it for future reference.
This adapter is designed to provide a stable 5V DC power supply for compatible electronic devices, specifically Awei Luxury Y100, Y200, and Y300 portable Bluetooth speakers.

2. Important Safety Information

To prevent injury or damage to your device, always observe the following safety precautions:

- Do not expose the adapter to water, moisture, or extreme temperatures.
- Do not disassemble or attempt to repair the adapter. Refer all servicing to qualified personnel.
- Ensure the adapter is used with devices that match its voltage and current specifications (5V DC). Using with incompatible devices may cause damage.
- Avoid placing heavy objects on the power cord.
- Unplug the adapter during lightning storms or when unused for long periods.

Warning: This adapter is designed for indoor use only. Do not use outdoors.

3. Package Contents

- 1 x onerbl 5V AC/DC Adapter

4. Product Specifications

Feature	Specification
Input Voltage	AC 100-240V, 50/60Hz

Output Voltage	DC 5V
Wattage	5 Watts
Cable Length	Approximately 76 inches (6.3 feet)
Special Features	Over Voltage Protection, Over Heat Protection, Short-circuit Protection
Compatibility	Awei Luxury Y100, Y200, Y300 Portable Bluetooth Speakers

Note: Specifications are subject to change without prior notice.

5. Setup and Connection

1. **Verify Compatibility:** Ensure your device requires a 5V DC input and has a compatible power port. This adapter is specifically designed for Awei Luxury Y100, Y200, and Y300 portable Bluetooth speakers.
2. **Connect to Device:** Insert the DC output plug of the adapter firmly into the power input port of your Awei speaker.
3. **Connect to Power Outlet:** Plug the AC input prongs of the adapter into a standard AC 100-240V wall outlet.
4. **Power On:** Once connected, your device should begin charging or power on, depending on its design.



Figure 1: onerbl 5V AC/DC Adapter. This image shows the adapter with its AC prongs and the DC output plug, connected by a coiled cable.



Figure 2: Front and side views of the onerbl 5V AC/DC Adapter. The front shows the AC input prongs and product label, while the side highlights its compact design.



Figure 3: The onerbl 5V AC/DC Adapter in use, plugged into a power strip on a desk, demonstrating a typical application scenario.

6. Operating Instructions

The onerbl 5V AC/DC Adapter operates automatically once connected to a power source and a compatible device. It provides a continuous 5V DC output for charging or powering your device.

- The adapter features built-in protections against over-voltage, over-heat, and short-circuits to ensure safe operation.
- No user interaction is required for its basic function beyond proper connection.



Figure 4: Illustration of the adapter's "Smart Chip" technology, highlighting its multiple protection features including short-circuit, over-voltage, and over-current protection.

7. Care and Maintenance

Proper care will extend the life of your onerbl 5V AC/DC Adapter:

- **Cleaning:** Disconnect the adapter from the power outlet and device before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or aerosols.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the cable and adapter housing for any signs of damage, such as cuts, fraying, or cracks. If damage is found, discontinue use and replace the adapter.

Figure 5: An illustration detailing the durable design of the adapter's cable, showing the internal copper wire and protective PVC jacket.

8. Troubleshooting

If you encounter issues with your onerbl 5V AC/DC Adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Device not powering on/charging.	◦ Adapter not properly plugged into outlet. ◦ Adapter not properly connected to device. ◦ Power outlet is not functional. ◦ Device is incompatible or faulty. ◦ Adapter is faulty.	◦ Ensure adapter is securely plugged into a live wall outlet. ◦ Verify the DC plug is fully inserted into the device's power port. ◦ Test the outlet with another known working appliance. ◦ Confirm your device requires 5V DC input. Test the device with its original adapter if available. ◦ If all else fails, the adapter may be faulty and require replacement.
Adapter feels excessively hot.	◦ Normal operation (slight warmth is expected). ◦ Overload or short circuit. ◦ Poor ventilation.	◦ If it's just warm, it's likely normal. ◦ Immediately unplug the adapter and device. Check for any damage to the cable or device. Do not use if damage is found. ◦ Ensure the adapter is in an open area with adequate airflow.

9. Warranty and Support

For warranty information or technical support, please refer to the retailer or manufacturer's website where the product was purchased. Please have your product model (ASIN: B0C4YDB4TV) and purchase date available when contacting support. Manufacturer: Shenzhen Waweis Technology Co., Ltd

10. Environmental Disposal

Please dispose of this product responsibly according to local regulations. Do not dispose of electronic waste with general household waste. Contact your local authorities for information on recycling and disposal options.

© 2023 onerbl. All rights reserved.
This manual is for informational purposes only. onerbl is not responsible for any direct or indirect damages, losses, or costs resulting from the use or inability to use this product.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C4YDB4TV

More documents and user manuals: **https://manuals.plus/**