

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [NZXT](#) /

> [NZXT Relay PC Gaming Desktop Speakers \(AP-SPKB2-US\) Instruction Manual](#)

NZXT AP-SPKB2-US

NZXT Relay PC Gaming Desktop Speakers

MODEL: AP-SPKB2-US INSTRUCTION MANUAL

Introduction

The NZXT Relay PC Gaming Desktop Speakers are designed to deliver a high-quality audio experience for your gaming and multimedia needs. Featuring a bookshelf-style design, 80 watts of total power, high dynamic range, silk dome tweeters, and glass fiber woofers, these speakers are engineered for detailed soundscapes and immersive audio. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your speakers.

What's in the Box

- NZXT Relay Desktop Speakers (2 units)

Key Features

- **Designed for PC Gaming:** Optimized for close-proximity listening with a high dynamic range for detailed in-game soundscapes.
- **Room-Filling Sound:** 80 watts of total power (40 watts per speaker) for immersive audio in games, music, and movies.
- **High-Quality Drivers:** Features silk dome tweeters and glass fiber woofers for smooth highs and rich lows.
- **Space-Saving Size:** Compact dimensions (6.25"D x 4.52"W x 7.32"H) to fit comfortably on a desktop.
- **Solid Construction:** Speaker enclosures are constructed from high-quality MDF to minimize resonance and distortion.
- **Universal Connectivity:** Includes 3.5 mm and RCA inputs for wide device compatibility.
- **Bluetooth Connectivity:** Supports wireless audio streaming.

Setup

Follow these steps to set up your NZXT Relay Desktop Speakers:

1. **Placement:** Place the speakers on your desktop, ensuring they are positioned for optimal close-proximity listening. The compact size allows for flexible placement.

2. **Connect Speakers:** Connect the left speaker to the right speaker using the provided speaker cable.
3. **Power Connection:** Connect the power cable to the right speaker and then to a power outlet.
4. **Audio Input:** Choose your preferred audio input method:
 - **3.5mm Input:** Connect your device (e.g., PC, laptop) to the 3.5mm AUX input on the right speaker using a 3.5mm audio cable.
 - **RCA Input:** Connect your device to the RCA inputs on the right speaker using an RCA audio cable.
 - **Bluetooth:** For wireless connection, ensure the speakers are powered on and enable Bluetooth on your device. Pair with 'NZXT Relay Speakers'.



Image: Rear view of NZXT Relay speakers highlighting 3.5mm and RCA inputs for universal connectivity.



SPACE-SAVING SIZE

Compact enough to fit comfortably on a desktop,
but large enough to provide powerful sound.

Image: NZXT Relay speakers on a desk, illustrating their compact, space-saving size with dimensions.

Video: Official NZXT Relay audio product video, demonstrating the speakers' features and setup.

Operating Instructions

The primary controls for the NZXT Relay speakers are located on the right speaker.

- **Power On/Off:** Use the power button/switch to turn the speakers on or off.
- **Volume Control:** Adjust the master volume using the dedicated knob/buttons.
- **Input Selection:** Cycle through available audio inputs (3.5mm, RCA, Bluetooth) using the input selection button.
- **Bluetooth Pairing:** To pair a new Bluetooth device, activate pairing mode on the speakers (refer to the quick start guide for specific button presses) and select 'NZXT Relay Speakers' from your device's Bluetooth settings.
- **Headphone Output:** Connect headphones to the dedicated jack on the right speaker for private listening.
- **Subwoofer Output:** Connect an optional subwoofer to the SUB OUTPUT port for enhanced bass.



TUNED FOR PC GAMING

Designed for close-up listening with a high dynamic range that brings out detailed in-game soundscapes.

Image: NZXT Relay speakers integrated into a PC gaming setup, demonstrating their intended use.

Maintenance

To ensure the longevity and optimal performance of your NZXT Relay speakers, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the speaker enclosures. Avoid abrasive cleaners or solvents.
- **Dust:** Regularly dust the speaker grilles and surfaces to prevent dust buildup, which can affect sound quality.
- **Placement:** Avoid placing speakers in direct sunlight, near heat sources, or in areas with high humidity.
- **Cables:** Ensure all cables are securely connected and not pinched or strained.

Troubleshooting

If you encounter issues with your NZXT Relay speakers, try the following solutions:

- **No Sound:**
 - Check if the speakers are powered on and the volume is turned up.
 - Verify that the correct audio input is selected on the speakers.
 - Ensure all audio cables are securely connected to both the speakers and your audio source.
 - If using Bluetooth, ensure the speakers are paired and connected to your device.

- **Distorted Sound:**

- Lower the volume on both the speakers and your audio source.
- Check audio cables for damage or loose connections.
- Ensure the audio source is not outputting a distorted signal.

- **Bluetooth Connectivity Issues:**

- Ensure speakers are in pairing mode or already paired.
- Move your device closer to the speakers to improve signal strength.
- Forget the device from your Bluetooth settings and re-pair.

Specifications

Feature	Specification
Brand	NZXT
Model Number	AP-SPKB2-US
Speaker Maximum Output Power	80 Watts
Connectivity Technology	3.5mm, RCA, TRS, Bluetooth
Audio Output Mode	Stereo
Mounting Type	Tabletop Mount
Enclosure Material	Engineered Wood (MDF)
Speaker Type	Bookshelf
Additional Features	Bass Boost
Control Method	Touch
Woofer Diameter	3 Inches
Tweeter Diameter	20 Millimeters
Item Dimensions D x W x H	6.25"D x 4.52"W x 7.32"H
Item Weight	4196 Grams
Power Source	Corded Electric

Warranty and Support

The NZXT Relay PC Gaming Desktop Speakers come with a **2-year manufacturer warranty**. For technical support, warranty claims, or additional product information, please visit the official NZXT website or contact their customer service directly.