

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Tronsmart](#) /

› [Tronsmart Force Max Portable Outdoor Speaker User Manual](#)

Tronsmart Force Max

Tronsmart Force Max Portable Outdoor Speaker User Manual

INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Tronsmart Force Max Portable Outdoor Speaker. Please read this manual thoroughly before operating the device and retain it for future reference.



Image: The Tronsmart Force Max Portable Outdoor Speaker, a black rectangular speaker with a mesh grille and the 'Tronsmart' logo prominently displayed on the front. It features a rugged design with visible screws and a handle on one side.

PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Tronsmart Force Max Outdoor Speaker
- 1 x User Manual (This document, also available as [PDF](#))
- 1 x Type-C Charging Cable
- 1 x Aux Cable
- 1 x Carrying Strap

PRODUCT OVERVIEW

The Tronsmart Force Max is an 80W portable outdoor speaker designed for robust audio performance. It features a 2.2 channel system with four drivers and dual passive radiators for omnidirectional sound. The speaker is equipped with a retractable strap for portability and is IPX6 waterproof, making it suitable for various outdoor environments.

2.2 Channel System

A state-of-art 4 drivers with dual passive radiators, Tronsmart Force Max presents an omnidirectional sound stage with impactful stereo sound.



Image: An exploded diagram illustrating the internal components of the Tronsmart Force Max speaker, highlighting its two tweeters and two woofers, which form the 2.2 channel audio system.

Easy-to-carry

Retractable strap makes it handy
for outdoor activities



Image: A man sitting on a boat, wearing the Tronsmart Force Max speaker across his body using its retractable carrying strap, demonstrating its portability for outdoor activities.

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided Type-C charging cable to the speaker's charging port and a compatible USB power adapter (not included). The charging indicator will illuminate during charging and turn off when fully charged. A full charge takes approximately 4 hours.

2. Powering On/Off

Press and hold the power button for 2-3 seconds to turn the speaker on or off. A sound indicator will confirm the action.

3. Bluetooth Pairing

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED.

2. Enable Bluetooth on your device (smartphone, tablet, etc.).
3. Search for 'Tronsmart Force Max' in your device's Bluetooth list and select it to connect.
4. Once connected, the LED indicator will remain solid, and a confirmation sound will play.

4. Connecting via AUX, USB Drive, or Micro SD Card

The speaker supports audio input via a 3.5mm AUX cable, a USB drive, or a Micro SD card. Insert the respective media or cable into the designated port on the speaker. The speaker will automatically switch to the corresponding input mode.

OPERATING INSTRUCTIONS

1. Basic Playback Controls

- **Play/Pause:** Press the Play/Pause button.
- **Volume Up:** Press the '+' button.
- **Volume Down:** Press the '-' button.
- **Next Track:** Press and hold the '+' button.
- **Previous Track:** Press and hold the '-' button.

2. Tri-bass EQ Effects

The speaker offers three distinct EQ modes: Vocal, 3D Bass, and Deep Bass. Press the 'EQ' button to cycle through these modes and select your preferred audio profile.

Tri-bass EQ Effects

Adjustable EQ caters for your music taste.



Vocal

3D Bass

Deep Bass

Image: A graphic illustrating the Tri-bass EQ Effects feature of the Tronsmart Force Max speaker, showing options for Vocal, 3D Bass, and Deep Bass sound profiles.

3. True Wireless Stereo (TWS) Pairing

To achieve a stereo sound experience, you can pair two Tronsmart Force Max speakers together:

1. Ensure both speakers are powered on and not connected to any Bluetooth device.
2. On one speaker, press the TWS button. It will enter TWS pairing mode.
3. The two speakers will automatically connect to each other. A confirmation sound will indicate successful pairing.
4. Once paired, connect your device to one of the speakers via Bluetooth as described in the 'Bluetooth Pairing' section. Both speakers will now play audio in stereo.

True Wireless Stereo Pairing

Pair 2 Force Max together to create a tiny surrounding home audio system with powerful stereo sound.



Image: Two Tronsmart Force Max speakers placed on a table outdoors, demonstrating their True Wireless Stereo pairing capability to create a wider soundstage for a group of people.

4. Using the Voice Assistant

With your smartphone connected via Bluetooth, press the dedicated Voice Assistant button on the speaker to activate Siri or Google Assistant on your device. You can then issue voice commands through the speaker's built-in microphone.

Convenient Voice Assistant




Image: The Tronsmart Force Max speaker on an outdoor table, with speech bubbles above it displaying icons for Siri, Cortana, and Google Assistant, indicating its compatibility with voice assistants.

5. Hands-free Calls

When connected to your smartphone via Bluetooth, you can answer or end calls directly using the speaker's controls. The built-in microphone allows for hands-free communication.

6. Power Bank Function

The Tronsmart Force Max features a 15,000 mAh battery that can also be used to charge other devices. Connect your device to the speaker's USB-A output port using a compatible charging cable (not included) to utilize this function.

Built-in Powerbank

Allows charging your device whenever you needed.



Image: The Tronsmart Force Max speaker on a wooden table, with a smartphone connected to it via a USB cable, demonstrating its built-in power bank functionality to charge external devices.

MAINTENANCE

1. Waterproof Care (IPX6)

The speaker is IPX6 waterproof, meaning it is protected against high-pressure water jets from any direction. However, it is not designed for submersion. Ensure all port covers are securely closed before exposing the speaker to water. After exposure to water, wipe the speaker dry with a soft cloth.

IPX6 Waterproof

Enjoy outdoor adventures with favorite songs streaming on Force Max.



Image: The Tronsmart Force Max speaker being splashed with water, illustrating its IPX6 waterproof rating and suitability for outdoor use.

2. General Cleaning

Clean the speaker with a soft, damp cloth. Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the surface.

3. Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, charge the battery to approximately 50% every three months to maintain battery health.

TROUBLESHOOTING

- **Speaker does not turn on:** Ensure the battery is charged. Connect the speaker to a power source and try again.

- **Cannot pair via Bluetooth:** Ensure the speaker is in pairing mode (flashing LED). Turn off and on your device's Bluetooth. If issues persist, clear the speaker from your device's Bluetooth history and try pairing again.
- **No sound:** Check the volume levels on both the speaker and your connected device. Ensure the correct input mode is selected (Bluetooth, AUX, USB, Micro SD).
- **Poor sound quality:** Move the speaker closer to your Bluetooth device to reduce interference. Ensure there are no obstructions between the speaker and the device.

SPECIFICATIONS

Feature	Detail
Model Name	Force Max
Brand	Tronsmart
Speaker Type	Outdoor
Speaker Maximum Output Power	80 Watts
Surround Sound Channel Configuration	2.2
Audio Output Mode	Tri-frequency Audio
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Bluetooth Range	59 Feet (18 meters)
Control Method	Voice
Water Resistance Level	IPX6 Waterproof
Battery Capacity	15000 Milliamp Hours
Charging Time	4 Hours
Playtime (50% volume)	Up to 13 Hours
Product Dimensions	10.2"D x 6"W x 3.4"H (258 x 153 x 86 mm)
Item Weight	5.6 Pounds (2.54 kg)
Compatible Devices	Smartphone, Tablet
Input Options	Bluetooth, 3.5mm AUX, USB Drive, Micro SD Card

13 Hours of Playtime



*Max 13 hours at 50% volume level. Actual results may vary depending on different music genres, volume, environment temperature, etc.

Image: The Tronsmart Force Max speaker positioned next to a campfire at dusk, with text indicating '13 Hours of Playtime', highlighting its long battery life for outdoor use.

WARRANTY INFORMATION

The Tronsmart Force Max Portable Outdoor Speaker comes with a **1-Year Warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

SUPPORT

For further assistance or detailed inquiries, please refer to the official Tronsmart website or contact customer support. An electronic version of this user manual is available for download [here](#).

Related Documents - Force Max

Tronsmart Force Max Portable Outdoor Speaker Thank you for purchasing the Tronsmart Force Max Portable Outdoor Speaker. Please read the user manual carefully and keep it handy for future reference. If you have any questions, suggestions or comments, please contact us by email at sales@tronsmart.com. Package Contents 1 x Tronsmart Force Max Portable Outdoor Speaker 1 x USB-A Power Cable 1 x 3.5mm Audio Cable 1 x Tronsmart Force Max Portable Outdoor Speaker 1 x Tronsmart Force Max Portable Outdoor Speaker 1 x Tronsmart Force Max Portable Outdoor Speaker Warranty This speaker is covered by a 12-month warranty. Please read the warranty policy carefully. The warranty is valid only for the original purchaser. The warranty does not cover any damage caused by misuse, accident, or unauthorized repair. The warranty is void if the product is used for commercial purposes. The warranty is void if the product is used for illegal purposes. The warranty is void if the product is used for any other purpose not intended by the manufacturer. Notes Please read the user manual carefully before using the speaker. The speaker is not a toy. Please use the speaker responsibly and safely. Please do not use the speaker for illegal purposes. Please do not use the speaker for any other purpose not intended by the manufacturer. © 2023 Tronsmart	Tronsmart Force Max Portable Outdoor Speaker User Manual Comprehensive user manual for the Tronsmart Force Max Portable Outdoor Speaker, detailing package contents, features like USB-A power bank and Aux-in, technical specifications, care instructions, and button operations for optimal use.
Tronsmart Force Pro Bluetooth Speaker  User Manual	Tronsmart Force Pro Portable Speaker: Quick Start Guide Learn how to power on, power off, activate the voice assistant, and reset your Tronsmart Force Pro portable speaker with this concise guide.
Tronsmart Bang Mini Portable Outdoor Speaker Thank you for purchasing the Tronsmart Bang Mini Portable Outdoor Speaker. Please read the user manual carefully and keep it handy for future reference. If you have any questions, suggestions or comments, please contact us by email at sales@tronsmart.com. Package Contents 1 x Tronsmart Bang Mini Portable Outdoor Speaker 1 x USB-A Power Cable 1 x 3.5mm Audio Cable 1 x Tronsmart Bang Mini Portable Outdoor Speaker 1 x Tronsmart Bang Mini Portable Outdoor Speaker 1 x Tronsmart Bang Mini Portable Outdoor Speaker Warranty This speaker is covered by a 12-month warranty. Please read the warranty policy carefully. The warranty is valid only for the original purchaser. The warranty does not cover any damage caused by misuse, accident, or unauthorized repair. The warranty is void if the product is used for commercial purposes. The warranty is void if the product is used for illegal purposes. The warranty is void if the product is used for any other purpose not intended by the manufacturer. Notes Please read the user manual carefully before using the speaker. The speaker is not a toy. Please use the speaker responsibly and safely. Please do not use the speaker for illegal purposes. Please do not use the speaker for any other purpose not intended by the manufacturer. © 2023 Tronsmart	Tronsmart Bang Mini Portable Outdoor Speaker User Manual User manual for the Tronsmart Bang Mini Portable Outdoor Speaker. Details include package contents, features like NFC streaming, USB-A power bank functionality, Aux-in mode, TF card and USB flash drive support, auto power-off, detailed specifications (Bluetooth 5.3, 50W output, IPX6 rating), care instructions, and comprehensive button operation guides for basic use and TWS stereo pairing.
Tronsmart Bang Max Portable Party Speaker Thank you for purchasing the Tronsmart Bang Max Portable Party Speaker. Please read the user manual carefully and keep it handy for future reference. If you have any questions, suggestions or comments, please contact us by email at sales@tronsmart.com. Package Contents 1 x Tronsmart Bang Max Portable Party Speaker 1 x USB-A Power Cable 1 x 3.5mm Audio Cable 1 x Tronsmart Bang Max Portable Party Speaker 1 x Tronsmart Bang Max Portable Party Speaker 1 x Tronsmart Bang Max Portable Party Speaker Warranty This speaker is covered by a 12-month warranty. Please read the warranty policy carefully. The warranty is valid only for the original purchaser. The warranty does not cover any damage caused by misuse, accident, or unauthorized repair. The warranty is void if the product is used for commercial purposes. The warranty is void if the product is used for illegal purposes. The warranty is void if the product is used for any other purpose not intended by the manufacturer. Notes Please read the user manual carefully before using the speaker. The speaker is not a toy. Please use the speaker responsibly and safely. Please do not use the speaker for illegal purposes. Please do not use the speaker for any other purpose not intended by the manufacturer. © 2023 Tronsmart	Tronsmart Bang Max Portable Party Speaker User Manual Comprehensive user manual for the Tronsmart Bang Max Portable Party Speaker. Learn about package contents, features like USB-A power bank, Aux-in, TF card, Karaoke, Guitar modes, specifications, care instructions, and detailed usage guides for Bluetooth connectivity, stereo pairing, and multi-speaker connections.

	Tronsmart T6 Pro Bluetooth Speaker User Manual User manual for the Tronsmart T6 Pro Bluetooth Speaker, covering button configuration, usage instructions, TWS pairing, and technical specifications.
	Tronsmart Bang SE Portable Party Speaker FAQ Frequently asked questions about the Tronsmart Bang SE portable party speaker, covering charging, speakerphone functionality, stereo pairing, charging phones, microphone support, Bluetooth connections, usage while charging, USB playback, light synchronization, and resetting the device.

Documents - Tronsmart – Force Max



[\[pdf\]](#) User Manual

TRONSMART FORCE MAX 01 MANUAL drive google uc id 1sJcvR Z1wQb6Rvfpxo 5flpldphlasL export Force Max User Manual tronsmart force max portable outdoor speaker dablew pk file 2022 06 Tronsmart 80W bluetooth Speaker 2 Channel 15000mAh Large Battery Tri bass EQ Effects Portable Outdoor Black Dab Lew Tech |||

FORCE MAX PORTABLE OUTDOOR SPEAKER USER MANUAL Button Configuration Volume/Previous Track True Wi ... stay on yellow. 4. The Bluetooth indicator of host speaker will flash. Search and click Tronsmart **Force Max** to pair. Disconnect from True Wireless Stereo Pairing Press True Wireless Stereo Pairi... lang:en score:38 filesize: 18.75 M page_count: 0 document date: 0000-00-00



[\[pdf\]](#) User Manual Guide

Force Max User Guide Tronsmart Portable Outdoor Speaker Loud Bluetooth Tri Frequency Audio Built in Powerbank Convenient Voice Assistant IPX6 Waterproof with Retractable Strap for Electronics 91BTJ5J8auL m media amazon images I |||

FORCE MAX PORTABLE OUTDOOR SPEAKER USER MANUAL Button Configuration Volume/Previous Track True Wi ... stay on yellow. 4. The Bluetooth indicator of host speaker will flash. Search and click Tronsmart **Force Max** to pair. Disconnect from True Wireless Stereo Pairing Press True Wireless Stereo Pairi... lang:en score:36 filesize: 892.39 K page_count: 16 document date: 2022-01-20



[\[pdf\]](#) User Manual

Force Max USB A Power Bank Function This speaker carries a charge out function that will automatically detect your device and begin to it when the User Manual tronsmart force max portable outdoor pazaruvane online media dev |||


FORCE MAX PORTABLE OUTDOOR SPEAKER USER MANUAL Button Configuration Volume/Previous Track True Wi ... stay on yellow. 4. The Bluetooth indicator of host speaker will flash. Search and click Tronsmart **Force Max** to pair. Disconnect from True Wireless Stereo Pairing Press True Wireless Stereo Pairi... lang:en **score:35** filesize: 18.75 M page_count: 16 document date: 2022-01-20



[\[pdf\]](#) User Manual Warranty

Tronsmart Force Max Portable Outdoor Speaker User Manual Shirley Инструкция руководство пользователяf19d38ac77e5829cd5168b598cf7024811ba38b7e9470ecb8e2f4abf8ccb6576 optim cropped 9320266teamplush by 2025 06

f19d38ac77e5829cd5168b598cf7024811ba38b7e9470ecb8e2f4abf8ccb6576 9320266 ||| Tronsmart **Force Max** Portable Outdoor Speaker Thank you for purchasing the**Force Max** Portable Outdoor Speaker. Please read the user manual before use and keep it handy for future reference. If you have any additional questions or comments, please contact us by email at: support tronsmart.com Package ... lang:en **score:34** filesize: 126.74 K page_count: 5 document date: 2023-08-19



[\[pdf\]](#)

Tronsmart Force Max bezprzewodowy gÅoÅnik Bluetooth 80W czarny Sklep internetowy stylem pl tronsmart force max glosnik bluetooth 80w 206373 upload files product |||

Tronsmart **Force Max** bezprzewodowy glonik Bluetooth 80W czarny Indeks: 206373 Producent: Tronsmart Kod producenta: 6970232014431 Cena: 486.80 zl Opis Tronsmart **Force Max** bezprzewodowy glonik Bluetooth 80W czarny Producent: Tronsmart Wysoko opakowania towaru w cm: 25,8 Szeroko opakowania towaru w cm:... lang:sw **score:29** filesize: 405.5 K page_count: 2 document date: 2022-11-07



[\[pdf\]](#) User Manual Instructions

Инструкция по эксплуатации Tronsmart Force X Скачать инструкцию Портативная колонка черный — купить цена в Москве интернет магазине «Mobila Shop» 1668647041 0861rtfqc

m71eevvfka9vpxq40af9u3u9oldf8 mobila shop upload instructions rt fq |||

FORCE X PORTABLE OUTDOOR SPEAKER USER MANUAL Button Configuration EQ True Wireless Stereo Indicat ... stay on yellow. 4. The Bluetooth indicator of host speaker will flash. Search and click Tronsmart **Force Max** to pair. Disconnect from True Wireless Stereo Pairing Press True Wireless Stereo Pairi...

lang:en **score:29** filesize: 1.38 M page_count: 16 document date: 2022-11-16



[\[pdf\]](#) User Manual

Force Max Benutzerhandbuch Tronsmart Portable Outdoor Speaker cdn02 plentymarkets iwy3mae6bf7c frontend Downloads |||

FORCE MAX PORTABLE OUTDOOR SPEAKER USER MANUAL Button Configuration Volume/Previous Track True Wi ... stay on yellow. 4. The Bluetooth indicator of host speaker will flash. Search and click Tronsmart **Force Max** to pair. Disconnect from True Wireless Stereo Pairing Press True Wireless Stereo Pairi...

lang:en **score:28** filesize: 5.91 M page_count: 16 document date: 2023-01-16




[\[pdf\]](#)

Tronsmart Force Max ebay hu shop ordered 95894 pic |||

Tronsmart **Force Max** Bluetooth vezeték nélküli hangszóró Felhasználói kézikönyv A csomag tartalma 1 x Tronsmart **Force Max** 1 x 3,5 mm-es audiókabel 1 x C típusú töltőkabel 1 x SoundPulse kártya 1 x felhasználói kézikönyv 1 x nyakpánt USB-A power bank funkcióval Ez a hangszóró USB-töltő funkcióval van felszerelve, amely automatik...

lang:it **score:28** filesize: 38.94 K page_count: 5 document date: 2023-09-15



[pdf] Declaration of Conformity

Tronsmart Force Max TRONSMART DOC files innpro pl s3 amazonaws |||

Deklaracja zgodności UE Nazwa producenta: Shenzhen Geekbuy E-commerce Co., Ltd. Adres: Warehouse 101H, No.49 Wuhe Avenue, Wuhe Community, Bantian Street, Longgang District, Shenzhen Dla następującego sprzętu: Nazwa produktu: Główny Bluetooth Model: **Force Max** Nazwa handlowa: Tronsmart Niniejszym potwierdzam, że produkt jest zgodny z wymaganiami Unii Europejskiej. Data: 2023-08-25



[pdf] User Manual

От тук Tronsmart Element Force X 60W SoundPulse™ User Manual tronsmart force x 60w portable outdoor speaker pazaruvane online media dev User speaker |||

FORCE X PORTABLE OUTDOOR SPEAKER USER MANUAL Button Configuration EQ True Wireless Stereo Indication ... ay on yellow. 4. The Bluetooth indicator of host speaker will flash. Search and click Tronsmart **Force Max** to pair. Disconnect from True Wireless Stereo Pairing Press True Wireless Stereo P...

lang:en score:27 filesize: 8.19 M page_count: 0 document date: 2022-11-05



[pdf]

Tronsmart Force Max Bluetooth vezeték nélküli hangszóró 1. ebay hu shop ordered 95894 pic srsrtid AfmBOoqcZUwv8tF tWFp0pf MJe64M4vbZvDvJUM6HLTMt4LM1 2dxrL |||

Tronsmart **Force Max** Bluetooth vezeték nélküli hangszóró Felhasználói kézikönyv A csomag tartalma 1 x Tronsmart **Force Max** 1 x 3,5 mm-es audiókabel 1 x C típusú töltőkabel 1 x SoundPulse kártya 1 x felhasználói kézikönyv 1 x nyakpánt USB-A power bank funkció Ez a hangszóró USB-töltő funkcióval van felszerelve, amely automatikusan...

lang:it score:26 filesize: 38.94 K page_count: 5 document date: 2023-09-15

Tronsmart Force Max Portable Outdoor Speaker
Thank you for purchasing the Force Max Portable Outdoor Speaker. Please read the user manual before use and keep it handy for future reference. If you have any additional questions or comments, please contact us by email at: sales@tronsmart.com

Package Contents

- 1 x Tronsmart Force Max Portable Outdoor Speaker
- 1 x 3.5mm Audio Cable
- 1 x Type-C Charging Cable
- 1 x Warranty Card
- 1 x SoundPulse! Card
- 1 x User Manual
- 1 x Carrying Strap

USB-A Power Bank Function

This speaker carries a USB charge-out function that will automatically detect your device and begin to charge it when the charging cable is plugged into the USB-A port. The output power is up to DC 5V/2A. In order to maintain stable music playing performance, it's not recommended to use the music and power bank function at the same time.

Aux-in Mode

Simply connect the speaker with your non-Bluetooth device via the 3.5 mm audio jack cable.

Note: After plugging in an audio cable, the speaker will automatically switch to Aux-in mode.

TF Card Slot Mode



Bezdrátový reproduktor Tronsmart
Force Max Bluetooth

Uživatelská příručka

[Tronsmart Force Max Portable Outdoor Speaker User Manual](#)

Comprehensive user manual for the Tronsmart Force Max Portable Outdoor Speaker, detailing package contents, features like USB-A power bank and Aux-in, technical specifications, care instructions, and button operations for optimal use.

lang:en score:26 filesize: 217.98 K page_count: 5 document date: 2023-08-08

[\[pdf\]](#)

TRONSMART Force X CZ Max files innpro pl s3 amazonaws Tronsmart |||

Bezdrťov reproduktor Tronsmart **Force Max** Bluetooth Uživatelsk prucka Obsah balen
1 x Tronsmart **Force Max** 1 x 3,5 mm audio kabel 1 x nabjec kabel typu C 1 x karta
SoundPulse 1 x uzivatelsk prucka 1 x srka na krk Funkce powerbanky USB-A Tento
reproduktor je vybaven funkc nabjen pes USB, kter automat...

lang:hr score:22 filesize: 973.85 K page_count: 8 document date: 2023-08-10



Głośnik bezprzewodowy Bluetooth
Tronsmart Force Max

Instrukcja obsługi

[\[pdf\]](#)

TRONSMART Force X PL Max files innpro pl s3 amazonaws Tronsmart |||

Glonik bezprzewodowy Bluetooth Tronsmart **Force Max** Instrukcja obsługi Zawarto
opakowania 1 x Tronsmart **Force Max** 1 x kabel audio 3,5 mm 1 x kabel do ładowania
typu C 1 x karta SoundPulse 1 x instrukcja obsługi 1 x smycz Funkcja Power Bank
USB-A Ten glonik jest wyposaony w funkcj ładowania USB, ktr...

lang:pl score:22 filesize: 1.51 M page_count: 7 document date: 2023-08-14



Bezdrátový reproduktor
Tronsmart Force X Bluetooth

Uživatelská příručka

[\[pdf\]](#)

TRONSMART Force X CZ files innpro pl s3 amazonaws Tronsmart |||

Bezdrátový reproduktor Tronsmart Force X Bluetooth Uživatelská příručka Obsah balení 1 x Tronsmart **Force Max** 1 x 3,5 mm audio kabel 1 x nabíjecí kabel typu C 1 x karta SoundPulse 1 x uživatelská příručka 1 x srážka na krk Funkce powerbanky USB-A Tento reproduktor je vybaven funkcí nabíjení přes USB, která automaticky...

lang:hr score:22 filesize: 996.23 K page_count: 8 document date: 2023-08-10

Tronsmart Force X Portable Outdoor Speaker
Thank you for purchasing the Force X Portable Outdoor Speaker. Please read the user manual before use and keep it handy for future reference. If you have any additional questions or comments, please contact us by email at: support@tronsmart.com

Package Contents
1 x Tronsmart Force X Portable Outdoor Speaker
1 x 3.5mm Audio Cable
1 x Type-C Charging Cable
1 x SoundPulse® Card
1 x Warranty Card
1 x User Manual
1 x Carrying Strap

USB-A Power Bank Function
This speaker carries a USB charge-out function that will automatically detect your device and begin to charge it when the charging cable is plugged into the USB-A port. The output power is up to 5V/2.1A. In order to maintain stable music playing performance, it's not recommended to use the music and power bank function at the same time.

Aux-In Mode
Simply connect the speaker with your non-Bluetooth device via the 3.5 mm audio jack cable.
Note: After plugging in an audio cable, the speaker will automatically switch to Aux-In mode.

TF Card Slot Mode
The speaker will play the music from your TF/Micro SD card when plugging the card into the slot. The maximum supported memory is 64 GB.

[\[pdf\]](#) User Manual Warranty

Shirley TRONSMART Force X EN files innpro pl s3 amazonaws Tronsmart |||

Tronsmart Force X Portable Outdoor Speaker Thank you for purchasing the Force X Portable Outdoor Speaker ... stay on yellow. 4. The Bluetooth indicator of host speaker will flash. Search and click Tronsmart **Force Max** to pair. Disconnect from True Wireless Stereo Pairing Press True Wireless Stereo Pairing...

lang:en score:21 filesize: 173.47 K page_count: 5 document date: 2023-08-08



Głośnik bezprzewodowy Bluetooth
Tronsmart Force X

Instrukcja obsługi

[\[pdf\]](#)

TRONSMART Force X PL files innpro pl s3 amazonaws Tronsmart |||

Głownik bezprzewodowy Bluetooth Tronsmart Force X Instrukcja obsługi Zawarto opakowania 1 x Tronsma ... nikw pozostanie lty. 4. Wskanik Bluetooth glonika glwnego bdzie miga. Wyszukaj i kliknij Tronsmart **Force Max** , aby sparowa. Rozlczanie z True Wireless Stereo Nacinij przycisk parowania TWS przy wylcz... lang:pl **score:21** filesize: 1.42 M page_count: 7 document date: 2023-08-14



Tronsmart Force Max Bluetooth vezeték nélküli hangszóró

Felhasználói kézikönyv

[\[pdf\]](#)

TRONSMART Force X HU Max files innpro pl s3 amazonaws Tronsmart |||

Tronsmart **Force Max** Bluetooth vezeték nélküli hangszóró Felhasználói kézikönyv A csomag tartalma 1 x Tronsmart **Force Max** 1 x 3,5 mm-es audiókabel 1 x C típusú töltőkabel 1 x SoundPulse kártya 1 x felhasználói kézikönyv 1 x nyakpánt USB-A power bank funkció Ez a hangszóró USB-töltő funkcióval van felszerelve, amely automatik...

lang:it **score:21** filesize: 1.08 M page_count: 11 document date: 2023-08-10



Tronsmart Force X Bluetooth vezeték nélküli hangszóró

Felhasználói kézikönyv

[\[pdf\]](#)

TRONSMART Force X HU files innpro pl s3 amazonaws Tronsmart |||

Tronsmart Force X Bluetooth vezeték nélküli hangszóró Felhasználói kézikönyv A csomag tartalma 1 x Tronsmart **Force Max** 1 x 3,5 mm-es audiókabel 1 x C típusú töltőkabel 1 x SoundPulse kártya 1 x felhasználói kézikönyv 1 x nyakpánt USB-A power bank funkcióval Ez a hangszóró USB-töltő funkcióval van felszerelve, amely automatikus...

lang:it score:21 filesize: 1.15 M page_count: 11 document date: 2023-08-10