



[Manuals.plus](#) /

› [Hisense](#) /

› Hisense VIDAA Smart TV 58A6KTUK User Manual

Hisense 58A6KTUK

Hisense VIDAA Smart TV 58A6KTUK User Manual

Model: 58A6KTUK

1. INTRODUCTION AND OVERVIEW

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Hisense VIDAA Smart TV 58A6KTUK. This 4K television features Direct Full Array technology for enhanced contrast and brightness, Dolby Vision for stunning visual clarity, and Pixel Tuning for optimized image details. The integrated VIDAA Smart TV operating system offers easy access to streaming applications, complemented by Alexa voice remote and VIDAA Voice for convenient navigation. Content sharing from mobile devices to the TV is also supported.



Figure 1: Front view of the Hisense VIDAA Smart TV 58A6KTUK.


Included Components

Upon unpacking, ensure all the following items are present:

- Hisense VIDAA Smart TV Unit
- TV Stand (2 pieces)
- Remote Control
- Remote Control Batteries (AAA alkaline, 2 pieces)
- User Manual (this document)
- Quick Start Guide
- Energy Label
- Power Cable

Hisense

UHD TV A6K 58"



Dimensions with stand (width x depth x height)
1295×274×809 mm

Dimensions without stand (width x depth x height)
1295×70×752 mm

Stand Width : 922 mm

Weight : 12.6 kg

What's in the Box

- Remote
- Battery
- User Manual
- Quick Start Page

Figure 2: Diagram illustrating TV dimensions with and without stand, and a list of included components.

2. SETUP

2.1 Stand Installation

To install the TV stand:

1. Carefully place the TV screen-down on a soft, flat surface to prevent damage.
2. Align each stand piece with the corresponding slots on the bottom of the TV.
3. Secure the stands using the provided screws. Ensure they are tightened firmly.



Figure 3: Close-up view of the TV stand attached to the television.

2.2 Connecting External Devices

The TV offers various ports for connecting external devices:

- **HDMI Ports:** Connect Blu-ray players, game consoles, or set-top boxes.
- **USB Ports:** For connecting USB storage devices to play media.
- **Antenna (ANT) Input:** Connect your terrestrial or cable antenna.
- **AV Input:** For older devices using composite video and stereo audio.
- **Digital Audio Out:** For connecting to external audio systems.
- **Ethernet Port:** For a wired internet connection.
- **Headphone Jack:** For private listening.
- **CI Card Slot:** For conditional access modules (CAMs) for encrypted channels.



Figure 4: Detailed view of the TV's rear panel with labeled connection ports.

2.3 Power Connection and Initial Setup

After connecting all necessary cables:

1. Plug the power cable into the TV and then into a wall outlet.
2. Press the power button on the remote control or on the TV itself.
3. Follow the on-screen instructions for the first-time setup, which typically includes selecting your language, connecting to a Wi-Fi network, and scanning for TV channels.

3. OPERATING INSTRUCTIONS

3.1 Remote Control Functions

The provided remote control allows full command over your TV. It features dedicated buttons for popular streaming services and integrated voice control.

- **Power Button:** Turns the TV on or off.

- **Input Button:** Selects input sources (HDMI, AV, etc.).
- **Navigation Buttons (Up/Down/Left/Right/OK):** For menu navigation and selection.
- **Volume Up/Down:** Adjusts the audio volume.
- **Channel Up/Down:** Changes TV channels.
- **Voice Control Button:** Activates Alexa built-in or VIDAA Voice for commands.
- **App Shortcut Buttons:** Direct access to services like Netflix, Disney+, Prime Video, YouTube, etc.



Figure 5: The TV remote control, highlighting the voice control functionality.

3.2 VIDAA Smart TV Interface

The VIDAA U operating system provides a user-friendly interface for accessing a wide range of content and applications.

- **Home Screen:** Displays your favorite apps, recommended content, and input sources.
- **App Store:** Download and install additional applications.
- **Universal Search:** Find content across various platforms.
- **One-Click Play:** Quickly launch your preferred streaming services.



Figure 6: The VIDAA Smart TV home screen with various application icons.

3.3 Picture and Sound Enhancement

Your Hisense TV incorporates advanced technologies for superior audiovisual experience:

- **Dolby Vision:** Delivers enhanced visual clarity with vibrant colors, deeper blacks, and brighter highlights.
- **Pixel Tuning:** Dynamically optimizes image quality at the pixel level, adjusting contrast, brightness, and sharpness for ideal details.
- **Direct Full Array:** Precise control of individual LEDs across the entire back panel for superior contrast.
- **DTS Audio:** Provides immersive stereo sound with English audio support.



Figure 7: Visual representation of Dolby Vision technology and its impact on entertainment experience.

Top Features



Figure 8: Overview of the TV's top features, including 4K resolution, Pixel Tuning, MEMC, Dolby Vision, Direct Full Array, and Voice Control.

3.4 Share to TV Functionality

The Share to TV feature allows you to cast content from your mobile devices directly to the television. This can be done via screen mirroring or by sharing specific media while continuing to use your device.

4. MAINTENANCE

4.1 Cleaning the TV

- **Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner. Avoid harsh chemicals.
- **Body:** Use a soft, dry cloth to wipe the TV's frame and back panel.
- Always unplug the TV from the power outlet before cleaning.

4.2 Software Updates

Your TV may receive software updates to improve performance and add new features. Ensure your TV is connected to the internet to receive these updates automatically or check for them manually through the settings menu.

5. TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common problems and solutions:

Problem	Possible Solution
No Power	Check if the power cable is securely connected to both the TV and the wall outlet. Ensure the outlet is functional.
No Picture, but Sound is Present	Verify the correct input source is selected. Check external device connections (e.g., HDMI cable).
No Sound, but Picture is Present	Check the volume level and mute status. Ensure external audio systems are correctly connected and powered on.
Cannot Connect to Wi-Fi	Ensure your Wi-Fi router is on and within range. Re-enter the Wi-Fi password. Try restarting both the TV and the router.
Remote Control Not Working	Replace the batteries. Ensure there are no obstructions between the remote and the TV's IR sensor.

For more detailed troubleshooting or persistent issues, please refer to the comprehensive troubleshooting section in the full user manual or contact Hisense customer support.

6. SPECIFICATIONS

Key technical specifications for the Hisense VIDAA Smart TV 58A6KTUK:

Feature	Specification
Manufacturer	Hisense
Model Number	58A6KTUK
Screen Size	58 inches
Display Technology	LED
Resolution	4K (3840 x 2160)
Refresh Rate	60 Hz
Supported HDR Format	Dolby Vision
Image Enhancement	Direct Full Array, Dolby Vision, Pixel Tuning, MEMC
Operating System	VIDAA U
Connectivity Technology	Wi-Fi, Bluetooth, Ethernet

Feature	Specification
Hardware Interface	HDMI, USB, Ethernet, Bluetooth
Total HDMI Ports	3
Total USB Ports	3
Audio Output Mode	Digital
Audio Encoding	DTS
Product Dimensions (D x W x H)	7P x 129.5W x 75.2H cm
Item Weight	10 kg (without stand: 100 Grams - likely a typo in source, assuming 10kg is with stand)
Color	Black
Model Year	2023

7. WARRANTY AND SUPPORT

7.1 Product Warranty

Your Hisense VIDAA Smart TV 58A6KTUK is covered by a manufacturer's warranty. Please refer to the warranty card included in the packaging or visit the official Hisense website for detailed information regarding warranty terms, conditions, and duration in your region.

7.2 Customer Support

Should you require further assistance, technical support, or service, please contact Hisense customer support. Contact details can typically be found on the Hisense official website or in the quick start guide provided with your TV.