Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Luqeeg Luqeeg4207dvwep5

Motorcycle Throttle Lock Assist User Manual

Model: Luqeeg4207dvwep5

Introduction

Thank you for choosing the Luqeeg Motorcycle Throttle Lock Assist. This device is designed to provide innovative throttle assistance, helping to relax your grip, relieve fatigue, and enhance riding comfort during long journeys. It is a universal accessory compatible with 22mm (7/8 inch) handlebars, specifically suitable for R1200GS and R1250GS motorcycles.



Image: The Luqeeg Motorcycle Throttle Lock Assist, a black device with metal accents, designed to attach to a motorcycle handlebar.

Safety Information

Always prioritize safety when operating your motorcycle. This throttle assist is designed to provide comfort and reduce fatigue, but it is not a substitute for proper throttle control. Ensure the device is correctly installed and functioning before each ride. The cruise control is not locked on at any time and can be easily overridden or disengaged. Always maintain full control of your motorcycle.

Package Contents

Please verify that all the following items are included in your package:

- 1 x Throttle Lock Assist Main Unit
- 1 x 2mm Hex Key
- 1 x 2.5mm Hex Key
- 1 x 3mm Hex Key
- 1 x Screw
- 1 x Mounting Cap
- 3 x Rubber Rings
- 1 x Mounting Ring
- 1 x Handlebar Ring
- 1 x Accessory Bracket



Image: All components of the Luqeeg Motorcycle Throttle Lock Assist laid out, including the main unit, various rings, screws, and hex keys.

Setup and Installation

The installation process is straightforward and typically takes about 15 minutes. Ensure you have free access to the bottom of your motorcycle's brake lever for proper installation.

1. **Prepare the Handlebar:** Ensure the handlebar area where the throttle assist will be mounted is clean and free from obstructions.
2. **Assemble the Main Unit:** Attach the accessory bracket and mounting cap to the main throttle lock unit using the provided screw.
3. **Install Rubber Rings:** Place the appropriate rubber rings onto the handlebar ring and mounting ring to ensure a snug fit and prevent slippage.
4. **Position the Throttle Lock:** Carefully position the throttle lock assist on your 22mm (7/8 inch) handlebar, ensuring it is aligned correctly with your throttle grip and brake lever. The device should be positioned so that the thumb lever can be easily accessed.
5. **Secure the Clamps:** Use the provided hex keys (2mm, 2.5mm, 3mm) to tighten the screws on the handlebar clamp components. Ensure the clamps are securely fastened but do not overtighten, which could damage the handlebar or the device.

6. **Test Functionality:** Before riding, manually test the throttle assist to ensure it engages and disengages smoothly. Verify that it does not interfere with the normal operation of your throttle or brake.



Image: The throttle lock assist installed on a motorcycle handlebar, showing its position relative to the throttle grip and brake lever.



Image: A close-up view of the separate handlebar clamp components, illustrating how they secure the device to the handlebar.



Image: The three hex keys (2mm, 2.5mm, 3mm) included for installation.

Operating Instructions

The Luqeeg Throttle Lock Assist is designed for simple and intuitive operation:

- **Engaging the Assist:** While riding at your desired speed, simply press down the thumb lever to engage the throttle assist. This will hold the throttle in position, allowing you to relax your grip and reduce hand fatigue.
- **Disengaging the Assist:** To disengage the throttle assist, simply flip up the thumb lever. The device will release the throttle, allowing for immediate manual control. You can also override it with a twist of the hand.
- **Adjusting Speed:** While engaged, minor speed adjustments can still be made by gently twisting the throttle. For significant speed changes or braking, disengage the assist.



Image: A close-up of the throttle lock assist, highlighting the thumb lever used for engagement and disengagement.



Image: The throttle lock assist positioned in the foreground with a motorcycle in the background, illustrating its purpose of relaxing the throttle grip and reducing fatigue.

Maintenance

The Luqeeg Throttle Lock Assist is constructed from durable nylon and rubber, designed for long-term outdoor use. Minimal maintenance is required:

- **Cleaning:** Wipe the device periodically with a damp cloth to remove dirt and grime. Avoid using harsh chemicals that could damage the material.
- **Inspection:** Regularly inspect the device for any signs of wear, damage, or loose components. Ensure all screws are snug.
- **Storage:** If storing your motorcycle for an extended period, ensure the throttle assist is clean and dry.

Troubleshooting

Problem	Possible Cause	Solution
Throttle assist does not engage or hold position.	Incorrect installation; loose clamps; worn rubber rings.	Re-check installation steps, ensure clamps are tight, replace rubber rings if worn.
Device interferes with throttle or brake operation.	Improper positioning on the handlebar.	Adjust the position of the throttle assist to ensure it does not obstruct other controls. Ensure free access to the bottom of the brake lever.
Device feels loose after installation.	Clamps not tightened sufficiently; incorrect rubber ring size.	Tighten all screws using the hex keys. Ensure the correct rubber rings are used for a snug fit on your 22mm handlebar.

Specifications

- **Model:** Luqeeg4207dvwep5
- **Material:** Durable Nylon, Rubber
- **Compatibility:** Universal for 22mm (7/8 inch) handlebars; specifically fits R1200GS R1250GS motorcycles.
- **Item Weight:** 200 grams
- **Package Dimensions:** 35.29 x 27.8 x 2.2 cm
- **Assembly Required:** No (minor installation)

Warranty and Support

Luqeeg provides a **24-month warranty** or refund for this Motorcycle Throttle Lock Assist. We are confident in the quality of our product.
If you have any questions, concerns, or require assistance with your purchase, please do not hesitate to contact us. Our support team is committed to resolving your issues within 24 hours.
For support, please refer to the contact information provided with your purchase or visit the official Luqeeg website.

© 2023 Luqeeg. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C4ZHGX2V

More documents and user manuals: **https://manuals.plus/**