AutoSky APT-110

AutoSky Portable GPS Tracker (Model APT-110) Instruction Manual

Brand: AutoSky | Model: APT-110

1. Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your AutoSky Portable GPS Tracker (Model APT-110). This compact and durable device offers real-time tracking for vehicles, assets, and personal belongings, utilizing advanced GPS and cellular technology. It features a built-in magnet for easy attachment and supports geofence notifications for enhanced security.

2. Setup Guide

2.1. Unboxing Your Device

Upon opening the package, you will find the AutoSky Portable GPS Tracker, a USB-C charging cable, a lanyard, and a user manual. The device also includes an attachable industrial magnet for secure mounting.

Figure 1: What's in the Box? The image displays the AutoSky Portable GPS Tracker, a USB-C charging cable, a lanyard, and the product manual.

2.2. Downloading the AutoSky+ App

To begin using your GPS tracker, download the official AutoSky+ mobile application. Scan the QR code provided on the back of the product box or in the manual, or search for "AutoSky+" in the Apple App Store or Google Play Store.

Figure 2: Add Your Tracker. This image illustrates the process of downloading the AutoSky+ app and adding a new device using the serial number.

2.3. Account Creation and Device Activation

Follow the on-screen instructions within the AutoSky+ app to create your account. During this process, you will be prompted to add your GPS tracker. Locate the serial number (SN) on the device itself, the manual, or the product box and enter it into the app. It is recommended to allow notifications to receive important updates regarding your device.

Your browser does not support the video tag.

Video 1: Activate Your GPS Tracker. This video provides a step-by-step guide on how to create an account and activate your AutoSky GPS Tracker within the app.

The activation process may take up to 45 minutes. Ensure your device is charged and placed near a window for optimal connectivity during activation. Do not delete your device from your account during this period.

2.4. Initial Charging

Before first use, fully charge your GPS tracker using the provided USB-C cable. Connect the cable to the device's USB-C port and a compatible power source. Verify that the GPS lights on the device are ON, indicating it is active and charging.

3. Operating Your GPS Tracker

3.1. Real-Time Tracking

Once activated, you can monitor the precise location of your AutoSky GPS Tracker in real-time via the AutoSky+ mobile app. The app displays the current location on a map, allowing you to track movements anytime, anywhere.



Figure 3: GPS Tracking. The image shows the AutoSky+ app interface with a map displaying the real-time location and historical routes of a GPS tracker.

3.2. Geofence Notifications

Set up virtual boundaries (geofences) within the AutoSky+ app. You will receive instant notifications when the tracker enters or exits these specified areas, enhancing security and enabling proactive monitoring of your assets or loved ones.

Figure 4: Geo Fence. This image demonstrates the geofence feature, allowing users to receive entry and exit notifications for specific locations.

3.3. SOS Button

The device is equipped with an SOS button. In an emergency, press and hold the SOS button for 3 seconds to alert your

specified contacts. The app will send notifications with the device's location to your pre-configured emergency contacts.

Figure 5: SOS Button. This image shows the SOS button on the tracker and corresponding alert messages on a smartphone, indicating an emergency.

3.4. Intelligent Mode and Power Saver Mode

The tracker offers different operating modes to optimize battery life and tracking frequency:

- **Intelligent Mode:** Broadcasts location every 3 minutes when in motion or if a turn of 35 degrees or more is detected. The interval can be adjusted to as quick as every 10 seconds, which will impact battery life.
- **Power Saver Mode:** This mode sends location updates less frequently, typically once every 30 minutes to every 24 hours, depending on settings.



Figure 6: Mode Setting. This image displays the app interface for configuring Intelligent Mode and Battery Saver Mode, allowing users to adjust transmission intervals.

3.5. Sharing Your Party Group

The AutoSky+ app allows you to create and manage a "party group" to share tracking data with family members or friends. You can invite others to your group by sharing a QR code from the app's settings.

Your browser does not support the video tag.

Video 2: AutoSky+ the Best GPS Tracker App. This video demonstrates various features of the AutoSky+ app, including sharing your location with a party group via QR code.

4. Maintenance

4.1. Charging

Regularly charge your device to ensure continuous tracking. The battery duration depends on the selected tracking mode (Intelligent or Power Saver). Use the provided USB-C cable for charging.

4.2. Cleaning and Durability

The AutoSky Portable GPS Tracker is designed to be splashproof and durable. Clean the device with a soft, dry cloth. Avoid submerging the device in water or exposing it to extreme temperatures.

4.3. Magnetic Attachment

The built-in magnet allows for easy and secure attachment to any metal surface. Ensure the surface is clean and dry before attaching the device to maintain a strong hold.



Figure 7: Strong Magnet. This image emphasizes the waterproof, heavy-duty magnet integrated into the tracker for firm attachment to metal surfaces.

5. Troubleshooting

5.1. Device Not Activating

If your device is not activating after selecting a subscription plan, ensure it is fully charged and placed near a window for optimal signal reception. The activation process can take up to 45 minutes. Do not remove the device from your account during this time.

5.2. Inaccurate Location Data

Ensure the device has a clear line of sight to the sky for accurate GPS reception. Obstructions like thick building materials or dense foliage can interfere with signal quality. Verify that the device is sufficiently charged.

5.3. App Connectivity Issues

Check your mobile device's internet connection. Ensure the AutoSky+ app is updated to the latest version. If issues persist, try restarting the app or your mobile device.

5.4. Subscription Required

Please note that a subscription is required for the AutoSky GPS Tracker to function. Subscription plans start at $16.99 per month for a month-to-month option, with lower rates available for longer commitments (e.g., $8.99 per month for a 36-month annual subscription). All plans allow modification of the time interval via AutoSky+.

6. Specifications

- **Brand:** AutoSky
- **Model Number:** APT-110
- **Special Feature:** Magnetic
- **Connectivity Technology:** Cellular
- **Supported Application:** GPS
- **Specific Uses:** Tracking various assets, such as vehicles, bicycles, or personal belongings
- **Additional Features:** Magnetic
- **Compatible Devices:** Smartphone
- **Smart Home Compatibility:** Smart Home Compatible
- **Built-In Media:** Battery
- **Manufacturer:** Promaster Electronic LLC
- **UPC:** 860008429810
- **ASIN:** B0C51SX6TG

7. Warranty Information

The AutoSky Portable GPS Tracker (Model APT-110) comes with a**1 Year Warranty**. Please refer to the warranty card included in your product packaging for full details and registration instructions.

8. Customer Support

For any questions, technical assistance, or support regarding your AutoSky GPS Tracker, please contact customer service. AutoSky offers 24/7 customer service to ensure your satisfaction.
You can find contact information on the AutoSky website or within the AutoSky+ app.

© 2026 AutoSky. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question